
Order No: PAPAMY1803051CE

Service Manual Air-to-Water Heatpump

Mono Bloc Unit WH-MXC09H3E8 WH-MXC12H9E8 WH-MXC16H9E8

> Destination Europe Turkey



This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the products dealt with in this service information by anyone else could result in serious injury or death.

A PRECAUTION OF LOW TEMPERATURE

In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.



© Panasonic Corporation 2018.

TABLE OF CONTENTS

		IAGE
	fety Precautions	
2. Sp	ecifications	6
2.1	WH-MXC09H3E8	
2.2 2.3	WH-MXC12H9E8 WH-MXC16H9E8	
	atures	
4. Lo	cation of Controls and Components	
4.1	Indoor Unit	16
5. Dir	nensions	34
5.1	Mono Bloc Unit	34
6. Re	frigeration and Water Cycle Diagram	35
6.1	Standard System	
	(Optional PCB not connected)	36
6.2	Advance System (Optional PCB connected)	36
7 Blo	ock Diagram	
7.1	WH-MXC09H3E8	
7.1	WH-MXC09H3E8	
7.3	WH-MXC16H9E8	
8. Wi	ring Connection Diagram	40
8.1	Water System	40
8.2	Refrigerant System	42
9. Ele	ctronic Circuit Diagram	44
9.1	Water System	
9.2	Refrigerant System	
-	nted Circuit Board	-
	Water System	
	Refrigerant System	
	tallation Instruction	
	Mono Bloc Unit Variation of system	
	How to Fix External Device	
11.4	System Installation	
12. Op	eration and Control	86
12.1	Basic Function	86
	Water Pump	98
	Indoor Unit Safety Auto Restart Control	
	Indication Panel	
	Indoor Back-Up Heater Control	
	Tank Heater Control	103
12.8	Base Pan Heater Control (Optional)	
	Heater Turn ON/OFF priority Control	
) Force Heater Mode 1 Powerful Operation	
	2Quiet Operation	
12.13	3 Sterilization Mode	109
12.14	Outdoor Ambient Thermo OFF Control	109

	12.15	Alternative Outdoor Ambient Sensor				
	Control					
	12.16 Force DHW mode 11 12.17 Anti Freeze Control 11					
12.18 Solar Operation (Optional)						
	12.19 Boiler Bivalent Control 113					
	12.20	External Room Thermostat Control	15			
	12 21	(Optional)11 I Three Ways Valve Control	15 16			
	12.22	2Two Ways Valve Control11	17			
	12.23	3 External OFF/ON Control 11	17			
	12.24	External Compressor Switch (Optional PCB)11	10			
	12.25	5Heat/Cool Switch (Optional PCB)	19			
	12.26	SG Ready Control (Optional PCB) 12	20			
	12.27	7 Demand Control (Optional PCB)	21			
		3 Holiday Mode				
)Flow Sensor				
13	3. Pro	otection Control12	23			
	13 1	Protection Control for All Operations 12	23			
		Protection Control for Heating Operation 12				
	13.3	Protection Control for Cooling Operation 12	27			
14	4. Ser	vicing Mode 12	28			
	14.1					
		Checking				
	14.2 14.3	Maintenance 12 Pump Down Procedures 12				
	14.3	How To Adjust Pump Speed				
	14.5	How To Adjust Pump Speed 13	31			
	14.6	How To Unlock Cool Mode	32			
	14.7	EEPROM Factory Default Data Setup Procedure	22			
	14.8	Dry Concrete Setup	34			
1	5. Mai	intenance Guide13				
	15.1	Maintenance Menu13	37			
16		oubleshooting Guide13				
		Refrigeration Cycle System				
		Relationship between the Condition of the				
		Air-to-Water Heatpump Indoor and				
		Outdoor Units and Pressure and Electric	10			
	16.3	Current				
		Error Codes Table				
	16.5	Self-diagnosis Method 14	15			
17	7. Dis	assembly and Assembly Instructions 19	97			
		To Remove The Cabinet Front Plate 19				
	17.2	To Remove The Cabinet Top Plate				
		To Remove The Cabinet Rear Plate				
	17.5	To Remove Water System Electronic				
		Controller Board 19				
	17.6	To Remove Air Purge Valve				

PAGE

17.9 To Remove Heater 17.10To Remove Filter	
18. Technical Data	204
18.1 Operation Characteristics	204
18.2 Heating Capacity Table	
18.3 Cooling Capacity Table	
19. Exploded View and Replacement	
Parts List	213
19.1 Water System	213
19.2 Refrigerant System	

1. Safety Precautions

- Read the following "SAFETY PRECAUTIONS" carefully before installation of (Mono bloc) Air-to-Water Heatpump system (hereafter referred to as "Mono bloc unit").
- Electrical works and water installation works must be done by licensed electrician and licensed water system installer respectively. Be sure to use the correct rating and main circuit for the model to be installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below.

Incorrect installation due to ignorance or negligence of the instructions will cause harm or damage, and the seriousness is classified by the following indications.

MARNING This indication shows the possibility of causing death or serious injury.	
CAUTION This indication shows the possibility of causing injury or damage to properties only.	

The items to be followed are classified by the symbols:

Symbol with white background denotes item that is PROHIBITED from doing.	
00	Symbol with dark background denotes item that must be carried out.

- Carry out test run to confirm that no abnormality occurs after the installation. Then, explain to user the operation, care and
 maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.
- If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.

1.	Do not install Mono bloc unit near handrail of veranda. When installing Mono bloc unit at veranda of high rise building, child may climb up to Mono bloc unit and cross over the handrail and causing accident.	\bigcirc
2.	Do not use unspecified cord, modified cord, join cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.	\bigcirc
3.	Do not tie up the power supply cord into a bundle by band. Abnormal temperature rise on power supply cord may happen.	\bigcirc
4.	Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury.	\bigcirc
5.	Do not sit or step on the unit, you may fall down accidentally.	\bigcirc
6.	Keep plastic bag (packaging material) away from small children, it may cause suffocation.	\bigcirc
7.	Do not use pipe wrench to install refrigerant pipe. It might deform the piping and cause the unit to malfunction.	\bigcirc
8.	Do not purchase unauthorized electrical parts for installation, service, maintenance and etc They might cause electrical shock or fire.	\bigcirc
9.	This unit is a multi supply appliances. All circuits must be disconnected before accessing to the unit terminals.	\bigcirc
10.	Do not modify the wiring of Mono bloc unit for installation of other components (i.e. heater, etc). Overloaded wiring or wire connection points may cause electrical shock or fire.	\bigcirc
11.	Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury etc.	\bigcirc
12.	For electrical work, follow the local national wiring standard, regulation and this installation instruction. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire.	0
13.	For water circuit installation work, follow to relevant European and national regulations (including EN61770) and local plumbing and building regulation codes.	0
14.	Must engage an authorized dealer or specialist for installation. If installation is defective, it will cause water leakage, electrical shock or fire.	0
15.	Install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire.	0
16.	Only use the supplied or specified installation parts. Else, it may causes Mono bloc unit vibrate, fall, water leakage, electrical shock or fire.	0
17.	Install at a flat, strong and firm location which is able to withstand the Mono bloc unit's weight. If the location is slanting, or strength is not enough the set will fall and cause injury.	0
18.	This equipment is strongly recommended to be installed with Residual Current Device (RCD) on-site according to the respective national wiring rules or country-specific safety measures in terms of residual current.	0
19.	The unit is only for use in a closed water system. Utilization in an open water system may lead to excessive corrosion of the water piping and risk of incubating bacteria colonies, particularly Legionella, in water.	0
20.	If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.	0
21.	Select a location where in case of water leakage, the leakage will not cause damage to other properties.	0

22.	When installing electrical equipment at wooden building of metal lath or wire lath, in accordance with electrical facility standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between.	0		
23.	This installation may be subjected to building regulation approval applicable to respective country that may require to notify the local authority before installation.	0		
24.	Any work carried out on the Mono bloc unit after removing the front panel which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.	0		
25.	This unit must be properly earthed, the electrical earth must not be connected to a gas pipe, water pipe, the earth of a lightning rod or a telephone. Otherwise there is a danger of electrical shock in the event of an insulation breakdown or electrical earth fault in the Mono bloc unit.	0		
1.	Do not install the Mono bloc unit in areas where there is a risk of flammable gas leakage. There is a risk of fire if flammable gas accumulates near or around the Mono bloc unit.	\bigcirc		
2.	Do not release refrigerant during piping work for installation, re-installation and during repairing a refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite.	\bigcirc		
3.	Make sure the power supply cord does not contact with hot part (i.e. water piping). High temperature may cause insulator of power supply cord damage hence electrical shock or fire.	\bigcirc		
4.	4. Do not touch the sharp aluminium fin, sharp parts may cause injury.			
5.	Do not apply excessive force to water pipes that may damage the pipes. If water leakage occurs, it will cause flooding and damage to other properties.	\bigcirc		
6.	Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water leakage may happen and may cause damage to properties of the user.	0		
7.	The piping installation work must be flushed before the Mono bloc unit is connected to remove contaminants. Contaminants may damage the Mono bloc unit components.	0		
8.	Select an installation location where it is accessible for maintenance.			
9.	 Power supply connection to Mono bloc unit. Power supply point should be in easily accessible place for power disconnection in case of emergency. Must follow local national wiring standard, regulation and this installation instruction. Strongly recommended to make permanent connection to a circuit breaker. It must be a double pole switch with a minimum 3.0 mm gap. Power Supply 1: Use approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0mm. Power Supply 2: Use approved 15/16A 2-poles circuit breaker with a minimum contact gap of 3.0mm. (Only applicable for WH-MXC09H3E8) or Use approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0mm. (Only applicable for WH-MXC12H9E8, WH-MXC16H9E8) 	0		
10.	Ensure the correct polarity is maintained throughout all wiring. Otherwise, it will cause electrical shock or fire.	0		
11.	After installation, the installer is obliged to verify correct operation of the Mono bloc unit. Check the connection point for water leakage during test run. If leakage occurs, it will cause damage to other properties.	0		
12.	Installation work. Four or more people are required to carry out the installation work. The weight of Mono bloc unit might cause injury if carried by less than four people.	0		

2. Specifications

2.1 WH-MXC09H3E8

Item		Unit	Refrigerant System			
Performance Test Condition	1		EN 14511			
POS (EAN)			5025232874354			
		Condition (Ambient/Water)	A35W7			
Cooling Capacity		kW		7.00		
		BTU/h	23900			
		kcal/h	6020			
Cooling FED		W/W	3.17			
Cooling EER		kcal/h		2.72		
		Condition (Ambient/Water)	A7W35		A2W35	
Heating Capacity		kW	9.00		9.00	
		BTU/h	30700		30700	
		kcal/h	7740		7740	
Heating COP		W/W	4.84		3.59	
		kcal/h	4.16		3.08	
	Low temperature Ap	plication (W35)	Warmer	Average	Colder	
	Application	Climate	wanner	Average	Colder	
	Pdesign	kW	9.0	9.0	11.0	
	Tbivalent / TOL	°C	2/2	-10 / -10	-15 / -22	
	SCOP / ns	(W/W) / %	5.95 / 235	4.59 / 181	4.08 / 160	
	Annual Consumption	kWh	2020	4049	6651	
Heating ErP	Class		A++	A++	A++	
	Medium temperature A	pplication (W55)			e Colder	
	Application	Climate	Wanner	Average	Colder	
	Pdesign	kW	9.0	9.0	11.0	
	Tbivalent / TOL	°C	2/2	-10 / -10	-15 / -22	
	SCOP / ns	(W/W) / %	4.02 / 158	3.32 / 130	3.20 / 125	
	Annual Consumption	kWh	2991	5596	8468	
	Class		A++	A++	A++	
Air Flow		m³/min (ft³/min)	Cooling: 89.5 (3160) Heating: 76.8 (2710))	
Refrigerant Control Device			Expansion Valve			
Refrigerant Oil		cm³	FV50S (1200)			
Refrigerant (R410A)		kg (oz)	2.30 (81.2)			
ECAS	GWP		2088			
F-GAS	CO2eq (ton) (Prechar	ged / Maximum)	4.802 / -			
	Туре			Hermetic Motor		
Compressor	Motor Type		Brushless (4-poles)			
	Rated Output	kW	4.50			

Item		Unit	Refrigerant System
	Туре		Propeller Fan
	Material		PP
Fan	Motor Type		DC (8-poles)
i dii	Output Power	W	60
	Fan Speed	rpm	Cooling: 550 (Top), 590 (Bottom) Heating: 490 (Top), 530 (Bottom)
	Fin Material		Aluminium (Pre Coat)
Heat Evolution	Fin Type		Corrugated Fin
Heat Exchanger	Row x Stage x FPI		2 x 51 x 19
	Size (W x H X L)	mm	903.7 x 1295.4 x 38.1

I	tem	Unit		Mono bloc Unit	
	Height	mm (inch)		1410 (55-1/2)	
Dimension	Width	mm (inch)	1283 (50-1/2)		
	Depth	mm (inch)	320 (12-19/32)		
Net Weight	·	kg (lbs)		151 (333)	
		Condition (Ambient/Water)	A35W7	A7W35	A2W35
Noise Level		dB(A)	Cooling: 49	Heating: 51	-
		Power level dB	Cooling: 67	Heating: 68	-
		Ø		Three	
Power Source (Phase, Volt	age, Cycle)	V	400		
		Hz	50		
Input Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35
		kW	Cooling: 2.21	Heating: 1.86	Heating: 2.51
Maximum Input Power for Heatpump System		kW	6.96k		
Power Supply 1 : Phase (Ø) / Max. Current (A) / Max. Inp	ut Power (W)	3Ø / 14.7 / 9.96k		
Power Supply 2 : Phase (Ø) / Max. Current (A) / Max. Inp	ut Power (W)	1Ø / 13.0 / 3.00k		
Power Supply 3 : Phase (Ø) / Max. Current (A) / Max. Inp	ut Power (W)	- / - / -		
Starting current		A	3.5		
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35
		A	Cooling: 3.5	Heating: 3.0	Heating: 3.9
Maximum Current for Heat	oump System	A	10.4		·
Power Factor Power factor means total figure of compressor and		Condition (Ambient/Water)	A35W7	A7W35	A2W35
outdoor fan motor.		%	Cooling: 91	Heating: 91	Heating: 93
	Number of core		-		
Power Cord	Length	m (ft)	-		
Thermostat	•		Electronic Control		
Protection Device			Electronic Control		

Item		Unit	Water System
Performance Test Condi	tion		EN14511
POS (EAN)			5025232874354
	Outdoor Ambient	°C (min. / max.)	Cooling: 16 / 43 Heating: -20 / 35
Operation Range	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating : 20 / 55 (Below Ambient -15°C) 20 / 60 (Above Ambient -10°C)
Internal Pressure Differential		kPa	Cooling: 20 Heating: 30
	Inlet	inch	1-1/4
Water Pipe Diameter	Outlet	inch	1-1/4
Water Drain Hose Inner Diameter		mm (inch)	15.00 (19/32)
Duran	Motor Type		DC Motor
Pump	Input Power	W	74
	Туре		Brazed Plate
	No. of Plates		36
Hot Water Coil	Size (H x W x L)	mm	65 x 120 x 376
	Water Flow Rate	l/min (m³/h)	Cooling: 20.1 (1.2) Heating: 25.8 (1.5)
Pressure Relief Valve W	ater Circuit	kPa	Open: 300, Close: 266 and below
Flow Switch Type			Electronic Sensor
Protection Device		A	Residual Current Circuit Breaker (25)
	Volume		10
Expansion Vessel	MWP	bar	3
Capacity of Integrated Electric Heater		kW / °C	3.00
Capacity of Integrated Electric Heater		kW/°C	3.00

Note:

- Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled indoor water inlet temperature of 12°C and water outlet temperature of 7°C.
- Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled indoor water inlet temperature of 30°C and water outlet temperature of 35°C.
- Specification are subjected to change without prior notice for further improvement.
- Flow rate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and =5°C

2.2 WH-MXC12H9E8

lt	em	Unit		Refrigera	nt System		
Performance Test Condition	1			EN 1	4511		
POS (EAN)				5025232	2874361		
		Condition (Ambient/Water)	A35W7				
Cooling Capacity		kW	10.00				
		BTU/h	34100				
		kcal/h		86	00		
Cooling EER		W/W	2.81				
		kcal/h		2.4	42		
		Condition (Ambient/Water)	A7W35			A2W35	
Heating Capacity		kW	12.00			12.00	
		BTU/h	41000			41000	
		kcal/h	10320			10320	
Heating COP		W/W	4.74		3.44		
		kcal/h	4.08			2.96	
	Low temperature Ap	plication (W35)	Warmer	Avo	rage	Colder	
	Application	Climate	Wanner	Ave	lage	Colder	
	Pdesign	kW	12.0	12	2.0	14.0	
	Tbivalent / TOL	°C	2/2	-10 /	/ -10	-15 / -22	
	SCOP / ns	(W/W) / %	5.86 / 231	4.32	/ 170	4.08 / 160	
	Annual Consumption	kWh	2738	57	45	8460	
Heating ErP	Class		A++	A++		A++	
	Medium temperature A	pplication (W55)	Warmer	Average		Colder	
	Application	Climate	Warmer				
	Pdesign	kW	12.0	12	2.0	13.0	
	Tbivalent / TOL	°C	2/2	-10	/ -10	-15 / -22	
	SCOP / ns	(W/W) / %	4.02 / 158	3.32	/ 130	3.20 / 125	
	Annual Consumption	kWh	3990	74	66	10012	
	Class		A++	A-	++	A++	
Air Flow		m³/min (ft³/min)	Cooling: 93.3 (3290) Heating: 80.0 (2830)				
Refrigerant Control Device				Expansi	on Valve		
Refrigerant Oil		cm³		FV50S	(1200)		
Refrigerant (R410A)		kg (oz)		2.30 ((81.2)		
	GWP			20	88		
F-GAS	CO2eq (ton) (Prechar	ged / Maximum)		4.80)2 / -		
	Туре			Hermet	ic Motor		
Compressor	Motor Type			Brushless	(4-poles)		
	Rated Output	kW		4.	50		

	Item	Unit	Refrigerant System
	Туре		Propeller Fan
	Material		PP
Fan	Motor Type		DC (8-poles)
	Output Power	W	60
	Fan Speed	rpm	Cooling: 600 (Top), 640 (Bottom) Heating: 520 (Top), 560 (Bottom)
	Fin Material		Aluminium (Pre Coat)
Llast Evebanger	Fin Type		Corrugated Fin
Heat Exchanger	Row x Stage x FPI		2 x 51 x 19
	Size (W x H X L)	mm	903.7 x 1295.4 x 38.1

I	tem	Unit		Mono bloc Unit	
	Height	mm (inch)		1410 (55-1/2)	
Dimension	Width	mm (inch)	1283 (50-1/2)		
	Depth	mm (inch)	320 (12-19/32)		
Net Weight	·	kg (lbs)		151 (333)	
Neisslaud		Condition (Ambient/Water)	A35W7	A7W35	A2W35
Noise Level		dB(A)	Cooling: 50	Heating: 52	-
		Power level dB	Cooling: 68	Heating: 69	-
		Ø		Three	
Power Source (Phase, Volt	age, Cycle)	V	400		
		Hz	50		
Input Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35
		kW	Cooling: 3.56	Heating: 2.53	Heating: 3.49
Maximum Input Power for I	Heatpump System	kW		7.96k	
Power Supply 1 : Phase (Ø) / Max. Current (A) / Max. Inp	out Power (W)		3Ø / 11.9 / 7.96k	
Power Supply 2 : Phase (Ø) / Max. Current (A) / Max. Inp	out Power (W)		3Ø / 13.0 / 9.00k	
Power Supply 3 : Phase (Ø) / Max. Current (A) / Max. Inp	out Power (W)		-/-/-	
Starting current		A		5.3	
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35
		А	Cooling: 5.3	Heating: 4.0	Heating: 5.3
Maximum Current for Heat	pump System	A		11.9	
Power Factor Power factor means total fi	gure of compressor and	Condition (Ambient/Water)	A35W7	A7W35	A2W35
outdoor fan motor.		%	Cooling: 97	Heating: 92	Heating: 95
David Octob	Number of core			-	•
Power Cord	Length	m (ft)		-	
Thermostat	•			Electronic Control	
Protection Device				Electronic Control	

	Item	Unit	Water System
Performance Test Cond	ition		EN14511
POS (EAN)			5025232874361
	Outdoor Ambient	°C (min. / max.)	Cooling: 16 / 43 Heating: -20 / 35
Operation Range	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating : 20 / 55 (Below Ambient -15°C) 20 / 60 (Above Ambient -10°C)
Internal Pressure Differe	ential	kPa	Cooling: 36 Heating: 50
Water Ding Diameter	Inlet	inch	1-1/4
Water Pipe Diameter	Outlet	inch	1-1/4
Water Drain Hose Inner	Diameter	mm (inch)	15.00 (19/32)
Dump	Motor Type		DC Motor
Pump	Input Power	W	79
	Туре		Brazed Plate
	No. of Plates		36
Hot Water Coil	Size (H x W x L)	mm	65 x 120 x 376
	Water Flow Rate	l/min (m³/h)	Cooling: 28.7 (1.7) Heating: 34.4 (2.1)
Pressure Relief Valve W	ater Circuit	kPa	Open: 300, Close: 266 and below
Flow Switch	Туре		Electronic Sensor
Protection Device		A	Residual Current Circuit Breaker (25)
	Volume	I I	10
Expansion Vessel	MWP	bar	3
Capacity of Integrated E	lectric Heater	kW / °C	9.00

Note:

• Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled indoor water inlet temperature of 12°C and water outlet temperature of 7°C.

Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled indoor water inlet temperature of 30°C and water outlet temperature of 35°C.

• Specification are subjected to change without prior notice for further improvement.

 Flow rate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and =5°C

2.3 WH-MXC16H9E8

lt	em	Unit		Refrigerar	nt System	
Performance Test Condition	1		EN 14511			
POS (EAN)			5025232874385			
		Condition (Ambient/Water)	A35W7			
Cooling Capacity		kW	12.20			
		BTU/h	41600			
		kcal/h		104	190	
		W/W		2.5	56	
Cooling EER		kcal/h		2.2	20	
		Condition (Ambient/Water)	A7W35			A2W35
Heating Capacity		kW	16.00			16.00
		BTU/h	54600			54600
		kcal/h	13760			13760
		W/W	4.28			3.10
Heating COP		kcal/h	3.68		2.67	
	Low temperature Ap	plication (W35)		A		Qaldar
	Application	Climate	Warmer	Aver	age	Colder
	Pdesign	kW	16.0	16	.0	19.0
	Tbivalent / TOL	°C	2/2	-10 /	-10	-15 / -22
	SCOP / ns	(W/W) / %	5.86 / 231	4.08 /	/ 160	3.83 / 150
	Annual Consumption	kWh	3650	810	07	12233
Heating ErP	Class		A++	A+	++	A++
	Medium temperature A	Application (W55)	Warmer	Average		Colder
	Application	Climate	wanner	Aver	aye	Colder
	Pdesign	kW	16.0	16	.0	18.0
	Tbivalent / TOL	°C	2/2	-10 /	-10	-15 / -22
	SCOP / ns	(W/W) / %	4.05 / 159	3.20 /	/ 125	3.20 / 125
	Annual Consumption	kWh	5280	103	330	13870
	Class		A++	A+	++	A++
Air Flow		m³/min (ft³/min)	Cooling: 109.4 (3860) Heating: 76.0 (2680)			
Refrigerant Control Device				Expansio	on Valve	
Refrigerant Oil		cm³		FV50S	(1600)	
Refrigerant (R410A)		kg (oz)		2.35	(83)	
F-GAS	GWP			208	88	
	CO2eq (ton) (Prechar	ged / Maximum)		4.90	7/-	
	Туре			Hermeti	c Motor	
Compressor	Motor Type			Brushless	(4-poles)	
	Rated Output	kW		4.6	60	

ŀ	em	Unit	Refrigerant System
	Туре		Propeller Fan
	Material		PP
Fan	Motor Type		DC (8-poles)
	Output Power	W	60
	Fan Speed	rpm	Cooling: 680 (Top), 720 (Bottom) Heating: 580 (Top), 620 (Bottom)
	Fin Material		Aluminium (Pre Coat)
Heat Exchanger	Fin Type		Corrugated Fin
	Row x Stage x FPI		2 x 51 x 19
	Size (W x H X L)	mm	898.8 x 1295.4 x 44

	tem	Unit		Mono bloc Unit			
	Height	mm (inch)		1410 (55-1/2)			
Dimension	Width	mm (inch)	1283 (50-1/2)				
	Depth	mm (inch)	320 (12-19/32)				
Net Weight		kg (lbs)		164 (362)			
		Condition (Ambient/Water)	A35W7	A7W35	A2W35		
Noise Level		dB(A)	Cooling: 54	Heating: 55	-		
		Power level dB	Cooling: 71	Heating: 72	-		
		Ø	Three				
Power Source (Phase, Vol	tage, Cycle)	V	400				
		Hz	50				
Input Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35		
		kW	Cooling: 4.76	Heating: 3.74	Heating: 5.16		
Maximum Input Power for I	Heatpump System	kW		10.48k	·		
Power Supply 1 : Phase (Ø	ð) / Max. Current (A) / Max. In	put Power (W)		3Ø / 15.5 / 10.48k			
Power Supply 2 : Phase (Ø	ð) / Max. Current (A) / Max. In	put Power (W)	3Ø / 13.0 / 9.00k				
Power Supply 3 : Phase (Ø	ð) / Max. Current (A) / Max. In	put Power (W)		-/-/-			
Starting current		A	7.1				
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35		
		А	Cooling: 7.1	Heating: 5.7	Heating: 7.9		
Maximum Current for Heat	pump System	A		15.5			
Power Factor Power factor means total fi	gure of compressor and	Condition (Ambient/Water)	A35W7	A7W35	A2W35		
outdoor fan motor.		%	Cooling: 98	Heating: 96	Heating: 95		
Dewer Card	Number of core			-	•		
Power Cord	Length	m (ft)		-			
Thermostat	•		Electronic Control				
Protection Device				Electronic Control			

	ltem	Unit	Water System
Performance Test Condi	tion		EN14511
POS (EAN)			5025232874385
	Outdoor Ambient	°C (min. / max.)	Cooling: 16 / 43 Heating: -20 / 35
Operation Range	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating : 20 / 55 (Below Ambient -15°C) 20 / 60 (Above Ambient -10°C)
Internal Pressure Differe	ntial	kPa	Cooling: 50 Heating: 84
	Inlet	inch	1-1/4
Water Pipe Diameter	Outlet	inch	1-1/4
Water Drain Hose Inner	Diameter	mm (inch)	15.00 (19/32)
Duran	Motor Type		DC Motor
Pump	Input Power	W	143
	Туре		Brazed Plate
	No. of Plates		52
Hot Water Coil	Size (H x W x L)	mm	93 x 120 x 375
	Water Flow Rate	l/min (m³/h)	Cooling: 35.0 (2.1) Heating: 45.9 (2.8)
Pressure Relief Valve W	ater Circuit	kPa	Open: 300, Close: 266 and below
Flow Switch	Туре		Electronic Sensor
Protection Device		A	Residual Current Circuit Breaker (25)
	Volume	I I	10
Expansion Vessel	MWP	bar	3
Capacity of Integrated E	lectric Heater	kW / °C	9.00

Note:

- Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled indoor water inlet temperature of 12°C and water outlet temperature of 7°C.
- Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled indoor water inlet temperature of 30°C and water outlet temperature of 35°C.
- Specification are subjected to change without prior notice for further improvement.
- Flow rate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and =5°C

3. Features

- **Inverter Technology** - Energy saving
- **High Efficiency** •
- **Compact Design** •
- **Environment Protection** .
 - Non-ozone depletion substances refrigerant (R410A)
- Easy to use control panel
- Weekly Timer setting

Quality Improvement

- Random auto restart after power failure for safety restart operation
- Gas leakage protection
- Prevent compressor reverse cycle
- Inner protector to protect compressor

•

- Serviceability Improvement Breakdown Self Diagnosis function
 - System Status Check Buttons for servicing purpose
 System Pumpdown Button for servicing purpose

 - Front maintenance design for outdoor unit

Operation Condition •


		*1.0001.010
For H (series)	HEATING	* ¹ COOLING
Water outlet temperature (°C) (Min. / Max.)	20 / 55 (Below Ambient -15°C) * ³ 20 / 60 (Above Ambient -10°C) * ³	5 / 20
Outdoor ambient temperature (°C) (Min. / Max.)	-20 / 35	16 / 43


NOTICE : When the outdoor temperature is out of the above temperature range, the heating capacity will drop significantly and outdoor unit might stop for protection control.

4. Location of Controls and Components

4.1 Indoor Unit

4.1.1 Remote Controller buttons and display





4.1.2 Initialization

Before starting to install the various menu settings, please initiate the Remote Controller by selecting the language of operation and installing the date and time correctly.

It is recommended that the installer conducts the following initialization of the Remote Controller.

Selecting the language

Press _____ and wait while the display is initializing.

- (1) Scroll with ∇ and \triangle to select the language.

Setting the clock

- Select with ▼ or ▲ how to display the time, either 24h or am/pm format (for example, 15:00 or 3 pm).
- ② Press ← to confirm the selection.
- ③ Use ▼ and ▲ to select year, month, day, hour and minutes. (Press ← to confirm the selection each time.)
- Once the time is set, time and day will appear on the display even if the Remote Controller is turned OFF.

Initialization	12:00am,Mor	
Initializi	ng	
Language	12:00am, Mor	
ENGLISH		
FRANÇAIS		
DEUTSCH		
ITALIANO		
Felect [+-]	Confirm	
Clock format	12:00am, Mon	
24h		
▼ am/p	m	
-Select [+-]	Confirm	
Date & Tima	12:00em, Mon	
Year/Month/Day	Haur : Min	
2015 / 01 / 07	10:00 am	
() Select	[₊-]Contirm	
	10:00em, Wed	
(ð) Start		


4.1.3 Quick Menu

After the initial settings have been completed, you can select a quick menu from the following options and edit the setting.

1 Press to display the quick menu.



Powerful



③ Press to turn on/off the select menu.

4.1.4 Menus For user

Select menus and determine settings according to the system available in the household. All initial settings must be done by an authorised dealer or a specialist. It is recommended that all alterations of the initial settings are also done by an authorised dealer or a specialist.


• After initial installation, you may manually adjust the settings.

- The initial setting remains active until the user changes it.
- The Remote Controller can be used for multiple installations.
- Ensure the operation indicator is OFF before setting.
- The system may not work properly if set wrongly. Please consult an authorised dealer.

To display <Main Menu>: ⋮≡

To select menu: 🛦 🔻 ৰ 🕨

To confirm the selected content:



Menu	Default Setting	Setting Options /	Display
1 Function setup 1.1 > Weekly timer			
Once the weekly timer is set up, User can edit from Quick Menu. To set up to 6 patterns of	set the par	of the week and tterns needed on ON/OFF / Mode)	Weekly timer 10:34am, Mon Sun Mon Tue Wed Thu Fri Sat 1. 8:00am ON ⊯ 40°C
 operation on a weekly basis. Disabled if Heat-Cool SW is pressed or if Force Heater is on. 	Timer copy Select da	y of the week	2. 12:00pm ON ¥ 24/28°C 40°C 3. 1:00pm ON ¥ 12/10°C ↔Day →Pattern [+-]Edit

Default Setting Setting	9 0	ptions		plav
---------------------------	-----	--------	--	------

1.2	> Holiday timer		-		
	To save energy, a holiday period may be set to either turn	OFF			
	OFF the system or lower the	> ON			
	temperature during the period.		tart and end. and time	Holiday: End Year/Month/Day	19:34am, Mon Hour : Min
		OFF or lowe	red temperature	2015/01/07	1D:00 am
	 Weekly timer setting may be ter but it will be restored once the h 				[]Conlinu
1.3	> Quiet timer				
	To operate quietly during the preset period. 6 patterns may be set.		start Quiet : and time		0 am 0
	Level 0 means the mode is off.		f quietness:) ~ 3	2 5:00 3 11:00 ↓Select [+-]	•
1.4	> Room heater				
	To set the room heater ON or OFF.	OFF			
1.5	> Tank heater		I		
	To set the tank heater ON or OFF.	OFF			
	Available only if connected to the	ne tank.	1		
1.6	> Sterilization				
	To set the auto sterilization ON or OFF.	OFF		CN A CF=	
	 Available only if connected to the Do not use the system during state. Ask an authorised dealer to detain regulations. 	terilization in order to pr	revent scalding with hot wate ilization function field setting	er, or overheating o is according to the l	f shower. ocal laws and
2	System check				
2.1	> Energy monitor				
	Present or historical chart	Present			
	of energy consumption,		and retrieve	Total consumption	(1year)
	generation or COP.	Historical chart	and retrieve	kWh_	
	 COP= Coefficient of Performant For historical chart, the period is Energy consumption (kWh) of here The total power consumption is differ from value measured by performance 	ce. s selected from 1 day/1 ating, *1 cooling, tank and an estimated value bas	week/1year. I total may be retrieved.	tivear 112131415161 Jan, 2015: 0.0 ↔Month \$Mode	7 <u>891011112</u> 0000 0 kWh Approx.
2.2	> Water temperatures	I			
	Shows all water temperatures in each area.	tank / Solar / Pool	ature of 8 items: / Zone 2 / Tank / Buffer and retrieve	Water temperatures 1. Inlet 2. Outlet 3. Zone 1 4. Zone 2 vPage	<u>10:34am, Mon</u> : 0°C : 0°C : 0°C : 0°C
1	he system is locked to operate without Only displayed when COOL mode is un			ers or our authorised se	erviceaptners.

Me	enu	Default Setting	Setting Options	/ Display	
2.3	> Error history				
	 Refer to Troubleshooting for error codes. The most recent error code is displayed at the top. 	Select a	and retrieve	Frran history 1 2 3 4 [.]Clear history	10:34am, Mnn
2.4	> Compressor	1			
	Shows the compressor performance.	Select a	and retrieve	Compressor 1. Current frequen 2. (OFF-ON) counte 3. Total ON time [_]Back	
2.5	> Heater	1			
	Total hours of ON time for Room heater/Tank heater.	Select a	and retrieve	Heater Total ON time ऄॖऀऻऻ ऄॖऀॴऀ [⊅]Back	10:34am, Mon : Oh : Oh
3	Dereand actum				
<u> </u>	Personal setup > Touch sound				
5.1	Turns the operation sound ON/OFF.	ON		ON OFF	
3.2	> LCD contrast	1			
	Sets the screen contrast.	3		Low	14k3¥lam, Mnn High ∎ ►
3.3	> Backlight	I	I		
	Sets the duration of screen backlight.	1 min		Barklight OFF 15 secs 1 min *S el eul L-J	14k34am, Man 5 mins 10 mins Continu
3.4	> Backlight intensity	1			
	Sets screen backlight brightness.	4		Barklight intensity Dark I Select (+-)	14k3Mam, Mnn Hright Coufirm
3.5	> Clock format	I	I		
	Sets the type of clock display.	24h		Clock format	

Me	enu	Default Setting	Setting Options /	/ Display	
3.6	> Date & Time				
	Sets the present date and time.	Year / Month /	/ Day / Hour / Min	Date & Lime Year/Month/Day P	10:34am, Mni Hour : Min 10 : 00 am [++]Confirm
3.7	> Language				
	Sets the display language for the top screen. • For Greek, please refer to the English version.	DEUTSCH ESPAÑOI SWEDISH / POLISH NEDERLAN SUOMI /	/ FRANÇAIS / / ITALIANO / _ / DANISH / NORWEGIAN / / CZECH / DS / TÜRKÇE / 'MAGYAR / NA / HRVATSKI	Language ENGLISH FRANÇAIS DEUTSCH ITALIANO Select [+-]	10:34am, Moi IConfirm
3.8	> Unlock password				
	4 digit password for all the settings.	0000		Ŧ	10:34am, Mor
				‡5elert [⊷)	Confirm
4	Service contact				
4.1	> Contact 1 / Contact 2				
	Preset contact number for installer.	Select a	and retrieve	Service schup Contect 1 Name : Bayan A T: 0681234 "Seleul	

4.1.5 Menus For installer

Menu	Default Setting	Setting Options / Dis	splay	
5 Installer setup > System	n setun			
5.1 > Optional PCB connecti	•			
To connect to the external P required for servicing.			Yes A No	
 Control over 2 zones (n and control over its functio (including the swimming poo ar thermal panels connecte	n and temperature.	vater in it).	ik or the Buffer Tank.
5.2 > Zone & Sensor				
To select the sensors and to select either 1 zone or 2 zor system.	• After selecting 1 or 2	e selected for	Zone & Sensor Zone 1 Zone 2 Zones "Select [.+	
	* For room thermosta selection of external	t, there is a further	Zone & Sensor Sensor Waterium Room the Room the	rmostat
5.3 > Heater capacity				
To reduce the heater power unnecessary.* 3 kW / 6 kW / 9 kW * Options of kW vary		6 kW / 9 kW	Heater capacity 3 k 6 k 9 k	w
depending on the model.			[▲] Select [+]Confirm
5.4 > Anti freezing				
To activate or deactivate the water freeze prevention whe the system is OFF.			Yta Nu	
5.5 > Tank connection				
To connect tank to the syste	m. No		Yes ▲ No	
5.6 > Buffer tank connection	-	1		
To connect tank to the syste and if selected YES, to set ∆T temperature.	m No		Yes No	
The optional PCB				
connectivity must be selec YES to enable the function • If the optional PCB connectivity is not selected the function will not appea on the display.	n. J, 5 °C	Set ∆T for Buffer Tank	Buffer Tank <u>∆T for Buffer Tan</u> Range: (0°C~10°C) Steps: ±1°C \$Select [-	

5.7	> Tank heater				
	To select external or internal tank heater and if External is selected, set a timer for the heater to come on. * This option is available if	Internal			10:34am,Mon sternal format
	Tank connection is selected (YES).	> External	<u> </u>		
	(123).	0:20	Tank heater ON time set.	Lank heater Tank heater: Of Range: (0:20-3 Steps: J0:05	
5.8	> Base pan heater				
	To select whether or not optional base pan heater is connected.	No			Yes ▲ No
		> Yes			
* Туре	 * Type A - The base pan heater activates only during deice operation. * Type B - The base pan heater activates when outdoor ambient temperature is 5 °C or lower. 	A	Set base pan heater type*.	Hase part heater	r type: 10:34am,Man ▼ B [-]Confirm
5.9	> Alternative outdoor sensor				
	To select an alternative outdoor sensor.	No			Yes No
5.10	> Bivalent connection	I			
	To select a bivalent connection to allow an additional heat	No			Yes ▲ No
	source such as a boiler to	> Yes			
	heat-up the buffer tank and domestic hot water tank when heatpump capacity is insufficient at low outdoor temperature. The bivalent feature can be set-up either in	-5 °C	Set outdoor temperature for turn ON Bivalent connection.	Bivalent connect Turn ON: Outdoo Range: (-15°C~3 Steps: ±1°C \$Select	or temp.
	alternative mode (heatpump	Yes > After selecting	the outdoor temperature	e	
	and boiler operate alternately), or in parallel mode (both	Control pattern			
	heatpump and boiler operate	Alternative / Paral	lel /Advanced parallel	Bivalent connect	ion 10:39am, Mon
	simultaneously), or in advance parallel mode (heatpump operates and boiler turns on for buffer-tank and/or domestic hot water depending on the control pattern setting options).	Select advanced par the tanks.	allel for bivalent use of	Pa Advano	mative raliei ni paraliei [+-] Confirm

Default Setting Setting Options / Display

	Ivanced parallel	
Heat	Selection of the tank	Bivalent connection _ 10:30am, K Advanced parallel
"Heat" implies Buffer Domestic Hot Water	Tank and "DHW" implies Tank.	l leat DHW
		çelect [بار] Confirm
Control pattern > Ac	lvanced parallel > Heat > `	Yes
		Bivalent connection = 10:30am, M
• Buffer Tank is activat "Yes".	ted only after selecting	Advanced parallel: Heat V39 ND
		"Select [+-] Confirm
	Cat the terms are ture	Bivalent connection 10:34am, M Heat start: Target temp.
-8 °C	Set the temperature threshold to start the bivalent heat source.	Range: (-10°C~0°C) Steps: ±1°C
		\$Select [₊-]Confirm
		Bivalent connection 10:34am,6
0:30	Delay timer to start the bivalent heat source (in hour and minutes).	Heat start: Delay time Range: (0:0D~1:30) Steps: 40:05
		Select [+]Confirm
	Cat the temperature	Bivalent connection 10:34am, M Heat stop: Target temp.
-2 °C	Set the temperature threshold to stop the bivalent heat source.	Range: (-10°C~0°C) Steps: ±1°C -2 ▼
		\$Select [₊-]Confirm
0:30	Delay timer to stop the bivalent heat source	Hivalent connection 10:34am,K Heat stop: Belay time Hange: (0:00–1:30)
	(in hour and minutes).	Steps: ±0:05
		‡9elest [₊J]Conlirun
Control pattern > Ac	Ivanced parallel > DHW >	
• DHW Tank is activate "Yes".	ed only after selecting	Bivalent connection = 10:34am,4 Advanced parallel: DHW V39 ND
		Select [,] Confirm
0:30	Delay timer to start the bivalent heat source (in hour and minutes).	Bivalent connection 10:34am, N DHW: Delay time Range: (0:30~1:30) Steps: ±0:05
	(in nour and minutes).	•

1111	(-1a	11
		1.

Default Setting	Setting O	ptions /	Display
-----------------	-----------	----------	---------

5.11 > External SW				
	No		Yes ▲ No	
5.12 > Solar connection				
The optional PCB connectivity must be selected	No		Yes ▲ No	
YES to enable the function.	> Yes			
 If the optional PCB connectivity is not selected, the function will not appear on the display. 	Buffer tank	Selection of the tank	Solar connection Buffer to DHW ta	
			_Select [+-]	Confirm
	> Yes > After selecti	na the tank	◆2elect [+-]	comm
	10 °C	Set \triangle T ON temperature	Solar connection △T Turn ON Range: (6°C~15°C) Steps: ±1°C	10:34am, Mon
				Confirm
	5 °C	ng the tank > △T ON temp Set △T OFF temperature	Solar connection ∆T Turn OFF Range: (2°C~9°C) Steps: ±1°C	10:34am, Mon
	> Ves > After selecti	∣ ng the tank >	•	
	5 °C	Set Antifreeze temperature	Solar connection Anti freeze Range: (-20°C~10°C) Steps: ±1°C	10:34am, Mon
	Select []Confirm Yes > After selecting the tank > △T ON temperature > △T OFF temperature After setting the antifreeze temperature			
	80 °C	Set Hi limit	Solar connection Hi limit Hange: (70°C-90°C) Steps: ±5°C	10:34am, Mnn ap 'c Coufirm

Menu	Default Setting	Setting Options / Di	splay	
5.13 > External error signal				
	No		Yes ▲ No	
5.14 > Demand control	1	1		
	No		Yes ▲ No	
5.15 > SG ready	1	1		
	No		Yes No	
	> Yes	1		
	120 %	Capacity (1) & (2) of Buffer Tank and DHW Tank (in %)	SC ready Capacity [1-0]: DHW Range: (50%-150% Steps: ±5%	
EAG > Estemates anno 200			\$Select [~]	Confirm
5.16 > External compressor SW	1		Yes	
	No		No	
5.17 > Circulation liquid	1	1		
To select whether to circulate water or glycol in the system.	Water		Circulation liquid Wate Ciyor	
			-Select [+-]	Confirm
5.18 > Heat-Cool SW	1	1		
	No		Yes A No	
5.19 > Force heater				_
To turn on Force heater either manually (by default) or automatically.	Manual		Force heater Auto Manu	
			^Select [+-]	Confirm
6 Installer setup > Operation :	•		Operation when	1 Million Mar
To access to the four major functions or modes.		in modes Cool / Auto / Tank	Operation setup Host Coul Auto Tank _Select [++]	125KDam, Mon Confirm

*1	The system is locked to operate without COQ mode. It can be unlocked only by authorised installers or our authorised service prtners.
*2	Only displayed when COOL mode is unlocked (This means when COOL mode is available).

ļ

Inst	taller setup > Operation setu	lb			
6.1	> Heat	•			
	To set various water & ambient temperatures for heating.	Water temp. for heating ON / Outdoor temp. for heating OFF / △T for heating ON / Outdoor temp. for heater ON > Water temp. for heating ON		Operation setup Heat Water temps for h Outdoor temps for All for heating O , Select [-	r heating OFF
		Compensation curve	Heating ON temperatures in compensation curve or direct input.	Operation setup Heat ON: Water te Componen Din	tion curva
		Water temp for be	oting ON > Companyation		
		> Water temp. for heating ON > Compensatio		Heat ON: Water te	mn :7one1
		X axis: -5 °C, 15 °C Y axis: 55 °C, 35 °C	Input the 4 temperature points (2 on horizontal X axis, 2 on vertical Y axis).	55°C ⁶⁰ 35°C ₂₀ -15 -5°C	15°C 15
		Temperature range f 1. WH-MDC model 2. WH-MXC model If 2 zone system is s		s on the model: points must also be	
		> Water temp. for he	ating ON > Direct		
		35 °C	Temperature for heating ON	Operation setup Heat ON: Water te Range: (20°C~60°C Steps: ±1°C	
				\$Select [+]Confirm
		• Min. ~ Max. range is 1. WH-MDC model 2. WH-MXC model			
		> Outdoor temp. for heating OFF			
		24 °C	Temperature for heating OFF	Operation setup Heat OFF: Outdoor Range: (5°C~35°C) Steps: ±1°C	
				\$Select [+]Confirm

Menu	Default Setting	Setting Options / Dis	splay	
	> △T for heating ON			
	5 °C	Set ∆T for heating ON.	Operation setup Heat ON: ΔT Range: (1°C~15°C) Steps: ±1°C \$Select	10:34am, Mon
	> Outdoor temp. for	r heater ON		
	0 °C	Temperature for heater ON	Operation setup Heater ON: Outdoo Range: (-15°C~20°C Steps: ±1°C	
6.2 > *1, *2 Cool			◆2ciect [+-]	Commin
To set various water & ambient temperatures for cooling.	Water temperatures for cooling ON and △T for cooling ON.		Operation setup Cool Water temps for co AT for cooling ON . Select	14k3Mam, Mnn alling GN Continn
	> Water temp. for co	oling ON	+ Jeacon Carl	Commun
	Compensation curve	Cooling ON temperatures in compensation curve or direct input.	Operation setup Cool ON: Water ten Componist Dire	on curva
	> Water temp. for cooling ON > Compensation curve			
	X axis: 20 °C, 30 °C Y axis: 15 °C, 10 °C	Input the 4 temperature points (2 on horizontal X axis, 2 on vertical Y axis)	Cool ON: Water ten 15℃ ²⁰ 10℃ 5 15 20℃ ↓ Select [+-]	30°C 30 Confirm
	• If 2 zone system is selected, the 4 temperature points must also be input for Zone			
	• "Zone 1" and "Zone 2" will not appear on the display if only 1 zone system.			
	> Water temp. for co	oling ON > Direct		
	10 °C	Set temperature for Cooling ON	Operation setup Cool ON: Water ten Range: (5°C~20°C) Steps: ±1°C	10:34am, Mon np.:Zone2
	> △T for cooling ON	<u> </u>		
	5 °C	Set $\triangle T$ for cooling ON	Operation setup Cool ON: ΔT Range: (1°C~15°C) Steps: ±1°C	10:34am, Mon
			\$Select [₊]	Confirm

*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
 *2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

Automatic switch from Heat to Cool or Cool to Heat. Outdoor temperatures for switching from Heat to Cool or Cool to Heat. Operation setup 1scstam, March Auto Outdoor temp. for (Heat to Cool) / Outdoor temp. for (Cool to Heat) Operation setup 10:34am, March Auto:Outdoor temp. for (Cool to Heat) >Outdoor temp. for (Heat to Cool) Operation setup 10:34am, March Auto:Outdoor temp. for (Heat to Cool) >Outdoor temp. for (Cool to Heat) Operation setup 10:34am, March Auto:Outdoor temp. for (Cool to Heat) 0 °C Set outdoor temperature for switching from Cool to Heat. Operation setup 10:34am, March Auto:Outdoor temp. for (Cool to Heat) 0 °C Set outdoor temperature for switching from Cool to Heat. Operation setup 10:34am, March Auto:Outdoor temp. for (Cool to Heat) 6.4 > Tank Floor operation time (max) / Tank re-heat temp. / Sterilization Operation setup 10:34am, March Auto:Outdoor temp. for (Cool to Heat) 0 Floor operation time (max) / Tank re-heat temp. / Sterilization Tank re-heat temp. / Sterilization Operation setup 10:34am, March Auto:Outdoor setup • The display will show 3 functions at a time. > Floor operation time (max) / Tank re-heat temp. Tank heat up time (max) Pare: (0:30:-000) Steps: 10:05 Tank-floor operation setup 10:34am, Marche Tank-floor operation setup 10:34am, Marche Tank-floor operation setup<	Ме	nu	Default Setting	Setting Options / Dis	play		
Cool or Cool to Heat. to Cool or Cool to Heat. Auta Outdoor temp. for (Heat to Cool) / Outdoor temp. for (Cool to Heat) Childrar temp. for (Cool to Heat) Set outdoor temp. for (Cool to Heat) > Outdoor temp. for (Cool to Heat) Set outdoor temp. for (Cool to Heat) Operation setup 10:34am, M Auto:Outdoor temp. (Cool to Heat) > Outdoor temp. for (Cool to Heat) Set outdoor temperature for switching from Heat to Cool Operation setup 10:34am, M Auto:Outdoor temp. (Cool to Heat) 10 °C Set outdoor temperature for switching from Cool to Heat. Operation setup 10:34am, M Auto:Outdoor temp. (Cool to Heat) 6.4 > Tank Set outdoor temp. for (Cool to Heat) Operation setup 10:34am, M Auto:Outdoor temp. (Cool to Heat) 6.4 > Tank Floor operation time (max) / Tank re-heat temp. / Sterilization Operation setup 10:34am, M Auto:Outdoor temp. (Cool to Heat) 6.4 > Tank Floor operation time (max) / Tank re-heat temp. / Sterilization Operation setup 10:34am, M Tank: Floor operation time (max) • The display will show 3 functions at a time. > Floor operation time (max) Operation setup 10:34am, M Tank:Floor oper. (Cool to Floor) (In hours and minutes) Operation setup 10:34am, M Tank:Floor oper. time (max) Range: (10:05-4:00) Steps: 50:05 • Tank heat up time (max) 1:00 Maximum time for heating the tank (In hours and minutes) Operation setup 10:34am, M Tank:Fl	6.3	> Auto					
Outdoor temp. for (Heat to Cool) / Outdoor temp. for (Cool to Heat) Candinar temp. for (Cool to Heat) > Outdoor temp. for (Heat to Cool) Operation setup 10:34am, Mitcloud temp. (Heat to Cool) 15 °C Set outdoor temperature for switching from Heat to Cool Operation setup 10:34am, Mitcloud tempe. (Heat to Cool Range: (11 ^C -25 ^C) > Outdoor temp. for (Cool to Heat) Operation setup 10:34am, Mitcloud temperature for switching from Cool to Heat. Operation setup 10:34am, Mitcloud temperature for switching from Cool to Heat. 6.4 > Tank Seting functions for the tank. Floor operation time (max) / Tank heat up time (max) Operation setup 10:34am, Mitcloud teme for switching from Cool to Heat. * Available only if connected to the tank. Floor operation time (max) / Tank heat up time (max) / Tank heat up time (max) Operation setup 10:34am, Mitclout head for 000 setup				Auto	10:3Mam, Mor		
Auditable only if connected to the tank. Available only i					Outdoor temp. for (Cool to Heat)		
6.4 > Tank 6.4 > Tank Seting functions for the tank. * Outdoor temp. for (Cool to Heat) • Available only if connected to the tank. * Floor operation time (max) / Tank heat up time (max) / Tank heat up time (max) / Stenilization • Tank heat up time (max) • Select • Tank heat up time (max) • Select • Tank heat up time (max) • Tank heat up time (max) • Select • Tank heat up time (max) • Select • Tank heat up time (max) • Select					Select [با] د	bulin	
15 °C Set outdoor temperature for switching from Heat to Cool. Auto:Outdoor temp. (Heat to Cool. Range: (11°C-25°C) steps: ±1°C > Outdoor temp. for (Cool to Heat) Set outdoor temperature for switching from Cool to Heat. Operation setup 10:34am, Mi Steps: ±1°C 10 °C Set outdoor temperature for switching from Cool to Heat. Operation setup 10:34am, Mi Steps: ±1°C Setting functions for the tank. Floor operation time (max) / Tank heat up time (max) / Tank heat up time (max) / Tank re-heat temp. / Sterilization Operation setup 10:34am, Mi Tank re-heat temp. / Steps: ±1°C • Available only if connected to the tank. Floor operation time (max) / Tank ne-heat temp. / Sterilization Operation setup 10:34am, Mi Tank re-heat temp. / Sterilization • The display will show 3 functions at a time. > Floor operation time (max) Operation setup 10:34am, Mi Tank:Floor ope. time (max) / Tank:Floor ope. time (max) 8:00 Maximum time for floor operation time (max) Tank:Floor ope. time (max) / Tank:Floor ope. time (max) 1:00 Maximum time for heating the tank (in hours and minutes) Operation setup 10:34am, Mi Tank:Floor ope. time (max) > Tank nee-heat temp. Set temperature to perform reboil of tank water. Operation setup 10:34am, Mi Tank:Floor ope. time (max) Attribute operation temp. Set temperature to perform reboil of tank water. Operation setup 10:34am, Mi Tank:Floor ope. time (max)			> Outdoor temp. for	(Heat to Cool)			
> Outdoor temp. for for (Cool to Heat) Operation setup 10:34am, Mr Auto:OutGoor temp. (Cool to Heat) 10 °C Set outdoor temperature for switching from Cool to Heat. Operation setup 10:34am, Mr Auto:OutGoor temp. (Cool to Heat) 6.4 > Tank Setting functions for the tank. Floor operation time (max) / Tank heat up time (max) / Tank re-heat temp. / Sterilization Operation setup 10:34am, Mr Auto:OutGoor temp. (Cool to Heat) • Available only if connected to the tank. Floor operation time (max) / Tank re-heat temp. / Sterilization Operation setup 10:34am, Mr I ank re-heat temp. - Setect • The display will show 3 functions at a time. > Floor operation time (max) Operation setup 10:34am, Mr Tank:Floor ope. time (max) Range: (0:30-10:00) Step: ±0:30 Step: Step: ±0:30 </td <td></td> <td></td> <td>15 °C</td> <td>for switching</td> <td>Auto:Outdoor temp. Range: (11°C~25°C) Steps: ±1°C</td> <td>15 °C</td>			15 °C	for switching	Auto:Outdoor temp. Range: (11°C~25°C) Steps: ±1°C	15 °C	
10 °C Set outdoor temperature for switching from Cool to Heat. Operation setup 10:34am, MA Auto:Outdoor temp.(Cool to Heat Range: (5 [°] C-14 [°] C) steps: ±1°C 6.4 > Tank Setting functions for the tank. Floor operation time (max) / Tank heat up time (max) Operation tane (max) / Tank heat up time (max) / Tank heat up time (max) / Tank heat up time (max) • Available only if connected to the tank. Floor operation time (max) / Tank heat up time (max) / Tank heat up time (max) Operation tane (max) / Tank heat up time (max) • The display will show 3 functions at a time. > Floor operation time (max) Operation setup 10:34am, Mr Tank heat up time (max) 8:00 Maximum time for floor operation time (max) Operation setup 10:34am, Mr Tank:Floor ope. time (max) > Tank heat up time (max) Tank:Floor ope. time (max) Operation setup 10:34am, Mr Tank:Heat up time (max) > Tank heat up time (max) Tank:Heat up time (max) Tank:Heat up time (max) Tank:Heat up time (max) > Tank heat up time (max) Set temperature to perform reboil of tank (in hours and minutes) Operation setup 10:34am, Mr Tank:Heat temp. <t< td=""><td></td><td></td><td></td><td></td><td>ÇSelect [₊-]C</td><td>onfirm</td></t<>					ÇSelect [₊-]C	onfirm	
10 °C Set outdoor temperature for switching from Cool to Heat. Auto:Outdoor tempe.(Cool to Heat. 6.4 > Tank Setting functions for the tank. * Available only if connected to the tank. Floor operation time (max) / Tank heat up time (max) • The display will show 3 functions at a time. > Floor operation time (max) • The display will show 3 functions at a time. > Floor operation time (max) • The display will show 3 functions at a time. > Floor operation time (max) • Tank heat up time (max) Qperation setup 10:34am, Mr Tank:Floor oper time (max) 8:00 Maximum time for floor operation gene time (max) 1:00 Maximum time for heating the tank (in hours and minutes) • Tank re-heat temp. Operation setup 10:34am, Mr Tank:Fleat up time (max) • Tank re-heat temp. Set temperature to perform reboil of tank water.			> Outdoor temp. for	(Cool to Heat)			
6.4 > Tank Setting functions for the tank. • Available only if connected to the tank. • The display will show 3 functions at a time. • The display display the tank (in hours and minutes) • Tank heat up time (max) function for the tank (in hours and minutes) • Tank re-heat temp & °C • Set temperature to perform reboil of tank water. • The display display the tank (in the tank water. • The display display the tank (in the tank water. • Tank re-heat temp. • T			10 °C	for switching	Auto:Outdoor temp. Range: (5°C~14°C)	10:34am, Mor (Cool to Heat)	
Setting functions for the tank. Floor operation time (max) / Tank heat up time (max) / Tank heat up time (max) / Tank re-heat temp. / Sterilization Cpreation setup 10:34am, Mile (moor operation time (max)) • The display will show 3 functions at a time. > Floor operation time (max) • The display will show 3 functions at a time. > Floor operation time (max) • The display will show 3 functions at a time. > Floor operation time (max) • The display will show 3 functions at a time. > Floor operation time (max) • The display will show 3 functions at a time. > Floor operation time (max) • The display will show 3 functions at a time. > Floor operation time (max) • The display will show 3 functions at a time. > Floor operation time (max) • Tank heat up time (max) Maximum time for floor operation setup 10:34am, Mile • Tank heat up time (max) @ Operation setup 10:34am, Mile • Tank heat up time (max) @ Operation setup 10:34am, Mile 1:00 Maximum time for heating the tank (in hours and minutes) @ Operation setup 10:34am, Mile • Tank re-heat temp. Range: (0:05-4:00) \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$					\$Select [₊-]C	onfirm	
• Available only if connected to the tank. Floor operation time (max) / Tank heat up time (max) / Tank neat temp. / Sterilization I ank • The display will show 3 functions at a time. • The display will show 3 functions at a time. • Floor operation time (max) • The display will show 3 functions at a time. • Floor operation time (max) • The display will show 3 functions at a time. • Floor operation time (max) • The display will show 3 functions at a time. • Floor operation time (max) • The display will show 3 functions at a time. • Floor operation time (max) • Tank heat up time (max) • Stoor operation time (max) • Tank heat up time (max) • Tank heat up time (max) • Tank heat up time (max) • Tank heat up time (max) • Tank heat up time (max) 1:00 Maximum time for heating the tank (in hours and minutes) • Operation setup 10:34am, Maximum (max) • Tank re-heat temp. • Tank re-heat temp. • Select []Confirm • Tank re-heat temp. • Set temperature to perform reboil of tank water. • Operation setup 10:34am, Maximum time for fank:Re-heat temp. • Tank re-heat temp. • Set temperature to perform reboil of tank water. • Confirm	6.4	> Tank		1			
> Floor operation time (max) 8:00 Maximum time for floor operation (in hours and minutes) • Tank heat up time (max) • Tank heat up time (max) 1:00 Maximum time for heating the tank (in hours and minutes) • Tank re-heat temp. • Tank re-heat temp. -8 °C Set temperature to perform reboil of tank water.	• Avai	Available only if connected to	Tank heat up time (max) / Tank re-heat temp. /		Tank Floor operation (Ime (max) Tank heat up time (max) Tank re-heat temp.		
8:00 Maximum time for floor operation (in hours and minutes) Operation setup 10:34am, Min Tank:Floor ope. time (max) > Tank heat up time (max) Tank:Floor ope. time (max) > Tank heat up time (max) Select []Confirm 1:00 Maximum time for heating the tank (in hours and minutes) Operation setup 10:34am, Min Tank:Floor ope. time (max) 1:00 Maximum time for heating the tank (in hours and minutes) Operation setup 10:34am, Min Tank:Heat up time (max) > Tank re-heat temp. Set temperature to perform reboil of tank water. Operation setup 10:34am, Min Tank:Re-heat temp.			• The display will show	w 3 functions at a time.			
8:00 Maximum time for floor operation (in hours and minutes) Operation setup 10:34am, Min Tank:Floor ope. time (max) > Tank heat up time (max) Tank:Floor ope. time (max) > Tank heat up time (max) Select []Confirm 1:00 Maximum time for heating the tank (in hours and minutes) Operation setup 10:34am, Min Tank:Floor ope. time (max) 1:00 Maximum time for heating the tank (in hours and minutes) Operation setup 10:34am, Min Tank:Heat up time (max) > Tank re-heat temp. Set temperature to perform reboil of tank water. Operation setup 10:34am, Min Tank:Re-heat temp.			> Floor operation tin	ne (max)			
> Tank heat up time (max) Operation setup 10:34am, Mit Tank:Heat up time (max) 1:00 Maximum time for heating the tank (in hours and minutes) Geration setup 10:34am, Mit Tank:Heat up time (max) > Tank re-heat temp. Set temperature to perform reboil of tank water. Operation setup 10:34am, Mit Tank:Heat up time (max)				Maximum time for floor operation	Tank:Floor ope. time Range: (0:30~10:00) Steps: ±0:30	8:00	
1:00 Maximum time for heating the tank (in hours and minutes) Operation setup 10:34am, Min Tank:Heat up time (max) Range: (0:05~4:00) Steps: ±0:05 > Tank re-heat temp. Set temperature to perform reboil of tank water. Operation setup 10:34am, Min Tank:Heat up time (max) Range: (0:05~4:00) Steps: ±0:05					ÇSelect [₊-]C	Confirm	
1:00 Maximum time for heating the tank (in hours and minutes) Tank:Heat up time (max) Name Name Name > Tank re-heat temp. Set temperature to perform reboil of tank water. Operation setup 10:34am, Mo			> lank heat up time	(max)			
> Tank re-heat temp. -8 °C Set temperature to perform reboil of tank water. Generation setup 10:34am, Month Tank:Re-heat temp. Range: (-12°C~-2°C) Steps: ±1°C			1:00	heating the tank	Tank:Heat up time (n Range: (0:05~4:00)		
-8 °C Set temperature to perform reboil of tank water.					\$Select [₊-]C	Confirm	
-8 °C Set temperature to perform reboil of tank water. Tank:Re-heat temp. Range: (-12°C~-2°C) Steps: ±1°C			> Tank re-heat temp	• 1			
water.			• • • •		Tank:Re-heat temp.	10:34am, Mor	
			-δ	-0 0	1 ·	- 	Confirm


Menu

Default Setting Setting Options / Display

		> Sterilization			
		Sterilization may be set for 1 or		Operation setup	10:34am, Mon
			s of the week.	Sterilization: Day	
				Sun Mon Tue 🗉	cd Thu Fri Sat
		Sun / Mon / Tue / Wed / Thu / Fri / Sat			- -
				4•Day \$⊒/⊟] [+]Configur
		> Sterilization: Time	•		
		Time of the selected day(s) of the week to		Operation setup	10:34am, Mon
			e the tank.	Sterilization: Tim	e
		0:00 ~ 23:59		12:0)() pm
				Select [-	⊔]Confirm
		> Sterilization: Boili	ng temp.		
				Operation setup	10:34am, Mon
				Sterilization: Boil	<u>v</u> ,
	65 °C	65 °C	Set boiling temperatures for sterilize the tank.	Range: (55°C~65° Steps: ±1°C	(C) 65 ℃
			-Select [-	⊷]Confirm	
		> Sterilization: Ope.	time (max)		
				Operation setup 10:34am	10:34am, Mon
				Sterilization: Ope. time (max)	
		Set sterilizing time (in hours and minutes)	Range: (0:05~1:00) Steps: ±0:05	0) 0:10	
			\$Select [+	⊔]Confirm	
7	Installer setup > Service se	etup			
7.1	> Pump maximum speed				
	To set the maximum speed of Setting the flow rate, max. duty and oper		max. duty and operation	Service setup	10:34am, Mor
the pump.			· · · · · · · · · · · · · · · · · · ·		Duty Operation
		Max. Duty	e: XX:X L/min : 0x40 ~ 0xFE,		CE CAir Purge
		Dump: ON/OEE/Air Durgo			

	Pump: ON/OFF/Air Purge	< Select
7.2 > Pump down		
To set the pump down operation.	Pump down operation ON	P Pump down operation In progress! (%)cit+


Installer s	etup > Service setup				
7.3 → Dry	oncrete				
	e concrete (floor, c.) during construction.	Edit to set the temperature of dry concrete.		Service setup Dry concrete	10:34am,Mon ON
Do not use this menu for any other purposes and in period	ON / Edit		Edit		
other that				 Select	[+-]Confirm
construc		> Edit			
			Heating temperature for	Service setup	10:34am, Mon
			drying the concrete.	Dry concrete: 1	
		Stages: 1 Temperature: 25 °C	Select the desired stages: 1 ~ 10, range: 1 ~ 99	Range: (25°C~5 Steps: ±1°C	25 °C
				[▲] Select	[₊-]Confirm
		> ON		1	
		Confirm the settin	g temperatures of dry	Service setup	10:34am, Mon
		concrete fo	or each stage.	Dry concrete: St	
				Stage Water set temp	: 1/10 . : 25℃
				Actual water te	
				[①] OFF	
7.4 → Serv	> Service contact				
To set u	To set up to 2 contact names and numbers for the User.	Service engineer's name and contact number.		Service setup	10:34am, Mon
				Service contact:	-
		Context 1 Context 2			
		Contact 1 / Contact 2			
				., Select	[] Confirm
		> Contact 1 / Contact 2			
		Contact name or number.		Service contact	10c3Mam, Mnn
				Contect 1	
					ai Adairs
	Name / phone icon		23 : 068	12345878	
				_Select	[+J]Edil
		jkimuupqrstuvwsyz O V ₊ •Select [vitenter		KLMNOPGR Space	
				1 , -∙5el act	-
			iumber: 1 ~ 9	4	2 3 (5 6) 8 9 - BS 0 # Conf [+]Enter




It is advisable to avoid more than 2 blockage directions. For better ventilation 8 multiple-outdoor installation, please consult authorized dealer/specialist.

5. Dimensions

5.1 Mono Bloc Unit



6. Refrigeration and Water Cycle Diagram




Refrigerant Cycle (Heating)


→ Water Cycle

---► Refrigerant Cycle (Cooling)

6.1 Standard System (Optional PCB not connected)





6.2 Advance System (Optional PCB connected)




7. Block Diagram

7.1 WH-MXC09H3E8






7.3 WH-MXC16H9E8




8. Wiring Connection Diagram

8.1 Water System

8.1.1 WH-MXC09H3E8




8.1.2 WH-MXC12H9E8 WH-MXC16H9E8




8.2 Refrigerant System

8.2.1 WH-MXC09H3E8 WH-MXC12H9E8




REMARKS: with the read of the




9. Electronic Circuit Diagram

9.1 Water System

9.1.1 WH-MXC09H3E8




9.1.2 WH-MXC12H9E8 WH-MXC16H9E8




45

9.2 Refrigerant System

9.2.1 WH-MXC09H3E8 WH-MXC12H9E8







10. Printed Circuit Board

10.1 Water System

10.1.1 Main Printed Circuit Board




10.1.2 Optional Printed Circuit Board




10.2 Refrigerant System


10.2.1 Main Printed Circuit Board

10.2.1.1 CU-MXC09H3E8 CU-MXC12H9E8





10.2.2 Noise Filter Printed Circuit Board



11.Installation Instruction

11.1 Mono Bloc Unit

Attac	hed Accessories	
No.	Accessories part	Qty.
1	Drain elbow	1
2	Rubber cap	8
3	Remote controller	1

Optional Accessory

No.	Accessories part	Qty.
4	Optional PCB (CZ-NS4P)	1
5	Base Pan Heater (CZ-NE3P)	1
6	Network Adaptor (CZ-TAW1)	
7	Network Adaptor Cable (CZ-TAW1-CBL)	1

Field Supply Accessories (Optional)

No.	Part		Mode	Specification	Maker
	2-way valve kit	Electromotoric Actuator	SFA21/18	AC230V	Siemens
	2-way valve kit	2 port Valve	VVI46/25	-	Siemens
ii	3-way valve kit	Electromotoric Actuator	SFA21/18	AC230V	Siemens
	5-way valve Kit	3-port Valve	VVI46/25	-	Siemens
iii	Boom thermostat	Wired	PAW-A2W-RTWIRED	AC230V	
101	Room thermostat	Wireless	PAW-A2W-RTWIRELESS	AG230V	-
iv	Mixing valve	-	167032	AC230V	Caleffi
v	Pump	-	Yonos 25/6	AC230V	Wilo
vi	Buffer tank sensor	-	PAW-A2W-TSBU	-	-
vii	Outdoor sensor	-	PAW-A2W-TSOD	-	-
viii	Zone water sensor	-	PAW-A2W-TSHC	-	-
ix	Zone room sensor	-	PAW-A2W-TSRT	-	-
х	Solar sensor	-	PAW-A2W-TSSO	-	-

It is recommended to purchase the field supply accessories listed in above table.

- Handling of Mono bloc unit
 - Mono bloc unit is a large and heavy apparatus. The handling of the unit only to be done by lifting tools with slings. These slings can be fitted into sleeves at the unit's base frame.



11.1.1 Select the Best Location

- Install the Mono bloc unit in outdoor locations only.
- Avoid installations in areas where the ambient temperature may drop below -20°C.
- The Mono bloc unit must be installed on a flat, solid surface.
- A place removed from any heat source or steam which may effect the operation of the Mono bloc unit.
- A place where air circulation is good.
- A place where drainage can be easily done.
- A place where Mono bloc unit's operation noise will not cause discomfort to the user.
- A place which is accessible for maintenance.
- Ensure to keep minimum distance of spaces as illustrated above from wall, ceiling, or other obstacles.
- A place where flammable gas leaking might not occur.


- A place where the Mono bloc unit's piping and wiring lengths come within reasonable ranges.
- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- Avoid installing the Mono bloc unit at a location where suction side may be exposed directly to wind.
- If Mono bloc unit installed near sea, region with high content of sulphur or oily location (e.g. machinery oil, etc.), it lifespan maybe shorten.
- When installing the product in a place where it will be affected by typhoon or strong wind such as wind blowing between buildings, including the rooftop of a building and a place where there is no building in surroundings, fix the product with an overturn prevention wire, etc. (Overturn prevention fitting model number: K-KYZP15C)



11.1.2 Mono Bloc Unit Installation


Mono bloc unit will become heavy when filled with water. Please install the unit on a strong concrete floor and consider the weight of the unit and water.

- Fix Mono bloc unit on the concrete floor with M12 anchor bolt at 4 locations.
- Pull-out strength of these anchor bolts must be above 15000N.



11.1.2.1 Disposal of Mono Bloc Unit Drain Water

- When a Drain elbow is used, please ensure to follow below:
 - The unit should be placed on a stand which is taller than 50mm.
 - Cover the 8 holes (ø20mm) with Rubber cap (refer to illustration below)
 - o Use a tray (field supply) when necessary to dispose the Mono bloc unit drain water.



• If the unit is used in an area where temperature falls below 0°C for 2 or 3 consecutive days, it is recommended not to use the Drain elbow and Rubber cap, for the drain water freezes and the fan will not rotate.

11.1.3 Piping Installation

🕂 WARNING

This section is for authorized and licensed electrician / water system installer only. Work behind the front plate secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.

Please engage a licensed water circuit installer to install this water circuit.

- This water circuit must comply with relevant European and national regulations (including EN61770), and local building regulation codes.
- Ensure the components installed in the water circuit could withstand water pressure during operation.
- Do not apply excessive force to piping that may damage the pipes.
- Use Rp 1¹/₄" nut for both water inlet and water outlet connection and clean all piping with tap water before connecting to the Mono bloc unit.
- Cover the pipe end to prevent dirt and dust when inserting it through a wall. If an existing tank is to be connected to this Mono bloc unit, ensure the pipes are clean before water pipe installation is carried out.
- Choose proper sealer which can withstand the pressures and temperatures of the system.
- Make sure to use two spanners to tighten the connection. Tighten the nuts with torque wrench: 117.6 N•m.
- If non-brass metallic piping is used for installation, make sure to insulate the piping to prevent galvanic corrosion.
- Do not use pipes that are crushed or deformed. If these inferior pipes are used, it may cause unit malfunction.
- Make sure to insulate the water circuit piping (insulator thickness : 20mm or more) to prevent condensation during cooling operation and reduction of heating capacity, as well as avoid freezing of the outdoor water circuit piping during winter season.
- After installation, check the water leakage condition in connection area during test run.
- In case of a power supply failure or pump operating failure, drain the system (as suggested in the figure below).






When water is idle inside the system, freezing up is very likely to happen which could damage the system.

Drainage piping installation

- Use a drain hose with inner diameter of 15 mm.
- The hose must be installed in a continuously downward direction and left open to the frost-free atmosphere.
- If drain hose is long, use a metal support fixture along the way to eliminate the wavy pattern of drain tube.
- Water will drip from this hose, therefore the outlet of this hose must be installed in an area where the outlet cannot become blocked.
- Do not insert this hose into sewage or drain pipe that may generate ammonia gas, sulfuric gas, etc.
- If necessary, use a hose clamp to tighten the hose at drain hose connector to prevent it from leaking.




11.1.4 Connect the Cable to Mono Bloc Unit

🕂 WARNING

This section is for authorised and licensed electrician only. Work behind the cabinet front plate secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.

11.1.4.1 Remove The Cabinet Front Plate

- 1. Remove the 4 mounting screws as shown in the illustration.
- 2. Slide the cabinet front plate downward to release the pawls. Then, pull it toward front to remove it.



11.1.4.2 Fixing of Power Supply Cord


(REFER TO WIRING DIAGRAM AT UNIT FOR DETAIL)

- 1. An isolating device must be connected to the power supply cable.
 - Isolating device (Disconnecting means) should have minimum 3.0 mm contact gap.
 - Connect the approved polychloroprene sheathed power supply 1 cord and power supply 2 cord and type designation 60245 IEC 57 or heavier cord to the terminal board, and to the other end of the cord to isolating device (Disconnecting means). See below table for cable size requirement.

Model	Power Supply Cord	Cable Size	Isolating Devices	Recommended RCD
WH-MXC09H3E8	1	5 x min 1.5 mm ²	20A	30mA, 4P, type A
WH-MAC09H3E0	2	3 x min 2.5 mm ²	15/16A	30mA, 2P, type AC
WH-MXC12H9E8 and WH-MXC16H9E8	1	$5 \text{ x min } 1.5 \text{ mm}^2$	20A	30mA, 4P, type A
	2	$5 \text{ x min } 1.5 \text{ mm}^2$	20A	30mA, 4P, type AC


- 2. To avoid the cable and cord being damaged by sharp edges, the cable and cord must be passed through the designated holes before being connected to the terminal block.
- 3. Secure the cable onto the control board with the holder (clamper).

For model WH-MXC09H3E8



Power Supply 1 Power Supply 2

11.1.4.3 Wire Stripping and Connecting Requirement



11.1.4.4 Connecting Requirement

For WH-MXC09H3E8

- The equipment's Power Supply 1 complies with IEC/EN 61000-3-2.
- The equipment's Power Supply 1 complies with IEC/EN 61000-3-3 and can be connected to current supply network.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-2.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-11 and shall be connected to suitable supply network, with the following maximum permissible system impedance $Z_{max} = 0.426$ ohm(Ω) at the interface. Please liaise with supply authority to ensure that the Power Supply 2 is connected only to a supply of that impedance or less.


For WH-MXC12H9E8, WH-MXC16H9E8

- The equipment's Power Supply 1 complies with IEC/EN 61000-3-2.
- The equipment's Power Supply 1 complies with IEC/EN 61000-3-3 and can be connected to current supply network.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-2.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-3 and can be connected to current supply network.


11.1.4.5 Connecting with external device (optional)

- All connections shall follow to the local national wiring standard.
- It is strongly recommended to use manufacturer-recommended parts and accessories for installation.
- For connection to main PCB
 - 1 Two-way valve shall be spring and electronic type, refer to "Field Supply Accessories" table for details. Valve cable shall be (3 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
 - * note: Two-way Valve shall be CE marking compliance component.
 - Maximum load for the valve is 9.8VA.
 - 2 Three-way valve shall be spring and electronic type. Valve cable shall be (3 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
 - * note: Shall be CE marking compliance component.
 - It shall be directed to heating mode when it is OFF.
 - Maximum load for the valve is 9.8VA.
 - 3 Room thermostat cable must be (4 or 3 x min 0.5 mm²), of type designation 60245 IEC 57 or heavier cord, or similarly double insulation sheathed cable.
 - 4 Maximum output power of booster heater shall be \leq 3 kW. Booster heater cable must be (3 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
 - 5 Extra pump cable shall be (2 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
 - 6 Boiler contact cable shall be (2 x min 0.5 mm²), of type designation 60245 IEC 57 or heavier.
 - 7 External control shall be connected to 1-pole switch with min 3.0 mm contact gap. Its cable must be (2 x min 0.5 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
 - * note: Switch used shall be CE compliance component.
 - Maximum operating current shall be less than $3A_{\text{rms}}$.


8 Tank sensor shall be resistance type, please refer to graph below for the characteristic and details of sensor. Its cable shall be (2 x min 0.3 mm²), double insulation layer (with insulation strength of min 30V) of PVC-sheathed or rubber-sheathed cable.



- 9 Room sensor zone 1 cable shall be (2 x min 0.3 mm²) double insulation layer of PVC-sheathed or rubbersheathed.
- 10 Outdoor air sensor cable shall be (2 x min 0.3 mm²) double insulation layer of PVC-sheathed or rubbersheathed.
- 11 Tank OLP cable must be (2 x min 0.5 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.





How to guide optional cables and power supply cords to Bushing 15




How to guide optional cables and power supply cords (view without internal wiring)

- For connection to optional PCB
 - 1 By connecting optional PCB, 2 Zone temperature control can be achieved. Please connect mixing valves, water pumps and thermistors in zone 1 and zone 2 to each terminals in optional PCB. Temperature of each zone can be controlled independently by remote controller.
 - 2 Pump zone 1 and zone 2 cable shall be (2 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
 - 3 Solar pump cable shall be (2 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
 - 4 Pool pump cable shall be $(2 \text{ x min } 1.5 \text{ mm}^2)$, of type designation 60245 IEC 57 or heavier.
 - 5 Room thermostat zone 1 and zone 2 cable shall be (4 x min 0.5 mm²), of type designation 60245 IEC 57 or heavier.
 - 6 Mixing valve zone 1 and zone 2 cable shall be (3 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
 - 7 Room sensor zone 1 and zone 2 cable shall be (2 x min 0.3 mm²), double insulation layer (with insulation strength of minimum 30V) of PVC-sheathed or rubber-sheathed cable.
 - 8 Buffer tank sensor, pool water sensor and solar sensor cable shall be (2 x min 0.3 mm²), double insulation layer (with insulation strength of minimum 30V) of PVC-sheathed or rubber-sheathed cable.
 - 9 Water sensor zone 1 and zone 2 cable shall be (2 x min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
 - 10 Demand signal cable shall be (2 x min 0.3 mm²), double insulation layer of PVC-sheathed or rubbersheathed cable.
 - 11 SG signal cable shall be (3 x min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
 - 12 Heat/Cool switch cable shall be (2 x min 0.3 mm²), double insulation layer of PVC-sheathed or rubbersheathed cable.
 - 13 External compressor switch cable shall be (2 x min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.








Terminal screw on PCB	Maximum tightening torque cN•m {kgf•cm}
M3	50 {5.1}
M4	120 {12.24}

11.1.5 Installation of Remote Controller

11.1.5.1 Installation Location

- Install at the height of 1 to 1.5 m from the floor (Location where average room temperature can be detected).
- Install vertically against the wall.
- Avoid the following locations for installation.
 - 1 By the window, etc. exposed to direct sunlight or direct air.
 - 2 In the shadow or backside of objects deviated from the room airflow.
 - 3 Location where condensation occurs (The Remote Controller is not moisture proof or drip proof.)
 - 4 Location near heat source.
 - 5 Uneven surface.
- Keep distance of 1 m or more from the TV, radio and PC. (Cause of fuzzy image or noise)

11.1.5.2 Remote Controller Wiring




- Remote Controller cable shall be (2 x min 0.3 mm²), of double insulation PVC-sheathed or rubber sheathed cable. Total cable length shall be 50 m or less.
- Be careful not to connect cables to other terminals (e.g. power source wiring terminal). Malfunction may occur.
- Do not bundle together with the power source wiring or store in the same metal tube. Operation error may occur.


11.1.5.3 Mounting The Remote Controller

For exposed type

Preparation: Make 2 holes for screws using a driver.




For embedded type **Preparation:** Make 2 holes for screws using a driver.




11.1.6 Installation of Network Adaptor and Base Pan Heater

11.1.6.1 Network Adaptor and Installation (Optional)


- 1. Open the Cabinet front plate, then connect the Network Adaptor Cable to the CN-CNT connector on the printed circuit board.
 - Pull the cable out of the Mono bloc unit so that there is no pinching.
 - If an optional PCB has been install in the Mono bloc unit, connect the CN-CNT connector to Optional PCB.




2. Insert a flat head screwdriver into the slot on the top of the adaptor and remove the cover. Connect the other end of the CN-CNT cable connector to the connector inside the adaptor.




3. On the wall near the Mono bloc unit, attach the adaptor by screwing screws through the holes in the back cover.



4. Pull the CN-CNT cable through the hole in the bottom of the adaptor and re-attach the front cover to the back cover.



 Use the included cord clamp to fix the CN-CNT cable to the wall.
 Pull the cable around as shown in the diagram so that external forces cannot act on the connector in the adaptor. Use the included cable tie to fix the cables together.




11.1.6.2 Base Pan Heater (Optional)


• It is strongly recommended to install a Base Pan Heater (optional) if the Mono bloc unit is installed in cold climate area. Refer the Base Pan Heater (optional) installation instruction for details of installation.

11.1.7 Charging the Water

- Make sure all the piping installations are properly done before carry out below steps.
 - 1 Open Cabinet front plate to access to the Pressure Relief Valve and Air Purge Valve.
 - 2 Turn the plug on the Air Purge Valve outlet anticlockwise by one complete turn from fully closed position.



3 Set the Pressure Relief Valve level "DOWN".



- 4 Start filling water (with pressure more than 0.1 MPa (1 bar)) to the Mono bloc unit via water inlet. Stop filling water if the free water flow through Pressure Relief Valve drain hose.
- 5 Turn ON the power supply and make sure Water Pump is running.
- 6 Check and make sure no water leaking at the tube connecting points.
- 7 Reinstall the Cabinet front plate by tightening the 2 mounting screws.

Reconfirmation 11.1.8

WARNING

Be sure to switch off all power supply before performing each of the below checkings. Before obtaining access to terminals, all supply circuits must be disconnected.

11.1.8.1 Check Water Pressure *(0.1 MPa = 1 bar)

Water pressure should not lower than 0.05 MPa (with inspects the Water Pressure Gauge). If necessary add tap water into the water circuit.

11.1.8.2 **Check Pressure Relief Valve**

- Check for correct operation of Pressure Relief Valve by turning on the lever to become horizontal.
- If you do not hear a clacking sound (due to water drainage), contact your local authorized dealer.
- Push down the lever after finish checking.
- In case the water keeps drained out from the unit, switch off the system, and then contact your local authorized dealer.

11.1.8.3 **Expansion Vessel Pre Pressure** Checking

[Upper limit water volume of the system] The Mono bloc unit has a build-in Expansion Vessel with 10 L air capacity and initial pressure of 1 bar.

Without antifreeze agent condition

Total amount of water in the system should be below 200 L.

If the total amount of water is more than 200 L, please add expansion vessel (field supply).

With antifreeze agent condition

In the case of using antifreeze agent, expansion rate ϵ is different depending on its maker.

Please refer to the antifreeze agent maker for the expansion rate ε before calculate the upper limit water volume of the system.

The expansion vessel capacity required for the system can be calculated from the formula below.

$$V = \frac{\varepsilon \times V_0}{1 - \frac{98 + P_1}{98 + P_2}}$$
V : Required gas volume
Vo : System total water volume

- Vo : System ϵ : Expansion rate $5 \rightarrow 60^\circ C$ = (depends on antifreeze
- agent used)
- P_1 : Expansion tank filling pressure = (100) kPa = 300 kPa
- P₂: System maximum pressure
-) Please confirm at actual place

- The gas volume of the sealed type expansion vessel is presented by <V: O It's advised to add 10% margin for required gas volume of calculation.

[Adjustment of the initial pressure of the expansion vessel when there is a difference in installation height] If the height difference between the Mono bloc unit and the highest point of the system water circuit (H) is more than 7m, please adjust the initial pressure of the expansion vessel (Pg) according to the following formula.

Pg= (H*10+30) kPa

11.1.8.4 Check RCCB

Ensure the RCCB set to "ON" condition before check RCCB.

Turn on the power supply to the Mono bloc unit. This testing could only be done when power is supplied to the Mono bloc unit.

WARNING

Be careful not to touch parts other than RCCB test button when the power is supplied to Mono bloc unit. Else, electrical shock may happen.

- Push the "TEST" button on the RCCB. The lever would turn down and indicate "0", if it functions normal.
- Contact authorized dealer if the RCCB malfunction.
- Turn off the power supply to the Mono bloc unit.
- If RCCB functions normal, set the lever to "ON" again after testing finish.

This product contains fluorinated greenhouse gasses. Refrigerant type : R410A (GWP=2088) For WH-MXC09H3E8 & WH-MXC12H9E8 Amount : 2.3 kg (4.802 ton CO₂ equivalent) For WH-MXC16H9E8 Amount : 2.35 kg (4.907 ton CO₂ equivalent)

11.1.9 Test Run

- 1. Before test run, make sure below items have been checked:-
 - Pipework are properly done. 0
 - Electric cable connecting work are properly 0 done.
 - Mono bloc unit is filled up with water and 0 trapped air is released.
- 2. Antifreeze agent must be added into water circuit to prevent freezing of water when outdoor ambient temperatures is low. Recommended antifreeze: Propylene glycol: 40% (equivalent to -20°C)
- 3. Set ON to the Mono bloc unit and RCCB. Then, for remote control operation please refers to (Mono bloc) Air-to-Water Heatpump's operation instruction.
- For normal operation, pressure gauge reading should be in between 0.05 MPa and 0.3 MPa.
- After test run, please clean the Water filter. 5. Reinstall it after finish cleaning.

11.1.9.1 **Reset Overload Protector**

Overload Protector serves the safety purpose to prevent the water over heating. When the Overload Protector trip at high water temperature, take below steps to reset it.

- 1. Take out the cover.
- Use a test pen to push the centre button gently in 2. order to reset the Overload Protector.
- 3. Fix the cover to the original fixing condition.



11.1.10 Maintenance


• In order to ensure optimal performance of the unit, seasonal inspections on the unit, functional check of RCCB, field wiring and piping have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer.

11.1.10.1 Maintenance for Water Filter Set

- 1. Remove the Cover by loosening the mounting screws to access to the Water Filter Set.
- 2. Turn OFF power supply.
- 3. Set the two valves for the Water Filter Set to "CLOSE".
- 4. Take off the clip, then gently pull out the mesh. Beware of small amount water drain out from it.
- 5. Clean the mesh with warm water to remove all the stain. Use soft brush if necessary.
- 6. Reinstall the mesh to the Water Filter Set and set back the clip on it.
- Set the two valves for the Water Filter Set to "OPEN".
- 8. Turn ON power supply.

9. After cleaning, reinstall the Cover by tightening the mounting screws properly.

Do not add or replace other than R410A type. It may cause product damage, burst, injury and etc. Use compatible R410A tools for refrigerant piping work and refrigerant charging during installation or servicing.




11.2 Variation of system

This section introduces variation of various systems using Air-To-Water Heatpump and actual setting method.

11.2.1 Introduce application related to temperature setting.

11.2.1.1 Temperature setting variation for heating


1. Remote Controller



S	Setting of remote controller
In	staller setting System setup Optional PCB connectivity - No
	Zone & Sensor: Water temperature


Connect floor heating or radiator directly to the Mono bloc. This is the basic form of the most simple system.

2. Room Thermostat




Connect floor heating or radiator directly to the Mono bloc. Install the remote controller in the room where floor heating is installed. This is an application that uses remote controller as Room Thermostat.

3. External Room Thermostat





Connect floor heating or radiator directly to Mono bloc.

Install separate external Room Thermostat (field supply) in the room where floor heating is installed. This is an application that uses external Room Thermostat.




4. Room Thermistor






Connect floor heating or radiator directly to Mono bloc. Install separate external room thermistor (specified by Panasonic) in the room where floor heating is installed. This is an application that uses external room thermistor.



11.2.1.2 Examples of installations

Floor heating 1 + Floor heating 2



Connect floor heating to 2 circuits through buffer tank as shown in the figure.

Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits.

Install the remote controller in one of the circuit and use it as Room Thermostat.


Install external Room Thermostat (field supply) in another circuit.

Both circuits can set circulation water temperature independently.

Install buffer tank thermistor on buffer tank.

It requires connection setting of buffer tank and ΔT temperature setting at heating operation separately. This system requires optional PCB (CZ-NS4P).

Floor heating + Radiator



Connect floor heating or radiator to 2 circuits through buffer tank as shown in figure.

Install pumps and thermistors (specified by Panasonic) on both circuits.

Install mixing valve in the circuit with lower temperature among the 2 circuits.

(Generally, if install floor heating and radiator circuit at 2 zones, install mixing valve in floor heating circuit.)

For temperature setting, select circulation water temperature for both circuits.


Both circuits can set circulation water temperature independently.

Install buffer tank thermistor on buffer tank.

It requires connection setting of buffer tank and ΔT temperature setting at heating operation separately. This system requires the optional PCB (CZ-NS4P).

Mind that if there is no mixing valve at the secondary side, the circulation water temperature may get higher than setting temperature.

Floor heating + Swimming pool



Connect floor heating and swimming pool to 2 circuits through buffer tank as shown in figure.

Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits. Then, install additional pool heat exchanger, pool pump and pool sensor on pool circuit.

Install the remote controller in room where floor heating is installed. Circulation water temperature of floor heating and swimming pool can be set independently.


Install buffer tank sensor on buffer tank.

It requires connection setting of buffer tank and ΔT temperature setting at heating operation separately. This system requires the optional PCB (CZ-NS4P).

* Must connect swimming pool to "Zone 2".

If it is connected to swimming pool, operation of pool will stop when "Cooling" is operated.

Swimming pool only



This is an application that connects to the swimming pool only.

Connects pool heat exchanger directly to Mono bloc without using buffer tank.

Install pool pump and pool sensor (specified by Panasonic) at secondary side of the pool heat exchanger.


Install the remote controller in room where floor heating is installed.

Temperature of swimming pool can be set independently.

This system requires the optional PCB (CZ-NS4P).

In this application, cooling mode cannot be selected. (not display on remote controller)

Simple 2 zone (Floor heating + Radiator)



This is an example of simple 2 zone control without using buffer tank.

Built-in pump from Mono bloc served as a pump in zone 1.

Install mixing valve, pump and thermistor (specified by Panasonic) on zone 2 circuit.

Please be sure to assign high temperature side to zone 1 as temperature of zone 1 cannot be adjusted.

Zone 1 thermistor is required to display temperature of zone 1 on remote controller.

Circulation water temperature of both circuits can be set independently.

(However, temperature of high temperature side and low temperature side cannot be reversed) This system requires the optional PCB (CZ-NS4P).

(CAUTION)


Thermistor 1 does not affect operation directly. But error happens if it is not installed.
 Please adjust flow rate of zone 1 and zone 2 to be in balance. If it is not adjusted correctly, it may affects

the performance.

(If zone 2 pump flow rate is too high, there is possibility that no hot water flowing to zone 1.) Flow rate can be confirmed by "Actuator Check" from maintenance menu.


11.2.2 Introduce applications of system that uses optional equipment.

DHW (Domestic Hot Water) Tank connection



This is an application that connects the DHW tank to the Mono bloc through 3-way valve. DHW tank's temperature is detected by tank thermistor (specified by Panasonic).

Tank + Solar connection




This is an application that connects the DHW tank to the Mono bloc through 3-way valve before connect the solar water heater to heat up the tank. DHW tank's temperature is detected by tank thermistor (specified by Panasonic). Solar panel's temperature is detected by solar thermistor (specified by Panasonic).

DHW tank shall use tank with built-in solar heat exchange coil independently.


Heat accumulation operates automatically by comparing the temperature of tank thermistor and solar thermistor. During winter season, solar pump for circuit protection will be activated continuously. If does not want to activate the solar pump operation, please use glycol and set the anti-freezing operation start temperature to -20°C. This system requires optional PCB (CZ-NS4P).

Buffer tank connection



This is an application that connects the buffer tank to the Mono bloc. Buffer tank's temperature is detected by buffer tank thermistor (specified by Panasonic). This system requires optional PCB (CZ-NS4P).

Buffer tank + Solar



This is an application that connects the buffer tank to the Mono bloc before connecting to the solar water heater to heat up the tank.

Buffer tank's temperature is detected by buffer tank thermistor (specified by Panasonic).


Solar panel's temperature is detected by solar thermistor (specified by Panasonic).

Buffer tank shall use tank with built-in solar heat exchange coil independently.

During winter season, solar pump for circuit protection will be activated continuously. If does not want to activate the solar pump operation, please use glycol and set the anti-freezing operation start temperature to -20°C.

Heat accumulation operates automatically by comparing the temperature of tank thermistor and solar thermistor. This system requires optional PCB (CZ-NS4P).

Boiler connection



This is an application that connects the boiler to the Mono bloc, to compensate for insufficient capacity by operate boiler when outdoor temperature drops & heat pump capacity is insufficient.

Boiler is connected parallel with heat pump against heating circuit.

There are 3 modes selectable by remote controller for boiler connection.

Besides that, an application that connects to the DHW tank's circuit to heat up tank's hot water is also possible.

(Operation setting of boiler shall be responsible by installer.)

This system requires optional PCB (CZ-NS4P).

Depending on the settings of the boiler, it is recommended to install buffer tank as temperature of circulating water may get higher. (It must connect to buffer tank especially when selecting Advanced Parallel setting.)

🕂 WARNING

Panasonic is NOT responsible for incorrect or unsafe situation of the boiler system.

Make sure the boiler and its integration in the system complies with applicable legislation. Make sure the return water temperature from the heating circuit to the indoor unit does NOT exceed 55°C. Boiler is turned off by safety control when the water temperature of the heating circuit exceed 85°C.


11.3 How to Fix External Device

11.3.1 Connecting Cables Length

When connecting cables between Mono bloc and external devices, the length of the said cables must not exceed the maximum length as shown in the table.

External device	Maximum cables length (m)
Two-way valve	50
Three-way valve	50
Mixing valve	50
Room thermostat	50
Booster heater	50
Extra pump	50
Solar pump	50
Pool pump	50
Pump	50
Boiler contact	50
External control	50
Tank sensor	30
Room sensor	30
Outdoor air sensor	30
Tank OLP	30
Buffer tank sensor	30
Pool water sensor	30
Solar sensor	30
Water sensor	30
Demand signal	50
SG signal	50
Heat/Cool switch	50
External compressor switch	50

11.3.1.1 Connection of the main PCB



Signal inputs

	-
Optional Thermostat	L N =AC230V, Heat, Cool=Thermostat heat, Cool terminal #It does not function when using the optional PCB
OLP for booster heater	Dry contact Vcc-Bit1, Vcc-Bit2 open/short (System setup necessary) It is connected to the safety device (OLP) of DHW tank.
External control	Dry contact Open=not operate, Short=operate (System setup necessary) Able to turn ON/OFF the operation by external switch
Remote controller	Connected (Please use 2 cores wire for relocation and extension. Total cable length shall be 50m or less.)


Outputs

3-way valve	AC230V N=Neutral Open, Close=direction (For circuit switching when connected to DHW tank)	
2-way valve	AC230V N=Neutral Open, Close (Prevent water circuit pass through during cooling mode)	
Extra pump	AC230V (Used when Mono bloc pump capacity is insufficient)	
Booster heater	AC230V (Used when using booster heater in DHW tank)	
Boiler contact	Dry contact (System setup necessary)	

Thermistor inputs

Zone 1 room sensor	PAW-A2W-TSRT #It does not work when using the optional PCB
Outdoor air sensor	AW-A2W-TSOD (Total cable length shall be 30m or less)
Tank sensor	Please use Panasonic specified part

11.3.1.2 Connection of Optional PCB (CZ-NS4P)



Signal inputs

Optional Thermostat	L N =AC230V, Heat, Cool=Thermostat heat, Cool terminal
SG signal	Dry contact Vcc-Bit1, Vcc-Bit2 open/short (System setup necessary) Switching SW (Please connect to the 2 contacts controller)
Heat/Cool SW	Dry contact Open=Heat, Short=Cool (System setup necessary)
External comp.SW	Dry contact Open=Comp.ON, Short=Comp.OFF (System setup necessary)
Demand signal	DC 0~10V (System setup necessary) Please connect to the DC 0~10V controller.

Outputs

Mixing valve	AC230V N=Neutral Open, Close=mixture direction Operating time: 30s~120s
Pool pump	AC230V
Solar pump	AC230V
Zone pump heater	AC230V


Thermistor inputs

Zone room sensor	PAW-A2W-TSRT
Buffer tank sensor	PAW-A2W-TSBU
Pool water sensor	PAW-A2W-TSHC
Zone water sensor	PAW-A2W-TSHC
Solar sensor	PAW-A2W-TSSO

11.3.1.3 Recommended External Device Specification


- This section explains about the external devices (optional) recommended by Panasonic. Please always ensure to use the correct external device during system installation.
- For optional sensor.
 - 1 Buffer tank sensor: PAW-A2W-TSBU Use for measurement of the buffer tank temperature.

Insert the sensor into the sensor pocket and paste it on the buffer tank surface.



2 Zone water sensor: PAW-A2W-TSHC Use to detect the water temperature of the control zone.


Mount it on the water piping by using the stainless steel metal strap and contact paste (both are included).




3 Outdoor sensor: PAW-A2W-TSOD

If the installation location of the outdoor unit is exposed to direct sunlight, the outdoor air temperature sensor will be unable to measure the actual outdoor ambient temperature correctly.

In this case, optional outdoor temperature sensor can be fixed at a suitable location to more accurately measure ambient temperature.




4 Room sensor: PAW-A2W-TSRT Install the room temperature sensor to the room which requires room temperature control.



5 Solar sensor: PAW-A2W-TSSO Use for measurement of the solar panel temperature.

Insert the sensor into the sensor pocket and paste it on the solar panel surface.



6 Please refer to the table below for sensor characteristic of the sensors mentioned above.

Temperature (°C)	Resistance (kΩ)
150	0.147
140	0.186
130	0.236
120	0.302
110	0.390
100	0.511
90	0.686
80	0.932
70	1.279
65	1.504
60	1.777
55	2.106
50	2.508
45	3.003
40	3.615
35	4.375
30	5.326
25	6.523
20	8.044
15	9.980
10	12.443
5	15.604
0	19.70
-5	25.05
-10	32.10
-15	41.45
-20	53.92
-25	70.53
-30	93.05
-35	124.24
-40	167.82

70

For optional pump.
 Power supply: AC230V/50Hz, <500W
 Recommended part: Yonos 25/6: made by Wilo




 For optional mixing valve. Power supply: AC230V/50Hz (input open/output close) Operating time: 30s~120s

Recommended part: 167032: made by Caleffi




11.4 System Installation


11.4.1 Remote Controller Outline




	Name	Function
A:	Main screen	Display information
B:	Menu	Open/Close main menu
C:	Triangle (Move)	Select or change item
D:	Operate	Start/Stop operation
E:	Back	Back to previous item
F:	Quick Menu	Open/Close Quick menu
G:	ОК	Confirm




First time of power ON (Start of installation)




11.4.2 Installer Setup





11.4.3 System Setup


1. Optional PCB connectivity Initial setting: No	System setup 17:26, Wed
	Optional PCB connectivity
If function below is necessary, please purchase and install optional PCB. Please select Yes after installing optional PCB.	Zone & Sensor
	Heater capacity
2-zone control Pool	Anti freezing
Buffer tank	Select [↓] Confirm
 Solar External error signal output 	
Demand control	
SG readyStop heat source unit by external SW	
2. Zone & Sensor Initial setting: Room and Water temp.	System setup 17:26, Wed
	Optional PCB connectivity
If no Optional PCB connectivity	Zone & Sensor
Select sensor of room temperature control from the following 3 items ① Water temperature (circulation water temperature)	Heater capacity
© Room thermostat (Internal or External)	Anti freezing
③ Room thermistor	Select [-] Confirm
When there is Optional PCB connectivity	
 Select either 1 zone control or 2 zone control. 	
If it is 1 zone, select either room or pool, select sensor If it is 2 zone, after select sensor of zone 1, select either room or pool for zone	
2, select sensor	
(CAUTION) In 2 zone system, pool function can be set at zone 2 only.	
3. Heater capacity Initial setting: Depend on model	System setup 17:26, Wed
	Optional PCB connectivity
If there is built-in Heater, set the selectable heater capacity.	Zone & Sensor
(CAUTION) There are models which cannot select heater.	Heater capacity
	Anti freezing
	Select [+] Confirm
4. Anti freezing Initial setting: Yes	System setup 17:26, Wed
Operate anti franzina of water size lation size uit	Optional PCB connectivity
Operate anti-freezing of water circulation circuit. If select Yes, when the water temperature is reaching its freezing temperature, the	Zone & Sensor
circulation pump will start up. If the water temperature does not reach the pump	Heater capacity
stop temperature, back-up heater will be activated.	Anti freezing
(CAUTION) If set No, when the water temperature is reaching its freezing	Select [4] Confirm
temperature or below 0°C, the water circulation circuit may freeze and cause malfunction.	
5. Tank connection Initial setting: No	System setup 17:26, Wed
Select whether it is connected to hot water tank or not.	Zone & Sensor
If set Yes, it becomes setting that uses hot water function.	Heater capacity
Hot water temperature of tank can be set from main screen.	Anti freezing
	Tank connection
	Select [+] Confirm



10. Bivalent	Initial setting: No			System setup	17:26, Wed
				Tank heater	,
	ed with boiler operation			Base pan heate	er
Connect the start signal of the boiler in boiler contact terminal (main PCB). Set Bivalent connection to YES. After that, please begin setting according to remote controller instruction.			Alternative outdoor sensor		
			Bivalent		
Boiler icon will be dis	played on remote cont	roller top screen.		Select	[←] Confirm
 Alternative (switch Parallel (allow boi 	n to boiler operation wher operation when dro	eration. Movement of each nen drops below setting ter ps below setting temperatu boiler operation time of pa	nperature) ıre)	wn below.	
Please set target ten When boiler tempera	perature of boiler to b ture is higher than hea	ontact" is "ON", "_"(unders e the same as heat pump t t pump temperature, zone ol the boiler operation. Ope	temperature. temperature car	nnot be achieved if	mixing valve is not instal led.
Alternative mode operate boiler or	ly operate heat	pump only		boiler and heat	operate heat pump only
		Outdoor temp.	panip an		
	10°C (setting from remote	controller)	-		Outdoor tem
	ada			-10°C (setting	from remote controller)
Advanced Parallel m For heating	bue				
operate boiler an		t pump only		HW tank	energie haat numm antu
pump simultanec				ate boiler and heat p simultaneously	operate heat pump only
< <u>,</u>		Outdoor temp.			Outdoor temp
	-10°C (setting from remote	e controller)		-10°C (se	etting from remote controller)
Although heat pump ope					AND
but water temperature not reach this temperature more than 30 mins (se from remote controll Boiler temp. ON = Setting -8°C (setting from remote controller)	ire for tting er)	Circulation water temp. → atting temp	Tank temp. Lowering Tank Boiling ini temp. Heat pump	Heat pump thermo ON	tual tank temp. does t achieve the setting emp. within 30min tetting from remote ontroller), the boiler turn ON Tank setting temp. is achieved, both operations stop Tank setting temp.
In Advanced Parallel be made simultaneou when each time the r reset to OFF. Please	mode, setting for both Isly. During operation of node is switched, the l have good understand	of "Heating/Tank" mode,			→ tim
11. External SW	Initial setting:	No		System setup	17:26, Wed
	the operation by exten			Base pan heate Alternative outo Bivalent External SW Select	
12. Solar connect	on Initial setti	ng: No		System setup	17:26, Wed
Set when solar water	heater is installed.			Alternative outco Bivalent	loor sensor
Setting include items				External SW	
 Set either buffer tank or DHW tank for connection with solar water heater. Set temperature difference between solar panel thermistor and buffer tank or 			Solar connectio	n	
	stor to operate the sola			Select	[←] Confirm
DHW tank thermi	stor to stop the solar p	ar panel thermistor and buf ump. e (please change setting ba		f glycol.)	

r

Solar pump stop operation when it exceeds high limit temperature (when tank temperature exceed designated temperature (70~90°C))



PCB. ON/OFF signal used to ON/OFF tank heater (for sterilization purpose)

17. Circulation Liquid Initial setting: Water	System setup	17:26, Wed
	Demand control	
Set circulation of heating water.	SG ready	
There are 2 types of settings, water and anti-freeze function.	External compressor SW	
(CAUTION) Please set alvcol when using anti-freeze function.	Circulation liquid	
It may cause error if setting is wrong.	Select [4] Co	nfirm
18. Heat-Cool SW Initial setting: Disable	System setup	17:26, Wed
	SG ready	
Able to switch (fix) heating & cooling by external switch.	External compressor SW	
(Short) : Fix at Heating (Heating +DHW)	Circulation liquid	
(Open) : Fix at Cooling (Cooling +DHW) (CAUTION) This setting is disabled for model without Cooling.	Heat-Cool SW	
(CAUTION) This setting is disabled for model without Cooling. (CAUTION) Does not display if there is no Optional PCB.	Select [هـ] Co	nfirm
Timer function cannot be used. Cannot use Auto mode.		
19. Force Heater Initial setting: Manual	System setup	17:26, Wed
	External compressor SW	
Under manual mode, user can turn on force heater through quick menu.	Circulation liquid	
If selection is 'auto', force heater mode will turn automatically if pop up error	Heat-Cool SW	

orce heater

Select


[] Confirm

happen during operation. Force heater will operate follow the latest mode selection, mode selection is dsiable under force heater operation.


Heater source will ON during force heater mode

11.4.4 Operation Setup

Heat





Cool




30. Tank re-heat temp. Initial setting: -8°C Set temp to perform reboil of tank water. (When boiled by heat pump only, (51°C – Tank re-heat temp) shall become max temp.) Setting range is -12°C ~ -2°C	-12°C ~ -2°C
31. Sterilization Initial setting: 65°C 10min Set timer to perform sterilization. 1 1 Set operating day & time. (Weekly timer format) 2 Sterilization temp (55~75°C × If use back-up heater, it is 65°C) 3 Operation time (Time to run sterilization when it reached setting temp 5min ~ 60min) User shall set whether to use or not to use sterilization mode.	

11.4.5 Service Setup







35. Service contact	Service setup	17:26, Wed	Contact-1: Bryan Ada	ms
	Service contact:		ABC/ abc	0-9/ Other
Able to set name & tel no. of contact person when there is breakdown	Contact 1		ABCDEFGHIJK	LMNOPQR
etc. or client has trouble. (2 items)	Contact 2		STUVWXYZ a	abcdefghi
			jklmnopqrstuv	w x y z
	Select [4] Confirm		→ Select	[⊷] Enter

12. Operation and Control

12.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operating mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operating mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at outdoor unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal water setting temperature and water outlet temperature.

12.1.1 Internal Water Setting Temperature

Once the operation starts, control panel setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the Air-to-Water Heat pump settings and the operation environment. The final shifted value will be used as internal water setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.

12.1.2 Heating Operation

12.1.2.1 Thermostat Control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > 2°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) <-3°C.

12.1.2.2 Thermostat Control (Outdoor Ambient Temperature)

Stops provide heating to room side during high outdoor ambient condition. Control content:

 Heating operation and water pump will turn OFF when outdoor ambient temperature > outdoor thermo off temperature + 3°C.

(Outdoor thermo off set temperature is set by control panel. Thermo off set temperature is between 5°C ~ 35°C)

• Heating operation will resume when Outdoor ambient temperature < Outdoor thermo OFF set temperature + 1°C.

12.1.2.3 Heat Mode Operation

Operation of heat pump provide heating capacity to room side by hot water through heating panel, floor heating or fan coil unit.

- 1 3 ways valve control:
- \circ 3 ways valve switch and fix to heating side.
- 2 Heat pump operates follow normal heating operation.
- 3 Back up heater operate follow normal operation.
- 4 2 ways valve control:
 - 2 ways valve opens.

12.1.3 Cooling Operation

12.1.3.1 Thermostat control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > -1.5°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) >3°C.

12.1.3.2 Cool Mode Operation

- 1 3 ways valve control:
- 3 ways valve switch and fix to cooling side.
- 2 Heat pump operates follow normal cooling operation.
- 3 Room heater DOES NOT operate during cool mode.
- 4 2 ways valve control:
 - 2 ways valve is closed.

12.1.4 Target Water Temperature Setting

12.1.4.1 Target Water Temperature Control of Standard System (Optional PCB not connected)

There are 2 types of temperature control selection which are Compensation and Direct.

- Temperature control type selection by installer:
 - 1 Compensation : Wlo, WHi, ODLo, ODHi can be set at installer menu.
 - 2 Direct : Direct Water Temperature Set
- Remote control setting by user:
 - 1 Compensation : Shift value ±5°C from the compensation curve
 - 2 Direct : Direct water temperature set change

*This setting at is only able to set when the room sensor select as Water Temperature. *Instead of water temperature, user will set target room temperature when room sensor select as Room Thermistor OR Internal Room Thermostat.

- Target water temperature is calculated as below condition.
 - Target water temperature = A (Base temperature) + B (shift temperature)

A (D T	Compensation	Direct
A (Base Temperature)	Value from the curve + User shift value set	Direct value from user setting

o B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below	
Sensor selection		
Water temperature	B = 0	
External Room thermostat	B = 0	
Internal Room Thermostat & Room Thermistor	Cool Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = 1* (room set temp (R/C) - actual room temp) Max/Min Regulation of B: (Max = 5 ; Min = -5) Heat Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = follow Heating PI control contents	


• Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
Мах	55°C (Below Ambient -15°C) * 60°C (Below Ambient -10°C) *	20°C
Min	20°C	5°C

* Between outdoor ambient -10°C and -15°C, max target decreases gradually from 60°C to 55°C.

Compensation Type: (Operation under Heat Mode and Cool Mode)


• The set temperature defines the parameters for the ambient (Outdoor temperature) dependent operation of the unit. The water temperature is determined automatically depending on the outdoor temperature. Default setting is the colder outdoor temperature will result in warmer water and vice versa. The user has the possibility to shift up and shift down the target water by remote control setting.



- Outdoor ambient is updated every 30 minutes when operation ON.
- Setting water outlet temperature always follow W_(LO) or W_(HI) whenever is higher if outdoor ambient sensor or indoor comminication error happen.

However, when powerful mode is requested by remote control during heating mode, the higher value of HLo or Whi will be used for A calculation.

- * There are 2 compensation curves (for heating and cooling). During heating mode, the heating curve is used and during cooling mode, the cooling curve is use.
- Compensation curve set shift value:



12.1.5 Target Water Temperature at Extension System (Optional PCB is connected)

Target water temperature is calculated as below.

- Heat Mode:
 - When buffer tank selection is "YES:" Target water temperature = Target buffer tank temperature + [2°C]
 - o When buffer tank selection is "NO"
 - If both zone 1 and zone 2 is active
 - Target Water Temperature = Higher zone target water temperature of Zone 1 and Zone 2.
 - If only one zone is active
 Target Water Temperature = Zone target water temperature of active zone.
- Cool mode:
 - When buffer tank selection is "YES"
 - If both zone 1 and zone 2 is active
 - Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2 + [-3°C]
 - If only one zone is active
 Target Water Temperature = Zone Target Water Temperature of active zone + [-3°C]
 - When buffer tank selection is "NO"
 - If both zone 1 and zone 2 active
 - Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2
 - o If only one zone is active
 - Target Water Temperature = Zone Target Water Temperature of active zone

*Cool Mode does not have SG ready control

12.1.6 Target Zone Water Temperature Control

Purpose:- To control zone mixing and zone pump according to the zone sensor temperature

12.1.6.1 Target Zone 1 water temperature setting control

- Start condition
 - Heating zone 1 is ON by remote control or Timer or Auto Mode OR
 - o Cooling zone 1 is ON by remote control or Timer or Auto Mode.
- Cancel condition
 - Heating zone 1 is OFF by remote control or Timer or Auto mode AND
 - Cooling zone 1 is OFF by remote control or Timer or Auto mode.
- Target Zone 1 water temperature is calculated as below condition.
 - Target Zone 1 water temperature = A (Base temperature) + B (shift temperature)

A (Base Temperature)	Compensation	Direct
A (base reinperature)	Value from the curve + User shift value set	Direct value from user setting

* During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.

o B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below	
Sensor selection		
Water temperature B = 0		
External Room thermostat B = 0		
Internal Room Thermostat &	Cool Mode: B = 0 ; when Zone OFF or Zone Room Therma OFF B = 1* (room set temp (R/C) - actual room temp) Max/Min Regulation of B: (Max = 5 ; Min = -5)	
Room Thermistor	Heat Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = follow Heating Room Temperature PI control logic	
Pool Function Selected B = Delta value setting from remocon		

* B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool "B" value)

** Pool function also can be select at Zone 1 when optional PCB is connected and Zone 1 system is select.

• Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
Мах	55°C (Below Ambient -15°C) * 60°C (Below Ambient -10°C) *	20°C
Min	20°C	5°C

* Between outdoor ambient -10°C and -15°C, max target decreases gradually from 60°C to 55°C.

- Target Zone 1 Water Temperature (Heat mode only) during SG ready control
 - o If buffer tank selection is "NO" then following shift is carried out.
 - While digital input is "10" or "11" then,
 Final Target Zone 1 water temperature
 = Target Zone 1 water temperature* (SG ready % setting (remote control menu))%
 - If buffer tank selection is "YES"
 - No shift of Target Zone 1 Water Temperature. Target Buffer Tank Temperature will change accordingly.
 * Refer to "Buffer tank temperature control"

12.1.6.2 Target Zone 2 water temperature setting control

- Start condition
 - $_{\odot}$ Heating zone 2 is ON by remote control or Timer or Auto Mode OR
 - \circ $\,$ Cooling zone 2 is ON by remote control or Timer or Auto Mode.
- Cancel condition
 - o Heating zone 2 is OFF by remote control or Timer or Auto mode AND
 - Cooling zone 2 is OFF by remote control or Timer or Auto mode.
- Target Zone 2 water temperature is calculated as below condition.
 - Target Zone 2 water temperature = A (Base temperature) + B (shift temperature)

A (Paga Tamparatura)	Compensation	Direct
A (Base Temperature)	Value from the curve + User shift value set	Direct value from user setting

* During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.

o B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below	
Sensor selection		
Water temperature B = 0		
External Room thermostat B = 0		
Internal Room Thermostat & Room Thermistor	Cool Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = 1* (room set temp (R/C) - actual room temp) Max/Min Regulation of B: (Max = 5 ; Min = -5) Heat Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF	
	B = follow Heating Room Temperature PI control logic	
Pool Function Selected B = Delta value setting from remocon		

* B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool "B" value)

** Pool function also can be select at Zone 2 when optional PCB is connected and Zone 2 system is select.

• Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
Мах	55°C (Below Ambient -15°C) * 60°C (Below Ambient -10°C) *	20°C
Min	20°C	5°C

* Between outdoor ambient -10°C and -15°C, max target decreases gradually from 60°C to 55°C.

- Target Zone 2 Water Temperature (Heat mode only) during SG ready control
 - o If buffer tank selection is "NO" then following shift is carried out.
 - While digital input is "10" or "11" then,
 - Final Target Zone 2 water temperature
 - = Target Zone 1 water temperature* (SG ready % setting (remote control menu))%
 - If buffer tank selection is "YES"
 - No shift of Target Zone 2 Water Temperature. Target Buffer Tank Temperature will change accordingly.
 * Refer to "Buffer tank temperature control"

12.1.6.3 Zone Temperature Control Contents


- During Standard System (Optional PCB not connected)
 - Only 1 zone temperature control is available
 - This zone room temperature is control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temperature)
 - Target Zone Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor. Target Water Temperature will set same as Target Zone Water Temperature
 - Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).
- * There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.
- During Extension System (Optional PCB connected)

- Buffer Tank connection select "NO" &
 - One zone system is select
 - This zone room temperature control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temp.)
 - Target Zone Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor.
 - Target Water Temperature will set same as Target Zone Water Temperature
 - Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).
- ^t There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.
 - 2 zone system select
 - Each zone room temperature is control by each sensor which select from either one of the 4 room sensor
 - Target Zone 1 & 2 Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor.
 * Zone Mixing Valve & Zone nump will operate to achieve Target Zone Water Temperature which
 - * Zone Mixing Valve & Zone pump will operate to achieve Target Zone Water Temperature which refer to zone sensor.
 - * Zone Sensor will detect if zone sensor is open or short.
 - Target Water Temperature will set same as the active & higher zone water temperature setting. (When cooling mode, lower zone water temp setting)
 - Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat).
- Buffer Tank Connection select "YES" &
 - 1 zone system or 2 zone system select
 - Each zone control by each sensor which select from either one of the 4 room sensor
 - Target Zone 1 & 2 Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor. Each zone have their own Target Zone Water Temperature.

* Zone Mixing Valve & Zone pump will operate to achieve each Target Zone Water Temperature which refer to zone sensor


- * Zone Sensor will detect if zone sensor is open or short.
- Target Buffer Tank Temperature will be set as active & higher zone water temperature setting + Buffer Delta T. (Heating) Target Buffer Tank Temperature will be set as active & lower zone water temperature setting (Cooling).
- Target Water Temperature will set as Target Buffer Tank Temperature + [2°C] (Heating) Target Water Temperature will set as Lower or Active Target Zone Water Temp. + [-3°C] (Cooling)
- Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
- Heat pump and water pump OFF when ROOM thermo OFF
 - Heat mode: ROOM thermo OFF (Buffer Tank Temperature > Target Buffer Tank + [0°C]
 - Cool mode: ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat)

12.1.7 Auto Mode Operation



- Control details:
 - To enable the unit to operate either heat or cool mode automatically, heat to cool set temperature and cool to heat set temperature can be set by control panel.
 - Automatic operation is judged based on control panel setting temperature and outdoor ambient temperature.
 - * Minimum setting of heat to cool set temperature is 1°C higher than cool to heat set temperature.
- Judgement control:
 - If outdoor ambient temperature < Heat to Cool Set Temperature, unit will operate in Heat Mode or else the unit will operate in Cool Mode.
 - If current operation is Cool mode, outdoor ambient temperature > Cool to Heat Temperature, unit will maintain Cool mode operation or else the unit will operate Heat mode.
 - If current operation is Heat mode, outdoor ambient temperature > Heat to Cool Temperature, unit will maintain Heat mode operation or else the unit will operate Cool mode.
 - Every 60 minutes the outdoor ambient temperature is judged.
 - When Auto + Tank mode is selected, operation mode switching is judged by both outdoor ambient temperature and indoor air temperature.

12.1.8 Auto Cooling Mode Operation Limit



- Auto Mode Cooling Only operation will start once the outdoor ambient temperature reaches 19°C and compressor will continue to run until the outdoor ambient temperature drops to 16°C.
- Due to this limitation, If Heat to Cool temperature is set lower than 19°C, the compressor will not operates until the outdoor ambient temperature reaches 19°C or higher.

12.1.9 Tank Mode Operation

- 3 ways valve direction
 - 3 ways valve switch to tank side during Tank Thermo ON condition. Switch 3 ways valve to room side when tank achieve Tank Thermo OFF temperature.
- Tank Thermo ON/OFF Characteristic
 - o Tank Thermo OFF

Case 1: Internal Tank Heater is select and Tank Heater ON

- Tank temperature > Tank Set Temperature continuously for 15 seconds.
- Water outlet >75°C

Case 2: Tank Heater OFF OR External Heater is select

- When heat pump OFF due to water thermos & Tank temperature > Tank water set temperature for continuously 20 seconds. OR
- Tank temperature > Tank set temperature + 1°C for continuously 20 seconds.

o Tank Thermo ON

Case 1: Internal Tank Heater is select and Tank Heater ON

• Tank temperature < Tank set temperature + R/C (Tank re-heat temperature)

Case 2: Tank Heater select OFF OR External Heater is select

- Tank temperature < Tank water set temperature + R/C (Tank re-heat temperature)
- * When tank thermo ON, water pump will ON for 3 minutes then only heat pump turn ON.
- * Tank water set temperature = tank set temperature or 51°C whichever lower.
- 2 ways valve close
- Heat pump Thermostat Characteristic
 - Heat pump Water Outlet set temperature is set to below table:

Outdoor ambient temperature	Heat pump water outlet temperature
< 5°C	55°C
> 5°C	57°C

Characteristic of heat pump thermos ON/OFF under tank mode condition:

Water Outlet Thermo Condition

- Heat pump thermos OFF temperature:
 - 1 Heat pump thermo OFF temperature = Target Water outlet temperature + (2°C)
 - 2 Water outlet temperature > heat pump thermo OFF temperature for continuously 3 minutes, heat pump OFF but water pump continue ON.
- Heat pump thermo ON temperature:
 - 1 Heat pump thermo ON temperature = water inlet during thermo OFF time + [-3°C]
 - 2 When water outlet temperature < heat pump thermo ON temperature, heat pump ON.

Water inlet thermo protection condition

- Heat pump thermo OFF temperature:
 - 1 Water inlet temperature > [57°C/55°C] for continuously 30 seconds, heat pump OFF, water pump continue ON.
- Heat pump thermo ON temperature:
 - 1 Heat pump thermos ON temp = water inlet temperature < [57°C/55°C].

Outdoor ambient temperature	Water inlet temperature
< 5°C	55°C
>= 5°C	57°C

Thermo ON/OFF for Heat Pump in Tank Operation:

When tank temperature achieve heat pump OFF condition, refer below condition: Condition 1: When Internal Tank Heater is select and Tank Heater ON

• Heat pump will turn OFF, water pump continue ON and room heater will continue ON if tank temperature below tank heater thermo ON condition. 3 ways valve will only switch to room side after tank temperature reach tank heater thermo OFF condition.

Condition 2: When Tank Heater select OFF OR when External Tank Heater is select and Tank heater ON

• If tank temperature achieve tank thermo OFF, heat pump turn OFF, water pump turn OFF, room heater OFF and 3 ways valve switch to room side.

When tank temperature achieve heat pump ON condition, water pump ON, heat pump ON and room heater turn OFF.

Heat pump OFF condition at Tank Mode

- Tank temperature > tank water set temperature continuously for 20 seconds after heat pump thermos OFF due to water thermo. (Heat pump turn OFF but water pump continue ON and room heater turn ON to achieve tank set temperature) OR
- Tank temperature > tank set temperature + [1°C] for continuously 20 seconds. (Heat pump OFF, water pump OFF, room heater OFF and 3 ways valve switch to room side)

Heat pump ON condition at Tank Mode

 Tank temperature < tank water set temperature + R/C setting (Tank re-heat temp) (Water pump turn ON OR continue ON, heat pump ON and 3 ways valve switch to tank side or maintain at tank side)

Internal heater control

• Internal heater only operates to tank side if the Internal Tank Heater is select, Tank heater ON and backup heater is enable.

Internal heater turn ON condition:

- Tank temperature < tank set temperature AND
- Heat pump thermos OFF AND
- 20 minutes from previous heater off AND
- Internal tank heater selects USE from control panel.

Internal heater turn OFF condition:

- Tank temperature > tank set temperature for continuously 15 seconds OR
- Heat pump thermo ON **OR**
- Mode change or operation is off by control panel.

External Heater control

• External heater only operate to tank side if tank heater ON & External Heater select.

12.1.10 Heat + Tank Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch to room side during room heat-up interval and switch to tank side during tank heatup interval. Both modes will switch alternately. Tank mode is the initial running mode of Heat + Tank mode.
- 2 Heat pump operation control:
 - During room heat-up interval
 - Follow normal heating operation.
 Switching to tank side depends to below cases:
 Case 1:
 [Previous switch from tank interval to room interval due to thermo OFF]
 - Switch to tank heat-up interval when Tank temp < Tank thermos ON temp (Room heat-up interval ends)
 - Case 2:

[If heating operation at room side is less than 30 minutes and switch to tank side 3 times consecutively]

 Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank thermo ON temperature. Case 3:

[Previous switch from tank interval to room interval due to tank interval timer is complete]

 Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** tank temperature < Tank thermo ON temperature.

- o During Tank heat-up interval
 - Tank interval is the first mode running when heat + tank mode is select.
 - Switch to room interval only when tank achieve tank thermo OFF OR tank heat-up interval timer is complete.
 - Heat pump operates according to normal tank mode operation.
- 3 Room heater control:
 - During heating heat-up interval
 - Follow normal room heater control operation.
- 4 Tank heater control:
 - During heating heat-up interval
 - If External tank heater is select.
 - External heater ON/OFF according to external tank heater operation control.
 - If internal tank heater is select.
 - Internal tank heater will not function under heating heat-up interval.
 - o During tank heat-up interval
 - If External tank heater is select.
 - Once heating heat-up interval switched to tank heat-up interval, tank heater is turn OFF and tank heater delay timer will start counting.
 - Tank heater will turn ON after tank heater delay timer is fulfill and tank temperature is lower than tank set temperature.
 - Tank heater delay timer is clear when switching to heating heat-up interval.
 - If internal tank heater is select.
 - Internal tank heater will turn ON after heat punp thermo off to boil tank temperature to tank set temperature.
 - o 2 ways valve control is open
 - Indoor water pump control:
 - Indoor water pump always turn ON if room heat pump thermo ON **OR** Tank thermo ON.

12.1.11 Cool + Tank Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch to room side during room cooling interval and switch to tank side during tank heat-up interval. Both mode will switch alternately. Tank mode is the initial mode of cool + tank mode.
- 2 Heat pump operation control:
 - o During room heat-up interval
 - Follow normal cooling operation. Switching to tank side depends to below cases: Case 1: [Previous switch from tank interval to room interval due to thermo OFF]
 Switch to tank best up interval when Tank temperature < Tank Therma
 - Switch to tank heat-up interval when Tank temperature < Tank Thermo ON temperature (Room interval will ends)
 - Case 2:

[If cooling operation at room side is less than 30 minutes and switch to tank side for 3 times consecutively]

 Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank thermo ON temperature. Case 3:

[Previous switch from tank interval to room interval is due to tank interval timer is complete]

 Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** tank temperature < Tank thermo ON temperature.

*Tank Thermo ON temperature:

Internal Tank Heater select USE	<tank (tank="" +="" c="" r="" re-heat="" set="" setting="" temperature="" temperature)<="" th=""></tank>
Others	<tank (tank="" +="" c="" r="" re-heat="" set="" setting="" temperature="" temperature)<="" th="" water=""></tank>

- o During tank heat-up interval
 - Tank interval is the first mode running when the cool + tank mode is select.
 - Switch to room interval only when tank achieve tank thermo OFF **OR** tank heat-up interval timer is complete.
 - Heat pump operates according to normal tank mode operation.
- 3 Room heater control:
 - During room cooling interval
 - Room heater is OFF and not operates.
- 4 Tank heater control:


0

•

- During room cooling interval
- If External tank heater is select.
 - External heater ON/OFF according to external tank heater operation control.
 - If internal tank heater is select and tank heater ON
 - Internal tank heater will not function under room cooling interval.
- o During tank heat-up interval
 - If External tank heater is select.
 - Once room cooling interval switch to tank heat-up interval, tank heater will turn OFF and tank heater delay timer will start counting.
 - Tank heater turns ON after tank heater delay timer is fulfill and tank temperature is lower than tank set temperature.
 - Tank heater delay timer is clear when switch to room cooling interval.
 - If internal tank heater is select and tank heater ON.
 - Internal tank heater will turn ON after heat pump thermos off to boil tank temperature to tank set temperature.
- 5 2 ways vale is close.
- 6 Indoor water pump control:
 - o Indoor water pump always turn ON if room heat pump thermo ON OR Tank thermo ON.

12.1.12 Outdoor Fan Motor Operation


Outdoor fan motor is adjusted according to operation condition. It starts when compressor starts operation and it stops 30 seconds after compressor stops operation.



12.2 Water Pump

12.2.1 Water Pump Control

- Once the indoor unit is ON, the water pump will be ON immediately and no error judgment for 70 seconds. However, during this 70 seconds operation, if there is any abnormality cause at outdoor or malfunction, the compressor should be OFF immediately and restart delay after 3 minutes.
- The system will start checking on the water flow level after operation start for 70 seconds. If water flow level is
 detected low continuously 60 seconds, the water pump and the compressor will be OFF permanently and
 OFF/ON control panel LED will blink (H62 error occurs).
- When error happens, the power has to be reset to clear the error.
- If there is no error indication, the water pump shall be continuously running.
- The water pump will remain ON when compressor OFF due to thermostat OFF setting is reached.
- Water pump will OFF when room thermo OR tank thermo OR buffer tank thermo OFF.
- Water pump will delay 15 seconds to turn OFF when request to OFF except during anti-freeze deice activate or air purge mode.




Maximum pump speed setting on remote control

 Standard pump speed is automatically controlled to get the designed water temperature different between water inlet and outlet (ΔT). Instead of setting the standard pump speed, maximum pump speed is manually adjusted by the installer according to water circuit pressure drop.

However, the following sequences do not follow maximum pump duty setting by remote control.


- Pump down mode
- Air purge mode
- Normal deice



12.2.2 Zone Water Pump Control

Purpose:

 Water pump install at each zone to circulate the water inside each zone during buffer tank connection selected "YES" or 2 zone systems.



Content:

- AC type water pump install for this zone water pump control. When optional PCB connected, 230V output will drive this zone pump.
- There are three pump can be connected through Optional PCB. (Zone 1 Pump, Zone 2 Pump, & Pool Pump)

* Zone 1 pump [P1] use to circulate zone 1 water circuit & Zone 1 mixing valve [M1] adjust to control the Zone 1 target water temperature.

* Zone 2 pump [P2] use to circulate zone 2 water circuit & Zone 2 mixing valve [M2] adjust to control the Zone 2 target water temperature.

* When Pool Function select as Zone 2 circuit, [P2] use to circulate water to heat exchanger which use to transfer heat to pool water.

* Pool pump [P3] circulates the pool water through the heat exchanger to get warm water.

- Zone 1 and Zone 2 water pump start condition:
 - Zone room request ON (eg. Zone 1 thermo ON, only zone 1 pump will turn ON)
- Zone 1 and Zone 2 water pump stop condition:
 Zone room request OFF
 - Pool water pump start condition: • Pool Zone request ON AND
 - Pool Zone request ON All
 Pool function is selected
 - Pool water pump stop condition
 - Pool zone: Zone room request OFF OR
 - Pool function is cancel

* Zone 1 & Zone 2 water pump need to turn OFF when antifreeze deice pump stop control activate and turn ON back after the antifreeze deice pump stop control end under setting of "NO" buffer tank connection.

Zone Pump Prohibit ON control:

- Start condition: Zone 1 water temperature ≥ 75°C continuously for 5 minutes *stop zone water pump operates if the zone water fulfilled.
- Cancel condition: After 30 minutes from start condition fulfilled.
 *zone water pump operates according to normal condition.

Zone Pump Control during Anti-Freeze

Zone pump control during Zone Anti-Freeze Control:

- When Zone Anti-Freeze Flag=1, Zone Pump Turn ON.
- When Zone Anti-Freeze Flag=0, Zone Pump Turn OFF.
- Zone pump control during Indoor Anti-Freeze Control:
- Zone pump only ON/OFF if the Extension PCB connected and Buffer Tank select "NO" condition


When Indoor Anti-Freeze flag=1, Zone Pump Turn ON

When Indoor Anti-Freeze flag=0, Zone Pump Turn OFF

* Pool Water Pump will not affected by both Indoor anti-freeze control or zone anti-freeze control.

12.2.3 Water Pump Speed Feedback Error

- Basically pump speed feedback is control by micon.
- When pump speed is below low limit or over high limit for a few seconds, micon detect pump error and system is stopped.
- Error detection conditions:
 - o Detect abnormal water pump speed for continuous 10 secs.
 - Current pump speed < 700 rpm or
 - Current pump speed > 6000 rpm for 10 seconds.
- Control contents:
 - When error occurs, water pump, heating and heater is stopped for 30 seconds then restart again (Retry control).
 - When micon detect error again, system is stopped and error code [H20] is displayed at control panel.




12.3 Indoor Unit Safety

12.3.1 Indoor Unit Safety Control

- 1 When water pump is ON, the system will start checking flow switch status (ON/OFF).
- 2 If the flow switch ON for 10 seconds, the system will check on the water inlet temperature for 10 seconds. If the water inlet temperature not exceeds 80°C, the water pump shall be continuously running with normal mode.

If the water inlet temperature exceeds 80°C for continuously 10 seconds, the water pump will be OFF immediately.

3 After water pump OFF for more than 10 minutes, it will be ON back and the indoor unit safety control checking is restarted.



12.4 Auto Restart Control

1 When the power supply is cut off during the operation of Air-to-Water Heatpump, the compressor will reoperate after power supply resumes.

12.5 Indication Panel

LED	Operation
Color	Green
Light ON	Operation ON
Light OFF	Operation OFF

Note:

• If Operation LED is blinking, there is an abnormality operation occurs.

12.6 Indoor Back-Up Heater Control

12.6.1 Indoor Electric Heater Control

- 1 Normal Heating Mode
 - Heater On condition:
 - a. Heater switch is ON
 - b. After Heatpump thermo ON for [30] mins
 - c. After water pump operate [9] mins
 - d. Outdoor air temperature < Outdoor set temperature for heater
 - e. When water outlet temperature < Water set temperature + [-4°C]
 - f. [20] minutes since previous Backup heater Off
 - * When heatpump cannot operate due to error happens during normal operation, heater will go into force mode automatic
 - * Heater need to operate during deice operation
 - Heater Stop Condition:
 - a. When outdoor set temperature > outdoor set temperature + [+2°C] for continuous 15 secs OR
 - b. When water out temp> water set temperature + [-2°C] for continuous 15 secs OR
 - c. Heater switch is Off OR
 - d. Heatpump thermo-off or OFF condition
- 2 Force Heater Mode
 - Heater On condition:
 - a. After water pump operate [9] mins
 - b. When water outlet temperature < water set temperature + [-4°C]
 - c. [20] minutes since previous Backup heater Off
 - Heater Stop condition
 - a. Force mode off OR
 - b. When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs
- * Do not operate heater at the following situation
- 1 Water outlet temperature sensor, and water inlet sensor abnormal
- 2 Flow switch abnormal
- 3 Circulation pump stop condition

12.6.2 Room Heater Operation during Deice

Purpose:

• To protect the indoor Heat Exchanger from ice forming and prevent heat exchanger plate breakage.

Control content:

- This Heater protection control will activate only if the backup heater is enable at custom setup by remote controller. Once fulfil the start condition, room heater will turn ON together (base on max heater capacity selection) and stop together if stop condition is fulfilled.
 * If the heater is request to turn ON OL B feedback will be detected.
 - * If the heater is request to turn ON OLP feedback will be detected.

Starting conditions:


- During normal deice operation 4~9
- Water outlet temperature < 10°C or Outdoor air temperature < -10°C or Water inlet temperature < 27°C

Heater operates when 1 \sim 2 fulfilled **OR** When 1 and 3 \sim 4 is fulfilled. However, this control does not relate to Heater ON/OFF button on remote control.

Stop condition:

- When normal deice end or
- Water outlet temperature > 45°C

However, room heater keeps ON if indoor electric heater control activate.



* Backup heater must Turn OFF if the water pump turn OFF.

12.7 Tank Heater Control

12.7.1 Tank Heater Remote Control Setting

1 Tank heater selection:

External: - Booster Heater use to heat up tank when select external Internal: - Backup Heater use to heat up tank when select internal * When select External Tank Heater, Heater Delay ON Timer need to set. (range 20 min ~ 3 hrs)


2 Tank Heater ON/OFF selection by user.

The remote control Tank set Temperature range will change according to the External and Internal Tank Heater use.

Tank Heater Selection	Range
External	40 ~ 75°C
Internal	40 ~ 65°C

12.7.2 External Heater Control at Tank Side

Heating operation condition:




- Tank heater Turn On condition:
 - 1 External Heater selected for Tank heater by remote controller.
 - 2 Tank Heater select ON by user.
 - 3 Tank mode operation ON (Tank mode, Heat + Tank, or Cool + Tank).
 - 4 After TANK HEATER DELAY TIMER fulfill during heat pump startup time in tank mode, or during switching from heating heat-up interval to tank heat + up interval in heat + tank mode.
 - 5 Tank temperature < tank set temperature +[Remote controller Set Tank Re-heat Temp] + [-1°C].
 - 6 20 minutes since previous heater off.

* TANK HEATER DELAY TIMER is clear when tank heat-up interval end.

- Tank heater Turn Off condition:
 - 1 Tank temperature > tank set temperature + [0°C] for continuous 15 seconds.
 - 2 When BOOSTER HEATER DELAY TIMER start count after switch from heating heat-up interval to tank heatup interval.
 - 3 Tank Heater select OFF by user.
 - 4 Tank Mode Operation OFF.

12.7.3 Internal Heater Control at Tank Mode

- Internal heater turn On condition:
 - 1 Internal Heater select for Tank heater by remote controller
 - 2 Tank Heater select ON by user.
 - 3 Backup Heater Enable
 - 4 Tank Temperature < Tank Set Temperature
 - 5 Heat Pump Thermo OFF
 - 6 20 minutes from previous heater off.
- Internal heater turn OFF condition:
 - 1 Tank Temperature > Tank Set Temperature + [0°C] for continuous 15 seconds. OR
 - 2 Heat Pump Thermo ON OR
 - 3 Mode Change or Operation OFF by remote controller OR
 - * Backup Heater Turn ON/OFF all together according to the selected heater capacity.



12.8 Base Pan Heater Control (Optional)

- To enable the base pan heater function, control panel initial setting has to be manually adjusted by activating Base Pan Heater menu.
- There are 2 optional start condition can be selected, Type A or Type B.
- Control details:

1

- Type A: (Default Auto Mode)
 - <u>Start conditions:</u> • When outdoor air temperature $\leq 3^{\circ}$ C during heating and deice operation is ON.

Control contents:

• Base pan heater is ON during deice operation and continues ON for 10 minutes after deice operation ends.

Cancel condition:

- When outdoor temperature > 6°C after deice end or
- o When operation is not at heating mode or
- o Base pan heater ON timer count is completed.
- 2 Type B: (ON Mode)

Start conditions:

• When outdoor air temperature is \leq 5°C and operates in heating mode, base pan heater is ON.

Cancel conditions:

- When outdoor air temperature is > 7°C or
- When operation is not at heating mode.

12.9 Heater Turn ON/OFF priority Control

Purpose:

 To allow only one heater between room and tank heater to turn ON at the same time due to both heater power supplies is sharing the same ELCB. Prohibit two heater sources to turn ON at the same time to avoid overcurrent.

Start condition:

- Tank heater function select YES by remote controller

Control contents:

1

- When there is only one heater source (Room Heater or Tank Heater) request to turn ON, operate same as normal room heater and tank heater operation.
- When both backup heater and booster heater request to turn ON at same time, will turn ON only ONE heater source. Under normal condition, tank heater has priority to turn ON except below condition.
 - Backup Heater Priority to Turn ON when
 - Request Backup heater turn ON at Hex Protection control during deice.
 - o Request Backup Heater turn ON at Hex Protection Control during low water temperature.
 - o Request Backup Heater turn ON at Anti-frost control.
 - Heat pump error and Force Mode operate.
- When switching from booster heater to backup heater OR backup heater to booster heater, need to delay 5 seconds in between Turn OFF one heater source and Turn ON another heater source.

12.10 Force Heater Mode

Purpose of Force Heater Mode

 As a backup heat source when heat pump error. Force heater Mode control backup heater to heat up the room circuit, and turn ON back up heater or booster heater to boil up tank water base on the tank heater selection (internal or external)

Force Heater Control start condition:

- Force heater request ON by user OR auto turn ON by remote controller during error AND (Force Heater mode can be operate regardless of mode selection, remocon will send the latest mode selection and force bit to indoor. Indoor will judge to turn ON heater to room side if it is heat mode selected, and turn ON heater to heat up tank water base on tank heater selection)
- During Error Happen (exclude the error list below)

Error List not allow Force Heater Operation

H12	Capacity Mismatch	H76	Indoor-Remote Controller Communication Error
H20	Abnormal Water Pump	H95	Abnormal Voltage Connection
H62	Abnormal Water Flow	F37	Abnormal Water Inlet sensor
H70	Abnormal Back-up Heater OLP	F45	Abnormal Water Outlet sensor
H74	PCB Communication Error		
[When tank mode operate with external heater selected & tank heater select ON]			
H72	Abnormal tank sensor	H91	Abnormal tank heater OLP

Force Heater Control Stop Condition:

- Force Heater request OFF OR
- Operation OFF request OR
- Power reset **OR**
- Error of above list happens during force heater operation.

Control contents:

- 1) After fulfil start condition, indoor will operate the force heater operation according to below mode condition
 - Heat mode Only : Turn ON backup heater to achieve room heat pump target water temperature.
 - Heat + Tank mode : Turn ON backup heater to heat up room **OR** Turn ON Heater to Boil up tank water. Cool mode Only
 - : Water pump and backup heater will OFF in force heater mode
 - Cool + Tank mode : Operate pump and internal Heater OR External heater to Boil up tank water.
 - Tank mode Only : Operate pump and internal Heater OR External heater to Boil up tank water.
 - * For heat mode condition, backup heater will only turn ON if the backup heater is enable regardless of Room Heater Selection

* For tank mode condition, If internal heater selected backup heater will turn ON to boil up tank water. If external heater selected, booster heater will turn ON to boil up tank water regardless of tank heater selection

Room Side: (Heat Mode)

- 1) When force heater mode start condition fulfilled, turn ON water pump and turn ON backup heater follow below control.
- 2) Operate the 3 ways valve at room side only and turn ON 2 ways valve as heat mode operation.
- 3) Turn ON the zone pump and mixing valve if system select 2 zone system or Buffer tank connect YES, control according to normal zone pump and mixing valve control.
- 4) When Force heater mode stop condition fulfilled, turn OFF heater as below condition and turn OFF water pump after pump delay time.

Backup Heater On Condition:

- a) When Force Heater Control start condition fulfill AND
- b) After water pump operate 2 minute AND
- c) When water outlet temperature < water set temperature + [-4°C] AND
- d) 20 minutes since previous Backup heater Off AND
- e) Backup Heater Enable

Backup Heater Stop condition

- a) Force mode off OR
- b) Operation off **OR**
- c) When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs **OR** * ON/OFF follow normal heater sequence.

Tank side (Tank mode)

- 1) When tank mode select and force heater bit received, turn ON backup heater (INTERNAL) or Booster Heater (External) depend on the tank heater selection.
- 2) If tank heater selection is INTERNAL, follow normal thermo judgement to switch 3 ways valve to tank side and room side.
- If tank heater selection is EXTERNAL, only turn ON booster heater according to tank thermo.

Tank Heater selection is INTERNAL:

Backup Heater ON Condition:

- a) After water pump operate 2 mins AND
- b) When tank temperature < Tank set temperature [Remocon Set Tank Re-heat Temp] AND
- c) 20 minutes since previous backup heater OFF AND
- d) Backup heater enable

Backup Heater OFF Condition:

- a) Force mode OFF OR
- b) When tank temperature > Tank set temperature for continuous 15 secs **OR**
- c) Tank Operation OFF

Tank Heater selection is EXTERNAL:

Backup Heater ON Condition:

- a) Force Heater mode ON AND
- b) Tank temperature < tank set temperature + [Remocon Set Tank Re-heat Temp] 1°C, AND
- c) 20 minutes since previous heater off.

Backup Heater OFF Condition:

- a) Tank temperature > tank set temperature for continuous 15 sec
- b) Force mode OFF
- c) Tank Mode Operation OFF (During tank interval or tank mode condition, water pump and 3 ways valve will OFF)

12.11 Powerful Operation

Powerful mode is use to increase the capacity of heat pump to achieve higher target temperature. Powerful mode is applicable when heat mode is operating.

Remote control setting:

On quick menu of remote control, there is 4 options of powerful mode can be select.

- OFF : Cancel powerful mode
- 30 minutes : Set powerful for 30 minutes
- 60 minutes : Set powerful for 60 minutes
- 90 minutes
 : Set powerful for 90 minutes

Control contents:

During the time set by remote control, powerful will activate according to 2 shift up controls. However, this function is applicable only for heating. Remote control will transmit the signal to indoor unit once this function is select then transmit OFF signal to indoor when the timer is complete. Indoor will transmit signal to outdoor for frequency control.

Indoor setting temperature shift

- If system is standard system (Optional PCB is not connected)
 - Target water temperature will shift up to WIo or Whi whichever higher.
- If system is extension system (Optional PCB is connected)
 - o Target water Zone 1 and Zone 2 temperature will shift up to Wlo or Whi whichever higher.

* If "Direct Type" temperature control is select, this powerful shift up setting is not effective.

- Start condition
 - o Powerful function is select by remote control.
- End Condition
 - OFF/ON button is pressed.
 - o Powerful function is OFF by remote control.

12.12 Quiet Operation

Quiet mode is use to reduce the noise of outdoor unit by reducing the frequency or fan speed.

Quiet level

There are 3 level (Level 1, Level 2, Level 3) to set by quick menu function on remote control.

Control content

Once the quiet function is select, the remote control will transmit the signal to indoor and outdoor unit.

Start condition

- Quiet mode is set on remote control.
- Quiet mode is request ON by weekly timer.

Stop condition

If any of below condition is achieve.

- OFF/ON button is pressed.
- Quiet mode is OFF by remote control.
- Quiet mode is request OFF by weekly timer.


12.13 Sterilization Mode

- Purpose:
 - To sterilize water tank by setting the required boiling temperature.
- Remote control setting
 - o Days for sterilization function to start can be select.
 - o Time of selected day to start sterilization function.
 - Boiling temperature (External heater is 55°C ~ 75°C, Internal heater is 55°C ~ 65°C)
 - Maximum operation time is 5 minutes to 1 hour.
- Start condition
 - o Tank connection set to "YES" by remote control
 - Sterilization function selects "YES".
 - o Sterilization signal received from remote controller by timer.
 - Tank mode request ON.
- Stop condition
 - When boiling timer is completed. Boiling timer (Remote control set maximum operation time) start counting once tank achieve boiling set temperature **OR**
 - o After 8 hours of operation since sterilization start.
 - Tank mode request OFF.
- Control content:
 - During sterilization function activation time, target tank set temperature will internally change to boiling set temperature.
 - During sterilization activates, heat pump and heater (external or internal) will operate as normal tank mode to achieve the boiling set temperature.
 - o Sterilization operation will end when stop condition is fulfill.
 - o After sterilization is complete, tank set temperature will resume to normal operation.

* Tank temperature may not achieve boiling set temperature if tank heater is select OFF **OR** external compressor switch.

12.14 Outdoor Ambient Thermo OFF Control

- Purpose
 - Stop provides heating to room side during high outdoor ambient condition.



- Control content
 - Heating outdoor ambient thermos OFF control only applicable when heat pump operate in heat mode. (This control will not activate when running in tank side)
 - Heat pump and water pump will turn OFF when outdoor ambient is higher than outdoor thermo OFF set temperature.
 - Heat pump thermos ON when outdoor ambient < outdoor thermos OFF set temperature + 1°C.

12.15 Alternative Outdoor Ambient Sensor Control

Purpose of the Alternative Outdoor Ambient Sensor:

 It is some possibility that the air to water heat pump unit will install at a location where the original ambient sensor is expose to direct sunlight. Therefore, another optional ambient sensor can be connect to indoor PCB and locate at new and better reading location to improve the heat pump performance.

Control Detail:

- Remocon can select either the extra outdoor ambient sensor is connected or not. (YES/NO)
- The alternative outdoor ambient sensor will connect to indoor unit main PCB terminal.
 - o when alternative sensor select NO
 - Original Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
 - Data communication direction : OUTDOOR send outdoor temperature reading to INDOOR.
 - Error judge : OUTDOOR will judge the original outdoor sensor error (F36 display if error detect). No
 judge error on alternative outdoor sensor
 - o when alternative sensor select YES
 - Alternative Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
 - Data communication direction : INDOOR send outdoor temperature reading to OUTDOOR.
 - Error judge : INDOOR will judge the Extra outdoor sensor error only after operation ON request received from remocon.

(F36 display if error detect). No judge error on original outdoor sensor.

12.16 Force DHW mode

Purpose:

When user want to use hot water now, user can press this force DWH mode under the quick menu to operate tank only mode to boil up the tank temperature.

Remocon setting:

Force DHW function can be activate under quick menu.

Control Content:

- When press the Force DHW function during operation OFF condition:
 - When receive this Force DHW bit from remocon, indoor will run tank only mode regardless of the mode selection.
 - After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to operation OFF with previous mode selection.
- When press the Force DHW function during operation ON condition:
 - When receive this Force DHW bit from remocon, indoor will memories the running mode and run tank only mode regardless of the mode selection.
 - After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to previous memories running mode.

* when operation OFF or mode change request from remocon during force DHW mode operation, End force DHW mode and follow the new request operation.

* Once receive force DHW mode from remocon, indoor direct start tank mode and consider tank thermo ON. Thermo OFF only when achieve tank thermo OFF depend on the Tank System Setting.

12.17 Anti Freeze Control

- Anti freeze protection control menu can be set YES or NO by control panel.
 - In heatpump system, there are 3 types of anti freeze control:
- 1. Expansion tank anti-freeze control
 - Expansion tank anti freeze heater ON condition:
 - Outdoor ambient temp. < 3°C
 - Expansion tank anti freeze heater OFF condition:
 - Outdoor ambient temp. > 4°C
 - 2. Water pump circulation anti freeze control
 - Water pump turns ON when <u>ALL</u> below conditions are fulfilled:
 - Heatpump OFF (stand by) OR error occurs.
 - Water flowing flag is ON.
 - Water flow switch is not abnormal.
 - Outdoor ambient temp. < 3°C OR outdoor ambient temp. sensor is abnormal.
 - Water inlet/outlet temp. < 6°C.
 - After 5 minutes from previous water pump OFF.
 - Water pump turn OFF when ANY of below conditions is fulfilled:
 - Outdoor ambient temperature $\geq 4^{\circ}$ C.
 - During -5°C < outdoor ambient temp. < 4°C
 - After water pump ON for 4 minutes, and water inlet temp. ≥ 8°C.
 - Else, shift to back up heater anti freeze control.
 - During outdoor ambient temp. < -5° C
 - After water pump ON for 4 minutes, and water inlet/outlet ≥ 20°C.
 - Else, shift to back up heater anti freeze control.
 - However, if flow switch is abnormal (H62), then water pump circulation anti freeze control will not activate.
 - 3. Back up heater anti freeze control:
 - Back up heater turn ON when <u>ALL</u> below conditions is fulfilled:
 - Water inlet/outlet temp. < 6° C.
 - Water pump circulation anti freeze control activated and water pump ON for 4 minutes.
 - Back up heater turns OFF when ANY of below conditions is fulfilled:
 - Water inlet/outlet temp. > 28°C.
 - Water pump circulation anti freeze control deactivated/water pump OFF.
 - However, if back up heater is abnormal (H70) then back up heater anti freeze control will not activate.

12.17.1 Zone Anti-Freeze Control

 If buffer tank selection is "NO" and Anti- Freeze function select "NO" from remote control, this control cannot activate.

Start condition:

- After [5] min from previous Zone pump off. **AND**
- Outdoor air temp < [3] °C OR Outdoor sensor is abnormal. AND
- Zone water temperature < [6]°C **OR** Zone Sensor Short or Open

Cancel condition:

- After water Zone pump ON [4] min AND
- Outdoor air temp ≥ [4]°C OR
- During -5 °C ≤ Outdoor air temp < [4] °C OR Zone water temperature sensor > [8] °C
- During Outdoor air temp < [-5] °C
 Zone water temperature sensor > [20] °C
 *However, Zone water temperature sensor is Open or Short, Condition C and D is ignored.


12.18 Solar Operation (Optional)

12.18.1 Solar Operation:

Solar function:

 This function allow user to control the solar pump to operate depend on the solar sensor reading compare to the tank installed. Solar pump will circulate the hot water energy store at solar panel to heat up the DHW Tank or Buffer Tank.

Solar Connection Diagram:



- Solar function can only enable when the Optional PCB is connected.
- Few part as below need to install to control the solar operation:
 - Solar Panel
 - o Solar Pump
 - o Solar Panel Sensor
 - Tank Sensor (Buffer tank sensor OR DHW Tank sensor depend on the connection direction)
 * During Solar Connection to the system, installer need to alert on the high water temperature may flow to the zone circuit or DHW piping circuit. Therefore pipe which withstand higher water temperature need to be installed.
- Solar remote control setting
 - 1 Solar Setting can only be set when the optional PCB connection is select "YES"
 - 2 By remote controller, Setting as below list can be set for solar function operation (Installer Menu)
 - Solar Function ("YES" or "NO)
 - Tank Connection Direction ("DHW TANK" or "BUFFER TANK")
 - Delta T turns ON: Difference temperature setting between solar panel sensor and Tank to turn on solar pump. (Range :5 ~ 15°C)
 - Delta T turns OFF: Difference temperature setting between solar panel thermistor and Tank to turn off solar pump. (Range :2 ~ 10°C)
 - Outdoor temp for Anti-Freeze : Outdoor temp to start Anti-Freeze control for solar circuit. (Range : -20 ~ 10°C)
 - Tank Temperature HI Limit Set (Range : 70 ~ 90°C)

12.18.2 Solar Operation Control

• Solar function can only be activate if the solar function selection "YES" from remote control. To achieve hot water from solar panel, indoor need to control the solar pump and circulate hot water from solar panel.

Under normal case:

- Solar pump start condition:
 - Solar panel temperature > Delta T turn on setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) AND
 - Tank temperature (DHW or Buffer) < Solar HI Limit Temp (R/C) AND
 - Operation ON with heat mode (apply to solar connect to "Buffer Tank" case)

* Condition c) ignore if the solar system is connect to DHW tank (control active under operation OFF time for Tank connection case)

- Solar pump stop condition:
 - Solar panel temperature < Delta T turn OFF setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) OR
 - Tank hot water temp >= Solar HI Limit Temp (R/C) + [2]°C

Under solar Anti-freeze protection control:

- Solar pump start condition:
 - Outdoor temp < Outdoor temp setting for Anti-Freeze (R/C)
- Solar pump stop condition:
 - Outdoor temp > Outdoor temp setting for Anti-Freeze + [2]°C

**However, During Cool mode this function cannot activate if Tank selection is "Buffer Tank". **Solar pump can operate even if Heat pump is under error stop.

- Solar operation during error:
 - o During Tank sensor (DHW or Buffer depend on selection) abnormal, Solar operation will not able to function.
 - During Solar Panel sensor detect OPEN (not include SHORT), Solar operation will not able to function too.

12.19 Boiler Bivalent Control

- Boiler is an additional or alternative heat source to heat up the room when necessary.
- Purpose of this control is to turn ON and turn OFF the Boiler output signal when boiler heating capacity needed in the system.
- Boiler is possible to connect to DHW Tank and Buffer Tank depends on the installer.
- Boiler operation parameter need to be set on Boiler itself, indoor do not control the boiler operation direction and
 operation.
- There are Alternative mode, Parallel mode, & Advance Parallel mode available to select by installer to fit to the total system.

Bivalent control selection by remote controller

Remote control setting value:

1 Outdoor Ambient Set = (Range: $-15^{\circ}C \sim 15^{\circ}C$)

• Alternative Mode

• Only one heat source operates at one time, either heat pump or boiler depends on condition.

Control detail:

During Operation ON at Heat mode or Tank mode or Heat + Tank Mode

- o Boiler signal turn ON and heat pump and water pump turn OFF when:
 - Outdoor ambient < Outdoor Ambient Set AND
 - Boiler prohibit flag = 0

** However indoor water pump can operate when Anti-freeze control condition fulfilled.

- Boiler signal turn OFF and heat pump and water pump turn ON when:
 - Outdoor ambient > Outdoor Ambient Set + [2°C] OR
 - Boiler prohibit flag = 1

• Parallel Mode

• Parallel mode allows heat pump and boiler ON at the same time. Boiler operates as an additional heating capacity when low heat pump capacity at low ambient condition.

Control detail:

During operation ON at Heat mode or Tank mode or Heat + Tank mode

- Boiler signal turns ON when:
 - Outdoor ambient < Outdoor Ambient Set AND
 - Boiler prohibit flag = 0
- Boiler signal turns OFF when:
 - Outdoor ambient > Outdoor Ambient Set + [2°C] OR
 - Boiler prohibit flag = 1

Advance Parallel Mode

 Advance parallel mode allow heat pump to operate and turn ON boiler only when ambient and temperature condition is fulfilled.

Remote control setting value:

- 1 Outdoor Ambient Set = (Range : $-15^{\circ}C \sim 15^{\circ}C$)
- 2 Selection of boiler connection direction. (Heat only, DHW only, Heat & DHW)
- 3 Setting data under Heat Direction
 - Start Temperature | START_TEMP |
 - Start Delay Timer | START_TIMER |
 - Stop Temperature | STOP_TEMP |
 - Stop Delay Timer | STOP_TIMER |
- 4 Setting data under DHW Direction
 - Delay Timer | DELAY_TIMER |

Control detail:

С

0

During operation ON at Heat Mode

- Boiler signal turns ON when
 - Outdoor ambient < Outdoor Ambient Set AND
 - Buffer tank temperature < Target Buffer Tank Temperature + [START_TEMP] for [START_TIMER] AND
 - Heat pump operate at room side AND
 - Connection of Boiler to Heating Select "YES" From installer menu AND
 - Buffer Tank connection select "YES" AND
 - Boiler prohibit flag = 0
 - Boiler signal turns OFF when
 - Outdoor ambient > Outdoor Ambient Set + [-2°C] OR
 - Buffer Tank temperature > Target Buffer Tank temperature + [STOP_TEMP] for [STOP_TIMER] OR
 - Heat pump not at room side. OR]
 - Boiler prohibit flag = 1

During operation ON at Tank Mode

• Boiler signal turns ON when

- Outdoor ambient < Outdoor Ambient Set AND
- Heat pump operate at tank side for continuous | DELAY_TIMER | AND
- Connection of Boiler to DWH Tank select "YES" from installer menu. AND
- Boiler prohibit flag = 0
- Boiler signal turns OFF when
 - Outdoor ambient > Outdoor Ambient Set + [2°C] OR
 - Heat pump not operates at tank side. OR
 - Boiler prohibit flag = 1

Boiler prohibit flag control

Purpose:

o For product safety. Boiler signal is OFF when water temperature is too high.

Start condition:

- Water outlet ≥ 85° C continues for 5 minutes.
- Water inlet ≥ 85° C continues for 5 minutes.
- Zone1 water temp ≥ 75°C continues for 5 minutes.
- Zone2 Water temp ≥ 75° C continues for 5 minutes.

Contents:

After start condition fulfilled, set boiler prohibit flag = 1

Cancel condition:

o After 30 minutes from start condition fulfilled.

Contents:

Set boiler prohibit flag = 0

12.20 External Room Thermostat Control (Optional)

Purpose:


1 Better room temperature control to fulfill different temperature request by external room thermostat. Recommended external room thermostat:

Maker	Characteristic
Siemen (REV200)	Touch panel
Siemen (RAA20)	Analog

Connection of external room thermostat:

Wire Connection and thermo characteristic of Siemen REV200:


Setting	L/L1 (H)	Heat Thermo	L/L2 (C)	Cool Thermo
Set Temp < Actual Temp	Open Circuit	OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF



Connect only heating line for heating only model. And connect both heating and cooling line for heat + cool model.

Wire Connection and thermo characteristic of Siemen RAA20:

Setting	L/Y1 (H)	Heat Thermo	L/Y2 (C)	Cool Thermo
Set Temp < Actual Temp	Open Circuit	OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF



Connect only heating line for heating only model. And connect both heating and cooling line for heat + cool model.

Control Content:

- External room thermostat control activate only when remote thermostat connection select YES by Indoor control
 panel.
- When indoor running heat mode, refer thermo On/Off from heating line feedback. And when indoor running cool
 mode, refer thermo On/Off from cooling line feedback.
- Heat pump Off immediately when receive thermo off feedback.


12.21 Three Ways Valve Control

Purpose:


- 3 ways valve is used to change flow direction of hot water from heat pump between heating side and tank side.

Control contents:

- 1 3 ways valve switch Off:
- o During 3 ways valve switch Off time, the hot water will provide heat capacity to heating side.
- 2 3 ways valve switch On:
- o During 3 ways valve switch On time, the hot water will provide heat capacity to tank side.
- 3 Stop condition:
 - During stop mode, 3 ways valve will be in switch off position.



SPDT 3 wire



* During pump down and force mode, fix 3 ways valve in close condition.

* Recommended Parts : SFA 21/18 (Siemens)


12.22 Two Ways Valve Control

Functionality of 2 ways valve:

• Use to allow hot water to floor heating panel or block cold water to floor heating panel.

Control contents:

- 1 When indoor running in heat mode, OPEN the 2 ways valve.
- 2 When indoor running in cool mode, CLOSE the 2 ways valve.
- 3 Stop condition:
 - a. During stop mode, fix 2 ways valve in close condition.




- * During pump down mode, fix 2 ways valve in close condition.
- * During force mode, open 2 ways valve.

* Recommended Parts : SFA 21/18 (Siemens)


12.23 External OFF/ON Control

• Communication circuit between indoor unit and external controller is as per below.



- Maximum length of communication cable is 50 meter.
- Control content:

External Control Switch	Control Panel OFF/ON	Control Panel Power LED	System Status
ON	ON	ON	ON
ON	OFF	OFF	OFF
OFF	ON	ON	OFF
OFF	OFF	OFF	OFF



When External SW connection select "YES" from remocon installer menu:

- Heating or Cooling system will operate normally if the External Switch signal is ON.
- Once the External Switch turn OFF, System Turn OFF (Heat pump, water pump, heater etc...)
- Remocon LED remain ON or OFF according to the current operation request.
- Pop up menu at remocon main screen as above screen to inform customer system stop by External Switch.
- It is possible to press cancel and return to main screen to do change of operation setting while waiting the External Switch turn ON back.
- Remocon LED will always follow the latest changes from remocon.
- If no action on remocon for continuous 5 minutes, the pop up screen will show again on the screen.
- But once the External Switch Turn ON back, pop up screen will disappear and system can operate normally according to the latest operation setting and request.

12.24 External Compressor Switch (Optional PCB)

External compressor switch port can have two purpose of control as below:

- Heat source ON/OFF function (Dip switch Pin 3 on PCB "OFF")
- Heater ON/OFF function (Dip switch Pin 3 on PCB "ON")
- Heat source ON/OFF function

Purpose:

 Heat pump ON/OFF function is use to turn OFF the high power consumption device (Heat pump, & Heater) when there is energy or electric current limitation. Other optional function still can be operate under heat pump and heater OFF condition.

Control Detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & Dip Switch on PCB "OFF" This heat pump ON/OFF function will activate
- The ON/OFF signal of this External Compressor Switch is same as External Switch.
- When the External Compressor Switch is ON:
- Heat pump system operate normally
- When the External Compressor Switch is OFF:
 - o Heat pump, Indoor water pump & Heater (Booster heater & Backup Heater) need to turn OFF
 - \circ $\,$ Solar, Boiler and zone control can be operate follow normal control condition.
 - * pump delay OFF also included in this control

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

• Heater ON/OFF function

Purpose:

• Heater ON/OFF function is use to turn OFF the heater (backup heater & booster heater) when there is energy or electric current limitation. Heat pump and other optional function still can operate.

Control detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & Dip Switch on PCB "ON" This heater ON/OFF function will activate
- When the External Compressor Switch is ON:
- Heat pump and heater operate normally
- When the External Compressor Switch is OFF:
 - Backup heater and booster heater cannot operate even heater request is ON.
 - Heat pump and option function (Solar, Boiler and zone control) can be operate follow normal control condition.

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

12.25 Heat/Cool Switch (Optional PCB)

Purpose:

• User can switch the running mode from heat to cool or cool to heat through external installed Heat/Cool switch. This kind of heat / cool switch may built in inside the field supply room remocon as well.

Control contents:


- Heat/Cool Switch can only be set when Cool Function is "enable" at custom menu setting, & Extension PCB select "YES" & Zone 1 not set "Pool" condition.
- This heat/cool switch control will be activate only when installer set the Heat/Cool Switch "USE" through remocon.
- Once the Heat/Cool Switch Set "USE", remocon will check indoor send Signal to judge the option of mode select.
 - When Heat/Cool Switch Contact Open : Remocon only can select Heat Mode, or Heat + Tank Mode, or Tank Mode
 - When Heat/Cool Switch Contact Close : Remocon only can select Cool Mode, or Cool + Tank Mode, or Tank Mode
- Operation ON/OFF will depend on remocon request.
- When Heat Mode is running with Contact Open, user change this setting to contact close, indoor will this signal to remocon judge and change mode to cool and send back to indoor. And it is same as from cool mode change to heat mode.
 - * This switch have higher priority, remocon follow indoor send signal when control activated.
 - * There is no effect to the operation when the mode running is only Tank Mode.

(Weekly Timer are ignored and cannot be set during Heat / Cool Switch is "Enable" Condition.)

12.26 SG Ready Control (Optional PCB)

Purpose:

• To set ON/OFF of heat pump and target temperature by digital input of third party device if necessary in field.



Remote control setting

For this function, following items need to be set on R/C (installer menu) -

- SG control = YES or NO
- Capacity up setting 1
 - Heating capacity [50 ~ 150 %]
 - DHW capacity [50 ~ 150 %]
- Capacity up setting 2
 - Heating capacity [50 ~ 150 %]
 - DHW capacity [50 ~ 150 %]

Control contents:

If SG control on remote control = "Yes", then following control only activate by digital input.

- While Digital input is " 00 " (Normal operation)
 - Normal operation. Once detect '00' system will operate back to normal condition.
 (All the target set temperature for heating side and DHW side will return back to previous set temperature when digital signal change from "10' or"11" back to "00".)
- While digital input is detected " 01 " (HP stop)
 - Heat pump & room heater & tank heater cannot operate.
 - (Solar control and Boiler back up and 2 Zone control can activate.)
- While digital input is detected " 10 " (Capacity 1)
 - Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting. However, which setting temperature is change depend on system setting.
- While digital input is detected " 11 " (Capacity 2)
 - Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting. However, which setting temperature is change depend on system setting.
- While digital input is detected " 10 " (Capacity 1)
 - Setting temperature for heating and Tank is changed. However, which setting temperature is change depend on system setting.

If Buffer selection is "YES"

Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature * Remote Control setting (" capacity 1) %

- * Max Min regulation is follow Target Buffer tank temperature control specification
- ** No change of Target zone water temperature, only set higher buffer tank temperature.

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 1) % * (Max regulation depend on the tank max setting limit)

If Buffer selection is "NO"

Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature * Remote Control Setting (*Capacity 1) %

(Zone 1 and Zone 2 will change according to its own target zone water temperature.) (Max regulation depend on the temperature control type select)

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 1) % * (Max regulation depends on the tank max setting limit)

• While digital input is detected " 11 " (Capacity 2)

Setting temperature for heating and Tank is changed.
 However, which setting temperature is change depend on system setting.

If Buffer selection is "YES"

Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature * Remote Control setting (" capacity 2) %

* Max Min regulation is follow Target Buffer tank temperature control specification

** No change of Target zone water temperature, only set higher buffer tank temperature.

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 2) % * (Max regulation depends on the tank max setting limit)

If Buffer selection is "NO"

Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature * Remote Control Setting (*Capacity 2) %

(Zone 1 and Zone 2 will change according to it's own target zone water temperature.) (Max regulation depend on the temperature control type select)

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 2) %

- * (Max regulation depends on the tank max setting limit)
- ** This function is not applicable for Cooling mode.

12.27 Demand Control (Optional PCB)

Remote control setting:

• When Optional PCB connection select 'YES", Demand Control function can select "YES" or "NO".

Purpose:

After the demand control select YES, below control will activated.
 0-10V Demand control

0-10V Demand control

• Demand control is use to reduce the current usage of heat pump unit by third party device.

Control start condition:

- Select "YES" at Demand control at installer menu.
- 0-10V input for this electrical current control is detected.

Control content:

- If start condition is fulfilled, indoor will receive the voltage signal from optional PCB. Indoor will send the rate value to outdoor unit.
- Outdoor will change the current limit according to the percentage receive from indoor unit.

12.28 Holiday Mode

• Purpose:

Promotes energy saving by allowing the user to stop the system during holiday and enables the system to resume at the preset temperature after holiday.

- Control details:
 - Indoor operate the unit according running mode request. Target temperature will follow holiday setting temperature.
 - If heat mode request is receive, Target Water Out Temperature will change according to holiday shift temperature set.
 - [If heat is set OFF at holiday, unit, water pump and zone control will OFF]
 - If tank mode request is receive, Target Tank Set Temperature will change according to the holiday tank shift temperature set.
 - [If tank is set OFF at holiday, heat pump and tank heater will OFF]
 - After days of holiday have been set, heat pump will stop and only resume operation at the end of holiday countdown.
- Start condition:
 - Holiday timer set and the holiday timer start
 - * The day holiday mode was set is counted as day 1.
- Stop condition:
 - o OFF/ON button is pressed.
 - Holiday timer is reached.

12.29 Dry Concrete

Purpose:
 Dravida bast

Provide heat to floor heating panel and dry the wet concrete during installation.

- Setting condition:
 - o Dry concrete parameter can be set through remote control under system setup.
 - Parameters are possible to set up to 99 days with different target set temperature
- Control details:
 - o Dry concrete mode will be activates when select ON from service setup.
 - Once start dry concrete function, remote control will send step 1 setting temperature to indoor unit.
 * This temperature is set at zone temperature. If system is 2 zones, both zone target temperature is set as same temperature.
 - Heat pump will start heat mode operation to room side with received target water outlet temperature.
 * Heat pump will operate according to Heat pump Target Water Temperature.
 - After complete day 1 setup operation, day 2 data will be send to indoor at 12.00am on the second day.
 - Each preset data will be send every day until dry concrete mode is complete, unit will turns OFF and exit dry concrete function.
 - o 3 ways valve and booster heater will turn OFF and 2 ways valve will turns ON.
- Cancel condition:
 - o Dry concrete mode is complete and OFF signal is received.
 - OFF signal is received by pressing OFF/ON button.

12.30 Flow Sensor

- The water flow sensor serves as an overload protector that shuts down the unit when the water level is detected to below.
- Abnormal flow detection:

Sequence	Abnormal flow	Normal flow
Normal case	Flow rate < 11 I/min or ≥ 69 I/min	≥ 11 I/min
During status 2~6 on Anti-freeze deice	Flow rate ≥ 11 l/min	< 11 l/min

13. Protection Control

13.1 Protection Control for All Operations

13.1.1 Time Delay Safety Control

1 The compressor will not start for three minutes after stop of operation.

13.1.2 30 Seconds Forced Operation

- 1 Once the compressor starts operation, it will not stop its operation for 30 seconds.
- 2 However, it can be stopped using control panel at indoor unit.

13.1.3 Total Running Current Control

- 1 When the outdoor running current exceeds X value, the compressor frequency will decrease.
- 2 If the outdoor running current does not exceed X value, the compressor frequency will return to normal operating frequency.
- 3 If the outdoor running current continue to increase till exceed Y value, compressor will stop, and if this occurs 3 times within 20 minutes, system will stop operation and OFF/ON control panel LED will blink (F16 error occurs).


	MXC09H3E8		MXC12H9E8		MXC16H9E8	
Operation Mode	X (A)	Y (A)	X (A)	Y (A)	X (A)	Y (A)
Heating	9.4	11.8	10.9	11.8	15.4	16.5
Cooling	6.2	11.8	6.2	11.8	7.7	16.5

A. DC Peak Current Control

- 1 When the current to IPM exceeds set value of 34 A, compressor will stop. Compressor will restart after three minutes.
- 2 If the set value exceeds again for more than 30 seconds after the compressor restarts, operation will restart after two minutes.
- 3 If the set value exceeds again for within 30 seconds after the compressor restarts, operation will restart after one minute. If this condition repeats continuously for seven times, system will stop operation and OFF/ON control panel LED will blink (F23 error occurs).

13.1.4 Compressor Overheating Prevention Control


 The compressor operating frequency is regulated in accordance to compressor tank temperature as shown in below figures. When the compressor tank temperature exceeds 107°C, compressor will stop, and if this occurs 4 times within 30 minutes, system will stop operation and OFF/ON control panel LED will blink (F20 error occurs).



13.1.5 High Pressure Sensor Control

- Purpose:
 - To protect the system operation.
- Detection period:
- After compressor on for 1 minute.
- Detection conditions:
- When abnormal high voltage detection, 5 V or when open circuit detection 0V for 5 seconds continuously.
- After detection:
 - When abnormality is detected 4 times within 120 minutes, unit stop operation.
 - OFF/ON control panel LED will blink (H64 error occurs).

13.1.6 Outside Temperature Current Control



Outdoor temperature

13.1.7 Crank Case Heater Control

- Purpose:
- For compressor protection during low outdoor ambient operation (during heating low temperature operation).
- Control content:
 - a. Trigger heater START condition
 - When the outdoor air temperature is below than 5°C, and discharge temperature is 11°C or below.
 - b. Resetting heater STOP condition
 - 1. When the outdoor air temperature exceeds entry condition (2°C)
 - 2. When the discharge temperature exceeds entry condition (5°C)

13.1.8 Compressor Cold Start Prohibition Control

- Purpose:
 - Protect compressor when poor compressor oil return at low outdoor ambient and high water temperature condition.
- Control content:
 - Do not run compressor when below condition fulfilled
 - a. Compressor top temperature < 10°C
 - b. Outdoor ambient < -20°C
 - c. Water temperature > 40°C

13.2 Protection Control for Heating Operation

13.2.1 Outdoor Air Temperature Control


The maximum current value is regulated when the outdoor air temperature rises above 14°C in order to avoid compressor overloading.

13.2.2 Deice Operation


When outdoor pipe temperature and outdoor air temperature is low, deice operation start where outdoor fan motor stop.

• Deice judging condition

Outdoor Unit Deice Control



- Deice mode selection condition
 - There are 2 deice modes, according to water inlet temperature and outdoor ambient temperature the deice mode is decided.




Judgement details:

- 1 When water inlet temperature is more than 50°C, unit will operate deice mode 1.
- 2 When water inlet temperature is less than 27°C, unit will operate deice mode 2.
- 3 When water inlet temperature is less than 50°C and outdoor ambient temperature is less than -10°C, unit will operate deice mode 2.
- 4 When water outlet temperature sensor 2 detect temperature is less than 22°C, unit will operate deice mode 2.

Deice operation time diagram

a. Deice mode 1 control:




b. Deice mode 2 control:

	Normal Deice	•				mode 2 minutes				Heating operation
Sequence	4~6	1	2	3	4	5	6	7	8	
Compressor										Free
Four way valve	OFF	ON								ON
OD fan	OFF		OFF							Free
Main Expansion valve Bypass Expansion valve	0									Free Free
Gas Bypass SV	OFF		ON							OFF
Pump	ON		OFF							ON

13.3 Protection Control for Cooling Operation

13.3.1 Outdoor Air Temperature Control

- The Compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.
- This control will begin 1 minute after the compressor starts.
- Compressor frequency will adjust base on outdoor air temperature.



13.3.2 Freeze Prevention Control 1

- 1 When indoor heat exchanger temperature is lower than 0°C continuously for 10 seconds, compressor will stop operating.
- 2 Compressor will resume its operation three minutes after the indoor heat exchanger is higher than 1°C.
- 3 Indoor heat exchanger freeze prevention (H99) will memory in error history.

14. Servicing Mode

14.1 Expansion Vessel Pre Pressure Checking

[Upper limit water volume of the system] The Mono bloc unit has a build-in Expansion Vessel with 10 L air capacity and initial pressure of 1 bar.

• Without antifreeze agent condition

Total amount of water in the system should be below 200 L.

If the total amount of water is more than 200 L, please add expansion vessel (field supply).

• With antifreeze agent condition

In the case of using antifreeze agent, expansion rate $\boldsymbol{\epsilon}$ is different depending on its maker.

Please refer to the antifreeze agent maker for the expansion rate ϵ before calculate the upper limit water volume of the system.

The expansion vessel capacity required for the system can be calculated from the formula below.

$$\mathbf{V} = \frac{\varepsilon \times V_0}{\mathbf{1} - \frac{98 + P_1}{98 + P_2}}$$

V : Required gas volume <expansion vessel volume L>

Vo : System total water volume <L>

- ϵ : Expansion rate 5 \rightarrow 60°C = (depends on antifreeze agent used)
- P_1 : Expansion tank filling pressure = (100) kPa
- P_2 : System maximum pressure = 300 kPa

() Please confirm at actual place

- The gas volume of the sealed type expansion vessel is presented by <V
- It's advised to add 10% margin for required gas volume of calculation.


[Adjustment of the initial pressure of the expansion vessel when there is a difference in installation height] If the height difference between the Mono bloc unit and the highest point of the system water circuit (H) is more than 7m, please adjust the initial pressure of the expansion vessel (Pg) according to the following formula.

14.2 Maintenance

• In order to ensure optimal performance of the unit, seasonal inspections on the unit, functional check of RCCB, field wiring and piping have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer.

14.2.1 Maintenance for Water Filter Set


- 1. Remove the Cover by loosening the mounting screws to access to the Water Filter Set.
- 2. Turn OFF power supply.
- 3. Set the two valves for the Water Filter Set to "CLOSE".
- 4. Take off the clip, then gently pull out the mesh. Beware of small amount water drain out from it.
- 5. Clean the mesh with warm water to remove all the stain. Use soft brush if necessary.
- 6. Reinstall the mesh to the Water Filter Set and set back the clip on it.
- 7. Set the two valves for the Water Filter Set to "OPEN".
- 8. Turn ON power supply.
- 9. After cleaning, reinstall the Cover by tightening the mounting screws properly.



Do not add or replace other than R410A type. It may cause product damage, burst, injury and etc. Use compatible R410A tools for refrigerant piping work and refrigerant charging during installation or servicing.

14.3 Pump Down Procedures

Refer below steps for proper pump down procedure.



-

Pump down operation in progress!

[①]OFF

Ψ

2 22


3:04pm,Mon

.....

[①] Start


Р

14.4 How To Adjust Pump Speed



Press ▲ or ▼ SW to select & confirm operation

14.5 How To Adjust Pump Speed




Press 🔺 or 🔻 SW to select & confirm operation

NOTE:

- 1. Whenever at [Screen 5], if press (SW to OFF, pump operation should be turned OFF.
- 2. Whenever at [Screen 6], if press 🕑 SW to OFF, pump operation should be turned OFF.

14.6 How To Unlock Cool Mode

Operation must be OFF



Custom menu	3 24pm,Mon
Cool mode	
Ena	able
Dis	able
	1
-select [-	⊔]Confirm ⊃
▲ ↓	▲ ▲
Custom menu	3:25pm,Mon
Cool mode	
Ena	able
Disa	able
[▲] Select [4]Confirm


14.7 EEPROM Factory Default Data Setup Procedure

nitializatior	1	12:00,Mor
h	nitializing	
5		:≡
•	↓	
		ি

- EEPROM default data setup is only possible during initialization process.

- Press (**A**, **V**, **(**, **)**) simultaneously for 5secs continuously, initialization process will stop & EEPROM default data setup process will start.


During EEPROM default data setup process, display should be as shown below.




- Once EEPROM default data setup process is complete, initialization process will re-start from beginning.

Initialization	12:00,Mon	←──	· Real time and date will blink
Initializing .			

14.8 Dry Concrete Setup



Next Page



Return to [Screen 6]


15. Maintenance Guide

In order to ensure safety and optimal performance of the unit, seasonal inspections on the unit, functional check of RCCB/ELCB, field wiring and piping have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer. Contact dealer for scheduled inspection.

1 Water pressure


Water pressure should not lower than 0.05 MPa (with inspects the Water Pressure Gauge). If necessary add tap water into Tank Unit. Refer to Tank unit installation instruction for details on how to add water.

- 2 Pressure relief valve
 - o Check for correct operation of Pressure Relief Valve by turning on the lever to become horizontal.
 - If you do not hear a clacking sound (due to water drainage), contact your local authorized dealer.
 - Push down the lever after finish checking.
 - In case the water keeps drained out from the unit, switch off the system, and then contact your local authorized dealer.



3 Air purge valve

Air purge valve must be installed at all high points in a closed water circuit system. An automatic air purge valve is provided inside the indoor unit. To automatically purge the air from the system, turn the plug on the air outlet anticlockwise by one complete turn from fully closed position. Excessive air is automatically purged if the plug is kept in this position.



4 Indoor unit control board area

Thorough visual inspection of the control board and look for defects, i.e. loose connection, melting of wire insulator and etc.

5 RCCB/ELCB

Ensure the RCCB/ELCB set to "ON" condition before check RCCB/ELCB. Turn on the power supply to the Indoor Unit. This testing could only be done when power is supplied to the Indoor Unit.

Be careful not to touch parts other than RCCB/ELCB test button when the power is supplied to Indoor Unit. Else, electrical shock may happen.

- Push the "TEST" button on the RCCB/ELCB. The lever would turn down and indicate "0", if it functions normal.
- o Contact authorized dealer if the RCCB/ELCB malfunction.
- Turn off the power supply to the Indoor Unit.
- o If RCCB/ELCB functions normal, set the lever to "ON" again after testing finish.

Reset overload protector 6

Overload Protector a serves the safety purpose to prevent the water over heating. When the Overload Protector a trip at high water temperature, take below steps to reset it.

- a. Take out the cover.
- b. Use a test pen to push the centre button gently in order to reset the Overload Protector.
- Fix the cover to the original fixing condition. C.



Use test pen to push this button for reset Overload protector.

15.1 Maintenance Menu

15.1.1 Service and maintenance

When connect CN-CNT connector with computer

Please use optional USB cable to connect with CN-CNT connector.

After connected, it requests for driver. If PC is under Windows Vista or later version, it automatically installs the driver under internet environment.

If PC uses Windows XP or earlier version and there is no internet access, please get FTDI Ltd's USB - RS232C conversion IC driver (VCP driver) and install.

http://www.ftdichip.com/Drivers/VCP.htm

If forget Password and cannot operate remote controller

Press \rightarrow + \rightarrow + \rightarrow for 5 sec. Password unlock screen appears, press Confirm and it shall reset Password will become 0000. Please reset it again.

(CAUTION) Only display when it is locked by password.

15.1.2 Maintenance menu

Setting meth	od of Mainten	ance menu	
Maintenance n	nenu	17:26, We	ed
Actuator check	ĸ		
Test mode			
Sensor setup			
Reset passwor	rd		
🚽 Select	C [لم]	onfirm	
Press + + + + + + + + + + + + + + + + + +	be set eck (Manual ON As there is no j careful not to c	I/OFF all funct protection action ause any erro	. ,
② Test mode (Normally it is			
within -2~2°		y when sensor	

④ Reset password (Reset password)

15.1.3 Custom menu

Setting method of Custom menu
Custom menu 17:26, Wed
Cool mode
Back-up heater
Reset energy monitor
v Select [↓] Confirm
Please press 📃 + ▼ + ◀ for 10 sec.
Items that can be set ① Cool mode (Set With/Without Cooling function) Default is without
(CAUTION) As with/without Cool mode may affect electricity application, please be careful and do not simply change it.
In Cool mode, please be careful if piping is not insulated properly, dew may form on pipe and water may drip on the fl oor and damage the fl oor.
 Backup heater (Use/Do not use Backup heater) (CAUTION) It is different from to use/not to use backup heater set by client. When this setting is used, heater power on due to protection against frost will be disabled. (Please use this setting when it is required by utility company.) By using this setting, it cannot defrost due to low Heating's setting temp and operation may stop (H75)
Please set under the responsibility of installer. When it stops frequently, it may be due to insuffi cient circulation fl ow rate, setting temp of heating is too low etc.
③ Reset energy monitor (delete memory of Energy monitor) Please use when moving house and handover the unit.

15.1.4 Specifications

15.1.4.1 Specifications of fresh water was heat transfer medium in brazed heat exchanger

Parameter	Quality Limits for Tap Water on the Secondary Side
Temperature	Below 60°C
рН	7 to 9
Alkalinity	60mg/I <hco<sub>3 <300mg/I</hco<sub>
Conductivity	< 500µS/cm
Hardness	[Ca ⁺ , Mg ⁺] / [HCO ₃ ⁻] > 5
Chloride	< 200mg/l at 60°C
Sulphate	$[SO_4^{2-}] > 100 mg/l and [HCO_3^{-}] / [SO_4^{2-}] > 1$
Nitrate	NO ₃ < 100mg/l
Chlorine	< 0.5mg/l

15.1.4.2 External filter

Solids in the water must be filtered.

Minimum filter mesh size required for the field supply external filter in the water inlet is 20 mesh.

16. Troubleshooting Guide

16.1 Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle.


Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan.

The normal pressure of the refrigeration cycle depends on various conditions, the standard values for them are shown in the table on the right. Normal Pressure (Standard)

	Gas pressure MPa (kg/cm²G)	
Heating Mode	2.3 ~ 2.9 (23 ~ 29)	
Cooling Mode	0.9 ~ 1.2 (9 ~ 12)	

 ★ Condition: ● Outdoor temperature 7°C at heating mode and 35°C at cooling mode.
 ● Compressor operates at

rated frequency.



16.2 Relationship between the Condition of the Air-to-Water Heatpump Indoor and Outdoor Units and Pressure and Electric Current

	Heating Mode			Cooling Mode		
Condition of the Air-to-Water Heatpump indoor and outdoor units	Low Pressure	High Pressure	Electric current during operation	Low Pressure	High Pressure	Electric current during operation
Water leakage or insufficient water flow rate in the system			-	1	1	1
Excessive amount of refrigerant				*	*	
Inefficient compression		1	1	1	1	1
Insufficient refrigerant (gas leakage)	1	1	1	1	1	1
Outdoor heat exchange deficiency	-	-	~			
Clogged expansion valve or Strainer	~		-			~

• Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

16.3 Breakdown Self Diagnosis Function

16.3.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- When abnormality occur during operation, the system will stop operation, and OFF/ON control panel LED will blink and error code will display on the control panel.
- Even error code is reset by turning OFF power supply or by selecting ERROR RESET, if the system abnormality
 is still unrepaired, system will again stop operation, and OFF/ON control panel LED will again blinks and error
 code will be display.
- The error code will store in IC memory.

• To check the error code

- When an abnormality occurs, system will stop operation and OFF/ON control panel LED will blink.
- Error code of the abnormality will be display on the control panel.
- To determine the abnormality description, the error code table needs to be referred.


 Panasonic


 Image: Pana


Press
Press

- To display past/last error code
 - Turn ON power supply.
 - Refer below procedure to retrieve the error code history.
- To permanently delete error code from IC memory
 - Turn ON power supply.
 - Refer below procedure to clear error history.

eg:







16.4 Error Codes Table

Diagnosis display	sis display Abnormality/Protection control Abnormality judgement		Primary location to verify		
H00	No abnormality detected	_			
H12	Indoor/Outdoor capacity unmatched	90s after power supply	 Indoor/outdoor connection wire Indoor/outdoor PCB Specification and combination table in catalogue 		
H15	Outdoor compressor temperature sensor abnormality	Continue for 5 sec.	Compressor temperature sensor (defective or disconnected)		
H20	Water pump abnormality	Continue for 10 sec.	Indoor PCBWater pump (malfunction)		
H23	Indoor refrigerant liquid temperature sensor abnormality	Continue for 5 sec.	 Refrigerant liquid temperature sensor (defective or disconnected) 		
H27	Service valve error	Continue for 5 minutes	 High pressure sensor (defective or disconnected) 		
H28	Abnormal solar sensor	Continue for 5 sec.	 Solar temperature sensor (defective or disconnected) 		
H31	Abnormal swimming pool sensor	Continue for 5 sec.	 Pool temperature sensor (defective or disconnected) 		
H36	Abnormal buffer tank sensor	Continue for 5 sec.	 Buffer tank sensor (defective or disconnected) 		
H38	Brand code not match	When indoor and outdoor brand code not same	_		
H42	Compressor low pressure abnormality	_	 Outdoor pipe temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB Compressor 		
H43	Abnormal Zone 1 sensor	Continue for 5 sec.	Water temperature Zone 1 sensor		
H44	Abnormal Zone 2 sensor	Continue for 5 sec.	Water temperature Zone 2 sensor		
H62	Water flow switch abnormality	Continue for 1 min.	Water flow switch		
H63	Abnormal low pressure sensor	4 times in 20 minutes	 Low pressure sensor (defective or disconnect) 		
H64	Refrigerant high pressure abnormality	Continue for 5 sec.	 Outdoor high pressure sensor (defective or disconnected) 		
H65	Abnormal deice water circulation	water flow > 7 l/min continously for 20 second during anti freeze deice	Water pump		
H67	Abnormal External Thermistor 1	Continue for 5 sec.	 Room temperature Zone 1 sensor 		
H68	Abnormal External Thermistor 2	Continue for 5 sec.	 Room temperature Zone 2 sensor 		
H70	Back-up heater OLP abnormality	Continue for 60 sec.	 Back-up heater OLP (Disconnection or activated) 		
H72	Tank sensor abnormal	Continue for 5 sec.	 Tank sensor 		
H74	PCB communication error	Communication or transfer error	Indoor main PCB and Sub PCB		
H75	Low water temperature control	Room heater disable and deice request to operate under low water temperature	Heater operation must enable to increase water temperature		
H76	Indoor - control panel communication abnormality	_	 Indoor - control panel (defective or disconnected) 		
H90	Indoor/outdoor abnormal communication	> 1 min after starting operation	 Internal/external cable connections Indoor/Outdoor PCB 		
H91	Tank heater OLP abnormality	Continue for 60 sec.	 Tank heater OLP (Disconnection or activated) 		
H95	Indoor/Outdoor wrong connection		Indoor/Outdoor supply voltage		
H98	Outdoor high pressure overload protection	_	 Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB 		
H99	Indoor heat exchanger freeze prevention	_	Indoor heat exchangerRefrigerant shortage		
F12	Pressure switch activate	4 times occurrence within 20 minutes	Pressure switch		
F14	Outdoor compressor abnormal revolution	4 times occurrence within 20 minutes	Outdoor compressor		
F15	Outdoor fan motor lock abnormality	2 times occurrence within 30 minutes	Outdoor PCBOutdoor fan motor		
F16	Total running current protection	3 times occurrence within 20 minutes	Excess refrigerantOutdoor PCB		

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
F20	Outdoor compressor overheating protection	4 times occurrence within 30 minutes	Compressor tank temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB Compressor
F22	IPM (power transistor) overheating protection	3 times occurrence within 30 minutes	Improper heat exchange IPM (Power transistor)
F23	Outdoor Direct Current (DC) peak detection	7 times occurrence continuously	Outdoor PCB Compressor
F24	Refrigeration cycle abnormality	2 times occurrence within 20 minutes	 Insufficient refrigerant Outdoor PCB Compressor low compression
F25	Cooling/Heating cycle changeover abnormality	4 times occurrence within 30 minutes	 4-way valve V-coil
F27	Pressure switch abnormality	Continue for 1 min.	Pressure switch
F29	Low Discharge Superheat	1 times occurrence within 2550 minutes	 Discharge Temperature sensor Discharge Pressure Sensor Pressure Switch Outdoor PCB
F30	Water outlet sensor 2 abnormality	Continue for 5 sec.	 Water outlet sensor 2 (defective or disconnected)
F32	Abnormal Internal Thermostat	Continue for 5 sec.	Control panel PCB thermostat
F36	Outdoor air temperature sensor abnormality	Continue for 5 sec.	Outdoor air temperature sensor (defective or disconnected)
F37	Indoor water inlet temperature sensor abnormality	Continue for 5 sec.	Water inlet temperature sensor (defective or disconnected)
F40	Outdoor discharge pipe temperature sensor abnormality	Continue for 5 sec.	 Outdoor discharge pipe temperature sensor (defective or disconnected)
F41	PFC control	4 times occurrence within 10 minutes	Voltage at PFC
F42	Outdoor heat exchanger temperature sensor abnormality	Continue for 5 sec.	 Outdoor heat exchanger temperature sensor (defective or disconnected)
F43	Outdoor defrost sensor abnormality	Continue for 5 sec.	 Outdoor defrost sensor (defective or disconnected)
F45	Indoor water outlet temperature sensor abnormality	Continue for 5 sec.	Water outlet temperature sensor (defective or disconnected)
F46	Outdoor Current Transformer open circuit	_	Insufficient refrigerant Outdoor PCB Compressor low
F48	Outdoor EVA outlet temperature sensor abnormality	Continue for 5 sec.	Outdoor EVA outlet temperature sensor (defective or disconnected)
F49	Outdoor bypass outlet temperature sensor abnormality	Continue for 5 sec.	Outdoor bypass outlet temperature sensor (defective or disconnected)
F95	Cooling high pressure overload protection	_	 Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB

16.5 Self-diagnosis Method

16.5.1 Connection Capability Rank Abnormality (H12)

Malfunction Decision Conditions:


During startup operation of cooling and heating, the capability rank of indoor checked by the outdoor is used to determine connection capability rank abnormality.

Malfunction Caused:

- 1 Wrong model interconnected.
- 2 Wrong indoor unit or outdoor unit PCB (main) used.
- 3 Faulty indoor unit or outdoor unit PCB (main).

Abnormality Judgment:

Continue for 90 seconds.



Troubleshooting:

16.5.2 Compressor Tank Temperature Sensor Abnormality (H15)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the compressor tank temperature sensor are used to determine sensor error.


Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:



16.5.3 Water Pump Abnormality (H20)

Malfunction Decision Conditions:


During startup and operation of cooling and heating, the rotation speed detected by the IPM of water pump motor during water pump operation is used to determine abnormal water pump (feedback of rotation > 6,000rpm or < 1,000rpm).

Malfunction Caused:

- 1 Operation stop due to short circuit inside the water pump motor winding.
- 2 Operation stop due to breaking of wire inside the water pump motor.
- 3 Operation stop due to breaking of water pump lead wires.
- 4 Operation stop due to water pump motor IPM malfunction.
- 5 Operation error due to faulty indoor unit PCB.

Abnormality Judgment:

Continue for 5 seconds.



16.5.4 Indoor Refrigerant Liquid Temperature Sensor Abnormality (H23)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor refrigerant liquid temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).


Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.5 Service Valve Error (H27)

Malfunction Decision Conditions:

During cooling operation, when:-


- [a] Indoor refrigerant pipe temperature at compressor startup present indoor refrigerant pipe temperature < 2°C [b] Present high pressure high pressure at compressor startup < 5kg/cm²
- **Judgment only for first time cooling operation and not during pump down operation.

Malfunction Caused:

- 1 3 way valves closed.
- 2 Faulty high pressure sensor.
- 3 Faulty indoor refrigerant pipe temperature sensor
- 4 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 minutes.



16.5.6 Abnormal Solar Sensor (H28)

Malfunction Caused:

- Faulty connector connection.
 Faulty solar sensor.
 Faulty indoor sub PCB.

Abnormality Judgment: Continue for 5 seconds.

Abnormal solar sensor			Caution	For safety reason and to prevent component breakdown, always switch off the power before remove and
				connect the component.
	H28 happens check connection at CN207 normal?	NO	•	Correct sensor connection
	YES			
	Measure resistance of sensor match characteristic?	NO	•	Change solar sensor
	YES			
	Change Indoor sub PCB			


16.5.7 Abnormal Swimming Pool Sensor (H31)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty swimming pool sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

Continue for 5 seconds.




16.5.8 Abnormal Buffer Tank Sensor (H36)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:


Continue for 5 seconds.



16.5.9 Brand Code Not Matching (H38)

Malfunction Caused:

1 Indoor and outdoor brand code not match.




16.5.10 Compressor Low Pressure Protection (H42)

Malfunction Decision Conditions:

During operation of heating and after 5 minutes compressor ON, when outdoor pipe temperature below -29°C or above 26°C is detected by the outdoor pipe temperature sensor.

Malfunction Caused:

- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 2 way valve partially closed.
- 4 Faulty outdoor unit fan motor.
- 5 Refrigerant shortage (refrigerant leakage).
- 6 Clogged expansion valve or strainer.
- 7 Faulty outdoor pipe temperature sensor.
- 8 Faulty outdoor unit main PCB (main).



16.5.11 Abnormal Zone 1 Sensor (H43)

Malfunction Caused:

- 1 Faulty connector connection.
- Faulty buffer tank sensor.
 Faulty indoor sub PCB.

Abnormality Judgment: Continue for 5 seconds.

Abnormal zone 1 sensor			Caution	For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.
Check the turn off power check	connector connection			
Normal?		NO		Poor contact Correct connection
	YES	_		
Check plug out connector from zone 1 connector sub PCB in the PCB measure resistance of zone 1 sensor characteristic match?		NO	-▶	Defective zone sensor Replace sensor
	YES	-		
Defective PCBReplace PCB				

16.5.12 Abnormal Zone 2 Sensor (H44)

Malfunction Caused:

- 1 Faulty connector connection.
- Faulty buffer tank sensor.
 Faulty indoor sub PCB.

Abnormality Judgment: Continue for 5 seconds.

Abnormal zone 2 sensor	,		aution	For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.
Turn off power check connecto	Turn off power check connector connection normal?		•	Correct abnormal connection
	YES	-		
Plug out from sub PCB, check sensor characteristics measure resistance is it match?		NO	•	Change sensor zone 2
	YES	-		
Change PCB]		

16.5.13 Water Flow Switch Abnormality (H62)

Malfunction Decision Conditions:


During operation of cooling and heating, the water flow detected by the indoor water flow switch is used to determine water flow error.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Water leak in system.
- 3 Faulty connector connection.
- 4 Faulty water flow switch.
- 5 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 10 seconds (but no judgment for 9 minutes after compressor startup/restart).



16.5.14 Outdoor High Pressure Abnormality (H64)

Malfunction Decision Conditions:


During operation of cooling and heating, when the outdoor high pressure sensor output signal is 0 Vdc or 5 Vdc.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 20 minutes.



16.5.15 Deice Circulation Error (H65)

Malfunction Decision Conditions:


During startup and operation of deice (mode 2), the water flow (> 10l/min) detected by the water flow switch is used to determine deice circulation error.

Malfunction Caused:

- 1 Water flow in air-to-water heatpump indoor unit circuitry.
- 2 Faulty indoor unit water flow switch.
- 3 Faulty indoor unit water pump.
- 4 Faulty indoor unit PCB.

Abnormality Judgment:

Continue for 10 seconds.




16.5.16 Abnoraml External Thermistor 1 (H67)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty room temperature zone 1 sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

Continue for 5 seconds.




16.5.17 Abnoraml External Thermistor 2 (H68)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty room temperature zone 2 sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

Continue for 5 seconds.



16.5.18 Indoor Backup Heater OLP Abnormality (H70)

Malfunction Decision Conditions:

During operation of indoor backup heater, when no power supplies to indoor backup heater or OLP open circuit.

Malfunction Caused:

- 1 Faulty power supply connector connection.
- 2 Faulty connector connection.
- 3 Faulty indoor backup heater overload protector (OLP).

Caution


4 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 60 seconds.

Troubleshooting:

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.19 Tank Temperature Sensor Abnormality (H72)

Malfunction Decision Conditions:


When tank connection is set to ON, the temperatures detected by the tank temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.



16.5.20 PCB Communication Error (H74)

Malfunction Decision Conditions:


When External PCB connection is select "YES" and no communication or transfer error between Main PCB and External PCB for 10 seconds and above.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty Indoor Main PCB.
- 3 Faulty External PCB.

Abnormality Judgment:

Continue for 10 seconds.



16.5.21 Low Water Temperature Control (H75)

Malfunction Decision Conditions:


When Back-up heater disable and Deice request to operate under low water temperature.

Malfunction Caused:

1 Back-up heater "Disable" under custom menu.

Abnormality Judgment:

HEX protection under Low water temperature HEX protection control.




16.5.22 Indoor-Control Panel Communication Abnormality (H76)

Malfunction Decision Conditions:

During standby and operation of cooling and heating, indoor-control panel error occur.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty control panel.
- 3 Faulty indoor unit PCB (main).



16.5.23 Indoor/Outdoor Abnormal Communication (H90)

Malfunction Decision Conditions:


During operation of cooling and heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

Malfunction Caused:

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty indoor unit PCB (main).
- 3 Indoor-outdoor signal transmission error due to wrong wiring.
- 4 Indoor-outdoor signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.
- 5 Indoor-outdoor signal transmission error due to disturbed power supply waveform.

Abnormality Judgment:

Continue for 1 minute after operation.



16.5.24 Tank Booster Heater OLP Abnormality (H91)

Malfunction Decision Conditions:


During operation of tank booster heater, and tank booster heater OLP open circuit.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty tank booster heater overload protector (OLP).
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 60 seconds.




16.5.25 Unspecified Voltage between Indoor and Outdoor (H95)

Malfunction Decision Conditions:


The supply power is detected for its requirement by the indoor/outdoor transmission.

Malfunction Caused:

- 1 Insufficient power supply.
- 2 Faulty outdoor unit PCB (noise filter/main).



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.26 Outdoor High Pressure Protection (H98)


Malfunction Decision Conditions:

During operation of heating, when pressure 4.0 MPa and above is detected by outdoor high pressure sensor.

Malfunction Caused:

- Faulty water pump. 1
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 2/3 way closed.
- 5 Cloqged expansion valve or strainer.
- 6 Excessive refrigerant.
- 7 Faulty outdoor high pressure sensor.
- 8 Faulty outdoor unit PCB (main).

Troubleshooting:



For safety reason and to prevent component breakdown,

always switch off the power before remove and connect the component.


16.5.27 Indoor Freeze-up Protection (H99)

Malfunction Decision Conditions:

During anti-freezing control in cooling operation, when the indoor refrigerant liquid temperature < 0°C.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 2 way valve partially closed.
- 5 Clogged expansion valve or strainer.
- 6 Refrigerant shortage (refrigerant leakage).
- 7 Faulty indoor refrigerant liquid temperature sensor.
- 8 Faulty indoor unit PCB (main).



16.5.28 Outdoor High Pressure Switch Activate (F12)

Malfunction Decision Conditions:

During operation of cooling and heating, when pressure 4.5 MPa and above is detected by outdoor high pressure switch.

Malfunction Caused:

- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 Faulty water pump.
- 4 Insufficient water flow rate in system.
- 5 Water leak in system.
- 6 2/3 way valve closed.
- 7 Clogged expansion valve or strainer.
- 8 Excessive refrigerant.
- 9 Faulty outdoor high pressure sensor and switch.
- 10 Faulty outdoor unit PCB.


Abnormality Judgment:

Continue 4 times in 20 minutes.





For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.29 Compressor Rotation Failure (F14)

Malfunction Decision Conditions:


A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Caused:

- 1 Compressor terminal disconnect.
- 2 Faulty outdoor unit PCB (main).
- 3 Faulty compressor.

Abnormality Judgment:

Continue 4 times in 20 minutes.



16.5.30 Outdoor Fan Motor (DC Motor) Mechanism Locked (F15)

Malfunction Decision Conditions:


The rotation speed detected by the Hall IC of the fan motor during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550 rpm or < 50 rpm).

Malfunction Caused:

- 1 Operation stop due to short circuit inside the fan motor winding.
- 2 Operation stop due to breaking of wire inside the fan motor.
- 3 Operation stop due to breaking of fan motor lead wires.
- 4 Operation stop due to fan motor Hall IC malfunction.
- 5 Operation error due to faulty outdoor unit PCB.

Abnormality Judgment:

Continue 2 times in 30 minutes.



16.5.31 Input Over Current Detection (F16)

Malfunction Decision Conditions:


During operation of cooling and heating, when outdoor current above 24.1 A (Heating) and 16.4 A (Cooling) [UD07FE5)] and 28.1 A (Heating) and 18.1 A (Cooling) [UD09FE5)] is detected by the current transformer (CT) in the outdoor unit PCB.

Malfunction Caused:

- 1 Excessive refrigerant.
- 2 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 3 times in 20 minutes.



16.5.32 Compressor Overheating (F20)

Malfunction Decision Conditions:


During operation of cooling and heating, when temperature above 112°C is detected by the compressor tank temperature sensor.

Malfunction Caused:

- 1 Faulty compressor tank temperature sensor.
- 2 2/3 way valve closed.
- 3 Refrigerant shortage (refrigerant leakage).
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Faulty compressor.

Abnormality Judgment:

Continue 4 times in 30 minutes.



16.5.33 IPM Overheating (F22)

Malfunction Decision Conditions:


During operation of cooling and heating, when temperature 95°C is detected by the outdoor IPM temperature sensor.

Malfunction Caused:

- 1 Faulty outdoor unit fan motor.
- 2 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 3 times in 30 minutes.



16.5.34 Output Over Current Detection (F23)

Malfunction Decision Conditions:


During operation of cooling and heating, when outdoor DC current is above 34 A is detected by the IPM DC Peak sensing circuitry in the outdoor unit PCB (main).


Malfunction Caused:

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty compressor.

Abnormality Judgment:

Continue for 7 times.





16.5.35 Refrigeration Cycle Abnormality (F24) (WH-UD03HE5-1 and WH-UD05HE-1)

Malfunction Decision Conditions:


- 1 During operation of cooling and heating, compressor frequency > Frated.
- 2 During operation of cooling and heating, running current: 0.65 A < I < 1.65 A.
- 3 During operation of cooling, water inlet temperature indoor refrigerant liquid temperature < 5°C.
- 4 During operation of heating, indoor refrigerant liquid temperature water inlet temperature < 5°C.

Malfunction Caused:

- 1 Faulty water inlet or indoor refrigerant liquid temperature sensors.
- 2 2/3 way valve closed.
- 3 Refrigerant shortage (refrigerant leakage).
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Poor compression of compressor.

Abnormality Judgment:

Continue 2 times in 20 minutes.



16.5.36 Refrigeration Cycle Abnormality (F24) (WH-UD07HE5-1 and WH-UD09HE-1)

Malfunction Decision Conditions:


- 1 During operation running (heating / cooling) for more than 10 minutes expect deice, pumpdown and test mode.
- 2 During heating / cooling, water outlet and water inlet difference is less than 1°C.
- 3 During heating / cooling, high pressure < 1MPa (143 Psi) for more than 10 minutes or < 0.2 MPa (28 Psi) for more than 5 minutes.
- 4 During heating / cooling, discharge temperature saturation temperature of high pressure \geq 60°C.

Malfunction Caused:

- 1 Refrigerant shortage (refrigerant leakage).
- 2 Faulty indoor water inlet, indoor water outlet, compressor discharge temp sensor or high pressure sensor.
- 3 2/3 way valve closed.
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 2 times in 20 minutes.



16.5.37 Four Way Valve Abnormality (F25)

Malfunction Decision Conditions:


- 1 During heating operation, when the indoor pipe temperature of thermostat ON indoor unit < 0°C.
- 2 During cooling operation, when the indoor pipe temperature of thermostat ON indoor unit > 45°C.

Malfunction Caused:

- 1 Faulty sensor.
- 2 Faulty connector connection.
- 3 Faulty outdoor unit PCB (noise filter/main).
- 4 Faulty four way valve.

Abnormality Judgment:

Continue 4 times in 30 minutes.



16.5.38 Outdoor High Pressure Switch Abnormal (F27)

Malfunction Decision Conditions:


During compressor stop, and outdoor high pressure switch is remain opened.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty switch.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 1 minute.



16.5.39 Low Discharge Superheat (F29)

Malfunction Decision Conditions:


During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).
- 4 Faulty High Pressure Switch
- 5 Refrigerant shortage (refrigerant leakage).

Abnormality Judgment:

1 times occurrence within 2550 minutes.



16.5.40 Indoor Water Outlet Temperature Sensor 2 Abnormality (F30)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor 2 are used to determine sensor error.

Malfunction Caused:


- 6 Faulty connector connection.
- 7 Faulty sensor.
- 8 Faulty indoor unit PCB.

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





16.5.41 Abnormal Internal Thermostat (F32)

Malfunction Decision Conditions:

When Zone 1 or Zone 2 room sensor select use internal thermostat AND


- Internal thermostat open circuit: less than °C continuously for 5 seconds OR
- Internal thermostat short circuit: 127°C or more continuously for 5 seconds.

Malfunction Caused:

- 1 Faulty wiring connection
- 2 Faulty Indoor PCB
- 3 Faulty remote controller

Abnormality Judgment:

Continue for 5 seconds.



16.5.42 Outdoor Air Temperature Sensor Abnormality (F36)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





16.5.43 Indoor Water Inlet Temperature Sensor Abnormality (F37)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water inlet temperature sensor are used to determine sensor error.


Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

For safety reason and to prevent component breakdown, **Troubleshooting:** Caution always switch off the power before remove and connect the component. Check the CN-TH1 connector connection: - Turn OFF the power - Check the connector connection No Is the CN-TH1 connector - Connector poor contact connection normal? Correct the connection Yes Check the indoor water inlet temperature sensor: - Plug out connector from the indoor unit PCB (main) - Measure the resistance of the indoor water inlet temperature sensor



16.5.44 Outdoor Discharge Pipe Temperature Sensor Abnormality (F40)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





16.5.45 Power Factor Correction (PFC) Abnormality (F41)

Malfunction Decision Conditions:


During operation of cooling and heating, when the PFC protection circuitry in the outdoor unit PCB (main) senses abnormal high DC voltage level.

Malfunction Caused:

- 1 Power supply surge.
- 2 Compressor windings not uniform.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 10 minutes.



16.5.46 Outdoor Pipe Temperature Sensor Abnormality (F42)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





16.5.47 Outdoor Defrost Temperature Sensor Abnormality (F43)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor defrost temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:

Caution



16.5.48 Indoor Water Outlet Temperature Sensor Abnormality (F45)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor are used to determine sensor errors.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





16.5.49 Outdoor Current Transformer Open Circuit (F46)

Malfunction Decision Conditions:

A current transformer (CT) open circuit is detected by checking the compressor running frequency (\geq rated frequency) and CT detected input current (< 0.65 A) for continuously 20 seconds.


Malfunction Caused:

- 1 CT defective.
- 2 Faulty outdoor unit PCB (main).
- 3 Compressor defective (low compression).

Abnormality Judgment:

Continue 3 times in 20 minutes.

Troubleshooting: A Caution



16.5.50 Outdoor Eva Outlet Temperature Sensor Abnormality (F48)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperature detected by outdoor Eva outlet temperature sensor are used to determine sensor error.


Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty Indoor PCB.

Abnormality Judgment:

Temperature (°C)

Continue for 5 seconds.



16.5.51 Outdoor Bypass Outlet Temperature Sensor Abnormality (F49)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperature detected by outdoor Bypass Outlet temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty Indoor PCB.

Abnormality Judgment:

-10 0 10 20 30 40 50

Temperature (°C)

Continue for 5 seconds.




16.5.52 Cooling High Pressure Overload Protection (F95)

Malfunction Decision Conditions:

During operation of cooling, when pressure 4.0 MPa and above is detected by outdoor high pressure sensor.

Malfunction Caused:

- Dust accumulation in the outdoor unit heat exchanger. 1
- 2 Air short circuit at outdoor unit.
- 3 2 way valve closed.
- 4 Faulty outdoor unit fan motor.
- 5 Cloqged expansion valve or strainer.
- 6 Excessive refrigerant.
- 7 Faulty outdoor high pressure sensor.
- 8 Faulty outdoor unit PCB (main).




For safety reason and to prevent component breakdown,

17. Disassembly and Assembly Instructions

High Voltage are generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.

Be sure to switch off all the power supply before performing each of the below action.


17.1 To Remove The Cabinet Front Plate




- 1. Remove 4 mounting screws.
- 2. Slide the cabinet frort plate downward to release the pawls. Then, pull it toward front to remove it.

17.2 To Remove The Cabinet Top Plate


- 1. Remove the 13 mounting screws
- 2. Lift the cabinet top plate
 - upward to remove it.




17.3 To Remove The Cabinet Rear Plate




17.4 To Remove Pressure Gauge




17.5 To Remove Water System Electronic Controller Board




17.6 To Remove Air Purge Valve




17.7 To Remove Flow Sensor




17.8 To Remove Water Pump




 \bigwedge When reinstall the water pipe, use grease or water at the joining.





17.10 To Remove Filter




18. Technical Data

18.1 Operation Characteristics

18.1.1 WH-MXC09H3E8


Heating Characteristics at Different Outdoor Air Temperature

Condition Outdoor air temperature : 7°C (DBT), 6°C (WBT) Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C Piping length : 7 m



Cooling Characteristics at Different Outdoor Air Temperature

Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C Piping length : 7 m




18.1.2 WH-MXC12H9E8

Heating Characteristics at Different Outdoor Air Temperature


Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT) Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C Piping length : 7 m



Cooling Characteristics at Different Outdoor Air Temperature

Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C Piping length : 7 m




18.1.3 WH-MXC16H9E8

Heating Characteristics at Different Outdoor Air Temperature


Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT) Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C Piping length : 7 m




Cooling Characteristics at Different Outdoor Air Temperature

Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C Piping length : 7 m



Cooling Characteristics at Different Outdoor Air Temperature

Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 12°C Indoor water outlet temperature : 18°C Piping length : 7 m



18.2 Heating Capacity Table

18.2.1 WH-MXC09H3E8

Water Out (°C)	3	0	3	5	4	0	4	5	5	0	5	5
Outdoor Air (°C)	Capacity (W)	Input Power (W)										
-15	9000	3240	9000	3510	9000	3910	9000	4300	9000	4730	9000	5160
-7	9000	2710	9000	3160	9000	3620	9000	4070	9000	4270	9000	4460
2	9000	2360	9000	2510	9000	2780	9000	3050	9000	3560	9000	4070
7	9000	1640	9000	1860	9000	2160	9000	2460	9000	2760	9000	3060
25	13600	1500	13600	1710	13200	1930	12800	2140	12000	2410	11200	2670

18.2.2 WH-MXC12H9E8

Water Out (°C)	3	0	3	5	4	0	4	5	5	0	5	5
Outdoor Air (°C)	Capacity (W)	Input Power (W)										
-15	12000	4750	12000	4960	12000	5410	12000	5860	11800	6240	11600	6620
-7	12000	3850	12000	4410	12000	4980	12000	5540	12000	5900	12000	6260
2	12000	3190	12000	3490	12000	3870	12000	4250	12000	4860	12000	5470
7	12000	2180	12000	2530	12000	2960	12000	3390	12000	3780	12000	4160
25	13600	1550	13600	1760	13400	2100	13200	2430	12600	2660	12000	2890

18.2.3 WH-MXC16H9E8

Water Out (°C)	3	0	3	5	4	0	4	5	5	0	5	5
Outdoor Air (°C)	Capacity (W)	Input Power (W)										
-15	16000	6300	16000	6890	16000	7450	16000	8100	16000	8480	15200	8960
-7	16000	5850	16000	6420	16000	7000	16000	7570	16000	8100	16000	8620
2	16000	4670	16000	5210	16000	5740	16000	6310	16000	6900	16000	7500
7	16000	3350	16000	3740	16000	4300	16000	4800	16000	5430	16000	5910
16	16000	2590	16000	3180	16000	3710	16000	4270	16000	4860	16000	5220
25	16000	2020	16000	2580	16000	2910	16000	3360	16000	3740	16000	4000

18.3 Cooling Capacity Table

18.3.1 WH-MXC09H3E8 WH-MXC12H9E8


	WH-M	IXC09	WH-MXC12		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Capacity (W)	Input Power (W)	
18	7000	1360	7500	1410	
25	7650	1910	8900	2160	
35	7000	2210	10000	3560	
43	6250	2660	8000	3010	

18.3.2 WH-MXC16H9E8

Water Out (°C)	-	7	1	8
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Capacity (W)	Input Power (W)
18	8500	1700	10000	1700
25	14000	4000	14000	2940
35	12200	4760	12200	3500
43	7100	3310	9800	3310

19. Exploded View and Replacement Parts List


19.1 Water System



Note:


The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.

19.2 Refrigerant System




Note:

The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.



Note:

The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.



Note:

The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.

<Water System>

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-MXC09H3E8	REMARK
	1	BASE PAN ASS'Y	1	ACXD52K02760	
	2	HOT WATER COIL-COMPLETE	1	ACXB90C00620	0
	3	FLOW SWITCH	1	CWB621137	0
	4	PUMP	1	CWB532116	0
	5	HEATER ASS'Y	1	ACXA34K00380	0
	6	SOUND PROOF MATERIAL	1	CWG302594	
Ŵ	7	THERMOSTAT	4	CWA151074	0
$\overline{\mathbb{A}}$	8	ELECTRONIC CONTROLLER (MAIN)	1	ACXA73C40130R	0
Ā	9	TERMINAL BOARD ASS'Y(A,B)	1	CWA28K1340	0
	10	SOUND PROOF MATERIAL	1	CWG302599	
\wedge	11	TERMINAL BOARD ASS'Y(1,2,3,4,5,6)	1	CWA28K1341	0
$\overline{\mathbb{M}}$	12	TERMINAL BOARD ASS'Y(7,8,9,10,11,12)	1	CWA28K1340	0
$\overline{\mathbb{A}}$	13	TERMINAL BOARD ASS'Y(13,14,15,16,17,18)	1	CWA28K1343	0
$\overline{\mathbb{A}}$	14	TERMINAL BOARD ASS'Y (A) / (A,B)	1	CWA28K1260	0
$\overline{\mathbb{A}}$	15	REACTOR	1	G0C103Z00003	0
	16	AIR PURGE VALVE	1	ACXB62-00130	0
	17	PRESSURE GAUGE	1	CWB070003	0
	18	PRESSURE RELIEF VALVE	1	ACXB62-00100	0
	19	CIRCUIT BREAKER	1	CWA181005	0
	20	FILTER COMPLETE	1	CWB51C1021	
	21	SENSOR-COMPLETE(WATER IN,OUT, REF TEMP)	1	ACXA50C13330	0
	22	SENSOR-COMPLETE(HEX WATER OUTLET)	1	ACXA50C13140	0
	23	REMOTE CONTROL COMPLETE	1	CWA75C4681	0
	24	RECEIVER	1	CWB141039	
	25	HOLDER COUPLING	1	ACXH35-01510A	
	26	CABINET SIDE PLATE ASS'Y	1	ACXE04-09480A	
	27	HANDLE	2	CWE161014	
	28	CABINET FRONT PLATE	1	ACXE06-03550A	
	29	CONNECTING BAR	1	CWE261313A	
	30	CONNECTING BAR	1	CWE261214A	
	31	PANASONIC BADGE	1	CWE373439	
	32	INVERTER BADGE	1	CWE373441	
	33	OPERATING INSTRUCTION	1	ACXF55-14590	
	34	OPERATING INSTRUCTION	1	ACXF55-14600	
	35	OPERATING INSTRUCTION	1	ACXF55-14610	
	36	OPERATING INSTRUCTION	1	ACXF55-14620	
	37	OPERATING INSTRUCTION	1	ACXF55-14630	
	38	OPERATING INSTRUCTION	1	ACXF55-14640	
	39	INSTALLATION INSTRUCTION	1	ACXF60-30020	
	40	INSTALLATION INSTRUCTION	1	ACXF60-17020	
	41	SOUND PROOF MATERIAL	1	ACXG30-07660	
	42	BAG	1	CWG861452	
	43	SHOCK ABSORBER	1	CWG713241	
	44	SHOCK ABSORBER	1	CWG713242	
	45	SHOCK ABSORBER	1	CWG713243	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-MXC09H3E8	REMARK
	46	BASE BOARD-COMPLETE	1	CWG62C1132	
	47	C.C.CASE	1	CWG568053	
	48	CIRCUIT BREAKER	1	CWA181008	0
	49	TERMINAL COVER	1	CWH171051	
	50	GASKET FOR TERMINAL COVER	1	CWB811177	

Note:

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock. ٠
- •

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-MXC12H9E8	WH-MXC16H9E8	REMARK
	1	BASE PAN ASS'Y	1	ACXD52K02760	←	
	2	HOT WATER COIL-COMPLETE	1	ACXB90C00620	ACXB90C00730	0
	3	FLOW SWITCH	1	CWB621137	←	0
	4	PUMP	1	CWB532116	←	0
	5	HEATER ASS'Y	1	ACXA34K00390	←	0
	6	SOUND PROOF MATERIAL	1	CWG302594	←	
\wedge	7	THERMOSTAT	4	CWA151074	←	0
$\overline{\mathbb{A}}$	8	ELECTRONIC CONTROLLER (MAIN)	1	ACXA73C40140R	ACXA73C40150R	0
$\overline{\mathbb{A}}$	9	TERMINAL BOARD ASS'Y(A,B)	1	CWA28K1340	←	0
	10	SOUND PROOF MATERIAL	1	CWG302599	<i>←</i>	
\square	11	TERMINAL BOARD ASS'Y(1,2,3,4,5,6)	1	CWA28K1341	←	0
$\underline{\Lambda}$	12	TERMINAL BOARD ASS'Y(7,8,9,10,11,12)	1	CWA28K1340	←	0
$\underline{\Lambda}$	13	TERMINAL BOARD ASS'Y(13,14,15,16,17,18)	1	CWA28K1343	←	0
$\underline{\Lambda}$	14	TERMINAL BOARD ASS'Y (A) / (A,B)	1	CWA28K1238	←	0
$\overline{\mathbb{A}}$	15	REACTOR	1	G0C103Z00003	←	0
<u> </u>	16	AIR PURGE VALVE	1	ACXB62-00130	`` ←	0
	10	PRESSURE GAUGE	1	CWB070003		0
	17	PRESSURE RELIEF VALVE	1	ACXB62-00100		0
	_				<i>←</i>	0
	20		1	CWB51C1021	→	
	21	SENSOR-COMPLETE(WATER IN,OUT, REF TEMP)	1	ACXA50C13330	→	0
	22	SENSOR-COMPLETE(HEX WATER OUTLET)	1	ACXA50C13140	→	0
	23	REMOTE CONTROL COMPLETE	1	CWA75C4681	<i>←</i>	0
	24	RECEIVER	1	CWB141039	<i>←</i>	
	25	HOLDER COUPLING	1	ACXH35-01510A	<i>←</i>	
	26	CABINET SIDE PLATE ASS'Y	1	ACXE04-09480A	<i>←</i>	
	27	HANDLE	2	CWE161014	←	
	28	CABINET FRONT PLATE	1	ACXE06-03550A	←	
	29	CONNECTING BAR	1	CWE261313A	←	
	30	CONNECTING BAR	1	CWE261214A	<i>←</i>	
	31	PANASONIC BADGE	1	CWE373439	<i>←</i>	
	32	INVERTER BADGE	1	CWE373441	←	
	33	OPERATING INSTRUCTION	1	ACXF55-14590	\leftarrow	
	34	OPERATING INSTRUCTION	1	ACXF55-14600	\leftarrow	
	35	OPERATING INSTRUCTION	1	ACXF55-14610	←	
	36	OPERATING INSTRUCTION	1	ACXF55-14620	←	
	37	OPERATING INSTRUCTION	1	ACXF55-14630	←	
	38	OPERATING INSTRUCTION	1	ACXF55-14640	←	
	39	INSTALLATION INSTRUCTION	1	ACXF60-30020	←	
	40	INSTALLATION INSTRUCTION	1	ACXF60-17020	←	
	41	SOUND PROOF MATERIAL	1	ACXG30-07660	←	
	42	BAG	1	CWG861452	←	
	43	SHOCK ABSORBER	1	CWG713241	←	
	44	SHOCK ABSORBER	1	CWG713242	←	
	45	SHOCK ABSORBER	1	CWG713243		
	46	BASE BOARD-COMPLETE	1	CWG62C1132		
			1 '	01100201102	~	1

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-MXC12H9E8	WH-MXC16H9E8	REMARK
	48	CIRCUIT BREAKER	2	CWA181008	\leftarrow	0
	49	TERMINAL COVER	1	CWH171051	\leftarrow	
	50	GASKET FOR TERMINAL COVER	1	CWB811177	\leftarrow	

Note:

All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock. ٠

•

<Refrigerant System>

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-MXC09H3E8	WH-MXC12H9E8	REMARK
	1	BASE PAN ASS'Y	1	CWD52K1276	←	
\wedge	2	COMPRESSOR	1	5JD420XBA22	←	0
	3	BUSHING - COMPRESSOR MOUNT	3	CWH50055	←	
	4	NUT-COMPRESSOR MOUNT	3	CWH561049	←	
	5	CRANKCASE HEATER	1	ACXA34-00110	←	
	6	CONDENSER COMPLETE	1	CWB32C3891	←	
	7	HIGH PRESSURE SENSOR	1	CWA501463	←	0
	8	DISCHARGE MUFFLER	1	CWB121014	←	
	9	HIGH PRESSURE SWITCH	1	CWA101013	←	0
	10	3-WAYS VALVE (GAS)	1	CWB011699	←	0
	11	4-WAYS VALVE	1	CWB001046	←	0
	12	3-WAYS VALVE(LIQUID)	1	CWB011700	←	0
	13	STRAINER	4	CWB111032	←	
	14	GASKET FOR TERMINAL COVER	3	CWB811017	←	
	15	RECEIVER	1	CWB141069	←	
	20	SOUND PROOF MATERIAL - COMP. BODY	1	ACXG30-00850	←	
	21	SOUND PROOF MATERIAL - COMP. TOP	1	CWG302266	←	
	22	SOUND PROOF BOARD	1	CWH151243	←	
	23	V-COIL COMPLETE(4 WAY VALVE)	1	CWA43C2169J	←	0
	24	V-COIL COMPLETE(MAIN EXPANSION VALVE)	1	CWA43C2602	←	0
	25	SENSOR-COMP.(OUTDOOR AIR,PIPE TEMP)	1	CWA50C2730	←	0
	26	SENSOR-COMP.(DISCHARGE TEMP)	1	CWA50C2576	←	0
	28	CABINET REAR PLATE-COMPLETE	1	ACXE02-02020A	←	
	29	CONTROL BOARD CASING	1	CWH10K1049	←	
	30	SENSOR-COMP.(DEFROST TEMP)	1	CWA50C2577	←	0
	31	TERMINAL BOARD ASS'Y(1,2,3,4,5)	1	CWA28K1240	←	0
Â	34	TERMINAL COVER	1	CWH171039A	←	
$\overline{\mathbb{A}}$	35	NUT - TERMINAL COVER	1	CWH7080300J	←	
$\overline{\mathbb{A}}$	38	ELECTRONIC CO.(NOISE FILTER)	1	CWA747838	←	0
$\overline{\mathbb{A}}$	44	ELECTRONIC CONTROLLER (MAIN)	1	ACXA73C40840R	ACXA73C40850R	0
$\overline{\mathbb{N}}$	46	REACTOR - MAIN	3	G0C293J00001	←	0
$\overline{\mathbb{A}}$	50	FAN MOTOR BRACKET	1	CWD54K1084	←	
	51	SCREW-FAN MOTOR BRACKET	2	CWH551040J	←	
	52	FAN MOTOR(UPPER)	1	EHDS83LAC	←	0
\wedge	53	FAN MOTOR(LOWER)	1	EHDS83MAC	←	0
$\overline{\mathbb{A}}$	54	SCREW-FAN MOTOR MOUNT	8	CWH551323	←	
	55	PROPELLER FAN ASSY	2	CWH00K1006	←	
	56	NUT	2	CWH561092	←	
	57	CABINET FRONT PLATE	1	CWE061098A	←	
	58	DISCHARGE GRILLE	2	CWE201073	←	0
	59	CABINET SIDE PLATE ASSY	1	CWE04K1023A	←	
	60	WIRE NET	1	CWD041069	←	
	61	CABINET TOP PLATE	1	CWE03C1105	←	
	62	ACCESSORY CO.(RUBBER CAP)	1	CWH82C1839	←	
	66	CABINET FRONT PLATE	1	CWE061274A	←	
	67	HANDLE	2	CWE161014	<i>←</i>	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-MXC09H3E8	WH-MXC12H9E8	REMARK
	68	TUBE ASSY (CAP.TUBE)	1	CWT07K1606	←	
	70	EXPANSION VALVE (1)	1	CWB051049	←	0
	71	EXPANSION VALVE (2)	1	CWB051029	←	
	72	2-WAYS VALVE(LIQUID)	1	CWB021637	←	0
	73	V-COIL COMPLETE(2-WAY VALVE)	1	CWA43C2607	←	0
	74	V-COIL COMPLETE(BYPASS EXPANSION VALVE)	1	CWA43C2335	←	0
	75	ACCESSORY CO.(DRAIN ELBOW)	1	CWG87C900	←	
	76	HEATER	1	CWA341071	←	0
\wedge	78	SENSOR COMPLETE (BYPASS & EVA EXIT TEMP)	1	CWA50C3165	←	0
	80	SOUND PROOF MATERIAL	1	CWG302598	←	
	82	ELECTRO MAGNETIC SWITCH	1	K6C2AGA00002	←	0
\wedge	83	ELECTRO MAGNETIC SWITCH	1	K6C4E8A00001	←	0
	84	REACTOR - SUB	3	G0C153J00009	←	0
	85	PTC THERMISTORS	1	D4DDG1010001	←	0
	86	CAPACITOR	3	DS441205NPQA	←	0
	87	LEADWIRE COMPRESSOR	1	CWA67C9411	←	
	88	SENSOR-COMPLETE (CN-TANK)	1	CWA50C2629	←	
	89	FLEXIBLE PIPE (L-TUBE)	1	CWH5850080	←	
	90	PACKING-L.TUBE	1	CWB81012	←	

Note:

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-MXC16H9E8	REMARK
	1	BASE PAN ASS'Y	1	CWD52K1276	
\mathbf{V}	2	COMPRESSOR	1	5JD650XBA22	0
	3	BUSHING - COMPRESSOR MOUNT	3	CWH50055	
	4	NUT-COMPRESSOR MOUNT	3	CWH561049	
	5	CRANKCASE HEATER	1	ACXA34-00110	
	6	CONDENSER COMPLETE	1	ACXB32C0001	
	7	HIGH PRESSURE SENSOR	1	CWA501463	0
	8	DISCHARGE MUFFLER	1	CWB121014	
	9	HIGH PRESSURE SWITCH	1	CWA101013	0
	10	3-WAYS VALVE (GAS)	1	CWB011699	0
	11	4-WAYS VALVE	1	CWB001046	0
	12	3-WAYS VALVE(LIQUID)	1	CWB011700	0
	13	STRAINER	4	CWB111032	
	14	GASKET FOR TERMINAL COVER	3	CWB811017	
	15	RECEIVER	1	CWB141069	
	20	SOUND PROOF MATERIAL - COMP. BODY	1	CWG302795	
	21	SOUND PROOF MATERIAL - COMP. TOP	1	CWG302266	
	22	SOUND PROOF BOARD	1	CWH151243	
	23	V-COIL COMPLETE(4 WAY VALVE)	1	CWA43C2169J	0
	24	V-COIL COMPLETE(MAIN EXPANSION VALVE)	1	CWA43C2602	0
	25	SENSOR-COMP.(OUTDOOR AIR,PIPE TEMP)	1	CWA50C2730	0
	26	SENSOR-COMP.(DISCHARGE TEMP)	1	CWA50C2576	0
	28	CABINET REAR PLATE-COMPLETE	1	ACXE02-02020A	
	29	CONTROL BOARD CASING	1	CWH10K1228	
	30	SENSOR-COMP.(DEFROST TEMP)	1	CWA50C2577	0
	31	TERMINAL BOARD ASS'Y(1,2,3,4,5)	1	CWA28K1240	0
\wedge	32	TERMINAL BOARD ASS'Y(U,V,W)	1	CWA28K1335	0
	38	ELECTRONIC CO.(NOISE FILTER)	1	CWA747735	0
$\overline{\mathbb{N}}$	44	ELECTRONIC CONTROLLER (MAIN)	1	ACXA73C40860R	0
	46	REACTOR - MAIN	3	G0C213J00001	0
$\overline{\mathbb{N}}$	50	FAN MOTOR BRACKET	1	CWD54K1024	
$\overline{\mathbb{A}}$	51	SCREW-FAN MOTOR BRACKET	2	CWH551040J	
	52	FAN MOTOR(UPPER)	1	EHDS83LAC	0
	53	FAN MOTOR(LOWER)	1	EHDS83MAC	0
\wedge	54	SCREW-FAN MOTOR MOUNT	8	CWH551323	
Ň	55	PROPELLER FAN ASSY	2	CWH00K1006	
	56	NUT	2	CWH561092	
	57	CABINET FRONT PLATE	1	CWE061098A	
	58	DISCHARGE GRILLE	2	CWE201073	0
	59	CABINET SIDE PLATE ASSY	1	CWE04K1023A	
	60	WIRE NET	1	CWD041069	
	61	CABINET TOP PLATE	1	CWE03C1105	
	62	ACCESSORY CO.(RUBBER CAP)	1	CWH82C1839	
	66	CABINET FRONT PLATE	1	CWE061274A	
	67	HANDLE	2	CWE161014	
	68	TUBE ASSY (CAP.TUBE)	1	CWT07K1742	
	70	EXPANSION VALVE (1)	1	CWB051049	0

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-MXC16H9E8	REMARK
	71	EXPANSION VALVE (2)	1	CWB051029	
	72	2-WAYS VALVE(LIQUID)	1	CWB021637	0
	73	V-COIL COMPLETE(2-WAY VALVE)	1	CWA43C2607	0
	74	V-COIL COMPLETE(BYPASS EXPANSION VALVE)	1	CWA43C2335	0
	75	ACCESSORY CO.(DRAIN ELBOW)	1	CWG87C900	
	76	HEATER	1	CWA341071	0
	78	SENSOR COMPLETE (BYPASS & EVA EXIT TEMP)	1	CWA50C3165	0
	80	SOUND PROOF MATERIAL	1	CWG302598	
	82	ELECTRO MAGNETIC SWITCH	1	K6C2AGA00002	0
	83	ELECTRO MAGNETIC SWITCH	1	K6C4E8A00001	0
	84	REACTOR - SUB	3	G0C353J00001	0
	85	PTC THERMISTORS	1	D4DDG1010001	0
	86	CAPACITOR	3	DS451605DPQB	0
	87	LEADWIRE COMPRESSOR	1	ACXA60C62280	
	88	SENSOR-COMPLETE (CN-TANK)	1	-	
	89	FLEXIBLE PIPE (L-TUBE)	1	CWH5850080	
	90	PACKING-L.TUBE	1	CWB81012	

Note:

• All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).

• "O" marked parts are recommended to be kept in stock.